

IEEE Guide for the Application of Metal-Oxide Surge Arresters for Alternating-Current Systems

Sponsor

**Surge Protective Devices Committee
of the
IEEE Power Engineering Society**

Approved 9 December 1997

IEEE Standards Board

Abstract: The application of metal-oxide surge arresters to safeguard electric power equipment against the hazards of abnormally high voltage surges of various origins is covered. Step-by-step directions toward proper solutions of various applications are provided. In many cases, the prescribed steps are adequate. More complex and special solutions requiring study by experienced engineers are described, but specific solutions are not always given. The procedures are based on theoretical studies, test results, and experience.

Keywords: electric power equipment, high-voltage surges, metal-oxide surge arresters, surge arresters, surge-protective devices

The Institute of Electrical and Electronics Engineers, Inc.
345 East 47th Street, New York, NY 10017-2394, USA

Copyright © 1998 by the Institute of Electrical and Electronics Engineers, Inc.
All rights reserved. Published 1998. Printed in the United States of America.

ISBN 1-55937-988-X

No part of this publication may be reproduced in any form, in an electronic retrieval system or otherwise, without the prior written permission of the publisher.

IEEE Standards documents are developed within the IEEE Societies and the Standards Coordinating Committees of the IEEE Standards Board. Members of the committees serve voluntarily and without compensation. They are not necessarily members of the Institute. The standards developed within IEEE represent a consensus of the broad expertise on the subject within the Institute as well as those activities outside of IEEE that have expressed an interest in participating in the development of the standard.

Use of an IEEE Standard is wholly voluntary. The existence of an IEEE Standard does not imply that there are no other ways to produce, test, measure, purchase, market, or provide other goods and services related to the scope of the IEEE Standard. Furthermore, the viewpoint expressed at the time a standard is approved and issued is subject to change brought about through developments in the state of the art and comments received from users of the standard. Every IEEE Standard is subjected to review at least every five years for revision or reaffirmation. When a document is more than five years old and has not been reaffirmed, it is reasonable to conclude that its contents, although still of some value, do not wholly reflect the present state of the art. Users are cautioned to check to determine that they have the latest edition of any IEEE Standard.

Comments for revision of IEEE Standards are welcome from any interested party, regardless of membership affiliation with IEEE. Suggestions for changes in documents should be in the form of a proposed change of text, together with appropriate supporting comments.

Interpretations: Occasionally questions may arise regarding the meaning of portions of standards as they relate to specific applications. When the need for interpretations is brought to the attention of IEEE, the Institute will initiate action to prepare appropriate responses. Since IEEE Standards represent a consensus of all concerned interests, it is important to ensure that any interpretation has also received the concurrence of a balance of interests. For this reason, IEEE and the members of its societies and Standards Coordinating Committees are not able to provide an instant response to interpretation requests except in those cases where the matter has previously received formal consideration.

Comments on standards and requests for interpretations should be addressed to:

Secretary, IEEE Standards Board
445 Hoes Lane
P.O. Box 1331
Piscataway, NJ 08855-1331
USA

Note: Attention is called to the possibility that implementation of this standard may require use of subject matter covered by patent rights. By publication of this standard, no position is taken with respect to the existence or validity of any patent rights in connection therewith. The IEEE shall not be responsible for identifying patents for which a license may be required by an IEEE standard or for conducting inquiries into the legal validity or scope of those patents that are brought to its attention.

Authorization to photocopy portions of any individual standard for internal or personal use is granted by the Institute of Electrical and Electronics Engineers, Inc., provided that the appropriate fee is paid to Copyright Clearance Center. To arrange for payment of licensing fee, please contact Copyright Clearance Center, Customer Service, 222 Rosewood Drive, Danvers, MA 01923 USA; (508) 750-8400. Permission to photocopy portions of any individual standard for educational classroom use can also be obtained through the Copyright Clearance Center.

Introduction

(This introduction is not part of IEEE Std C62.22-1997, IEEE Guide for the Application of Metal-Oxide Surge Arresters for Alternating-Current Systems.)

This guide presents the suggested application methods for using metal-oxide surge arresters when applied to ac power systems. This guide was written for arresters with and without gaps. Soon to be published IEC 99-5 is a similar standard used in the international community for arresters without gaps.

Material for this guide has been developed over many years. This edition has been compiled by Working Group 3.4.14 of the Application of Surge Protective Devices (ASPD) Subcommittee, Surge Protective Devices (SPD) Committee.

At the time this standard was completed, Working Group 3.4.14 had the following membership:

Jonathan J. Woodworth, *Chair*

Gene Baker
Philip P. Barker
Tom Bialek
R. Gordon Black
H. Steve Brewer
James J. Burke
Michael G. Comber
Tom Compton
Joslyn Corporation
John P. DuPont
Cliff C. Erven
H. Edward Foelker

Steve Hensley
Andrew R. Hileman
Hieu Huynh
David W. Jackson
Bengt Johnnerfelt
Joseph L. Koepfinger
Michael V. Lat
Gerald E. Lee
Antonio L. Lim
Jeff Mackevich
William A. Maguire
David J. Melvold

Yasin I. Musa
Ken Nolan
Joseph C. Osterhout
John B. Posey
Brian T. Steinbrecher
Keith B. Stump
Eva J. Tarasiewicz
Edgar R. Taylor, Jr.
Rao S. Thallam
Arnold Vitols
Reigh A. Walling
James W. Wilson, Jr.

The following persons were on the balloting committee:

Charles L. Ballentine
James J. Burke
Mike G. Comber
Douglas C. Dawson
Michele de Nigris
John P. DuPont
Cliff C. Erven
H. Edward Foelker
Andrew R. Hileman
David W. Jackson
Bengt Johnnerfelt
Robert A. Jones

Jeff J. Kester
Gerald E. Lee
Dennis W. Lenk
R. Thomas Leskovich
Antonio L. Lim
Jeff Mackevich
William A. Maguire
Francois D. Martzloff
David J. Melvold
Yasin I. Musa
Joseph C. Osterhout

Michael Parente
John B. Posey
Hans Steinhoff
Keith B. Stump
Andy Sweetana
Edgar R. Taylor, Jr.
Rao S. Thallam
Arnold Vitols
Steve G. Whisenant
James W. Wilson, Jr.
Jonathan J. Woodworth
Donald M. Worden

When the IEEE Standards Board approved this standard on 9 December 1997, it had the following membership:

Donald C. Loughry, *Chair*

Richard J. Holleman, *Vice Chair*

Andrew G. Salem, *Secretary*

Clyde R. Camp
Stephen L. Diamond
Harold E. Epstein
Donald C. Fleckenstein
Jay Forster*
Thomas F. Garrity
Donald N. Heirman
Jim Isaak
Ben C. Johnson

Lowell Johnson
Robert Kennelly
E. G. "Al" Kiener
Joseph L. Koepfinger*
Stephen R. Lambert
Lawrence V. McCall
L. Bruce McClung
Marco W. Migliaro

Louis-François Pau
Gerald H. Peterson
John W. Pope
Jose R. Ramos
Ronald H. Reimer
Ingo Rüsich
John S. Ryan
Chee Kiow Tan
Howard L. Wolfman

*Member Emeritus

Also included are the following nonvoting IEEE Standards Board liaisons:

Satish K. Aggarwal
Alan H. Cookson

Noelle D. Humenick
IEEE Standards Project Editor

IEEE Guide for the Application of Metal-Oxide Surge Arresters for Alternating-Current Systems

1. Scope

This guide covers the application of metal-oxide surge arresters (see IEEE Std C62.11-1993) to safeguard electric power equipment against the hazards of abnormally high voltage surges of various origins. Such overvoltages may cause flashovers and serious damage to equipment and thereby jeopardize the supply of power to users. It is essential to prevent this by the proper coordination of surge-protective devices with the insulation strength of the protected equipment.

This application guide does not cover the application of low-voltage surge protective devices below 1000 V ac. However, it references these devices when applied to the secondary of a transformer since they are part of the transformer protection.

The subject is broad, with many ramifications, and it requires a volume of considerable bulk to explain all possible cases in detail. Clause 5 of this guide covers the basic cases for stations used to supply and switch electric power transmission, subtransmission, or distribution feeders. Information is included in Clause 6 on application of arresters for protection of overhead and underground distribution systems, all distribution transformers, and other electric distribution equipment.

Step-by-step directions toward proper solutions for various applications are provided. In many cases, the prescribed steps are adequate. More complex and special situations requiring study by experienced engineers are described, but specific solutions may not be given. These procedures are based on theoretical studies, test results, and experience.

2. References

This guide shall be used in conjunction with the following publications. When the following standards are superseded by an approved revision, the revision shall apply.

ANSI C62.22-1987, American National Standard Guide for the Application of Gapped Silicon-Carbide Surge Arresters for AC Systems.¹

ANSI C84.1-1989, American National Standard for Electric Power Systems and Equipment—Voltage Ratings (60 Hertz).

IEC 34-15 (1995-01), Rotating Electrical Machines—Part 15: Impulse Voltage Withstand Levels of Rotating A.C. Machines with Form Wound Stator Coils (draft revision).²

IEEE Std 18-1992, IEEE Standard for Shunt Power Capacitors.

IEEE Std 100-1996, The IEEE Standard Dictionary of Electrical and Electronics Terms, Sixth Edition.³

IEEE Std 824-1994, IEEE Standard for Series Capacitors in Power Systems.

IEEE Std 998-1996, IEEE Guide for Direct Lightning Stroke Shielding of Substations.

IEEE Std 1036-1992, IEEE Guide for Application of Shunt Power Capacitors.

IEEE Std 1313.1-1996, IEEE Standard for Insulation Coordination—Definitions, Principles, and Rules.

IEEE Std C37.04-1979 (Reaff 1989), IEEE Standard Rating Structure for AC High-Voltage Circuit Breakers Rated on a Symmetrical Current Basis (DoD).

IEEE Std C37.015-1993, IEEE Application Guide for Shunt Reactor Switching.

IEEE Std C57.12.00-1993, IEEE Standard General Requirements for Liquid-Immersed Distribution, Power, and Regulating Transformers.

IEEE Std C57.12.01-1989, IEEE Standard General Requirements for Dry-Type Distribution and Power Transformers Including Those with Solid Cast and/or Resin-Encapsulated Windings.⁴

IEEE Std C57.13-1993, IEEE Standard Requirements for Instrument Transformers.

IEEE Std C57.21-1990 (Reaff 1995), IEEE Standard Requirements, Terminology, and Test Code for Shunt Reactors Rated Over 500 kVA.

IEEE Std C62.1-1989 (Reaff 1994), IEEE Standard for Gapped Silicon-Carbide Surge Arresters for AC Power Circuits.

¹ANSI publications are available from the Sales Department, American National Standards Institute, 11 West 42nd Street, 13th Floor, New York, NY 10036, USA.

²IEC publications are available from IEC Sales Department, Case Postale 131, 3, rue de Varembe, CH-1211, Genève 20, Switzerland/Suisse. IEC publications are also available in the United States from the Sales Department, American National Standards Institute, 11 West 42nd Street, 13th Floor, New York, NY 10036, USA.

³IEEE publications are available from the Institute of Electrical and Electronics Engineers, 445 Hoes Lane, P.O. Box 1331, Piscataway, NJ 08855-1331, USA.

⁴IEEE Std C57.12.01-1989 has been withdrawn; however, copies can be obtained from Global Engineering, 15 Inverness Way East, Englewood, CO 80112-5704, USA, tel. (303) 792-2181.

IEEE Std C62.11-1993, IEEE Standard for Metal-Oxide Surge Arresters for Alternating Current Power Circuits.

IEEE Std C62.92.1-1987 (Reaff 1993), IEEE Guide for the Application of Neutral Grounding in Electrical Utility Systems, Part I—Introduction.

IEEE Std C62.92.4-1991 (Reaff 1996), IEEE Guide for the Application of Neutral Grounding in Electric Utility Systems, Part IV—Distribution.

IEEE Std C62.92.5-1992 (Reaff 1997), IEEE Guide for the Application of Neutral Grounding in Electric Utility Systems, Part V—Transmission Systems and Subtransmission Systems.

NEMA MG 1-1993, Motors and Generators.⁵

3. Definitions and acronyms

3.1 Definitions

For the purposes of this guide, the following terms and definitions apply. IEEE Std 100-1996, The IEEE Standard Dictionary of Electrical and Electronics Terms, should be referenced for terms not defined in this clause.

3.1.1 arrester: *See:* surge arrester.

3.1.2 arrester discharge current: The current that flows through an arrester resulting from an impinging surge.

3.1.3 arrester discharge voltage: The voltage that appears across the terminals of an arrester during the passage of discharge current.

3.1.4 arrester duty cycle rating: The designated maximum permissible root-mean-square (rms) value of power-frequency voltage between its line and ground terminals at which it is designed to perform its duty cycle.

3.1.5 basic lightning impulse insulation level (BIL): The electrical strength of insulation expressed in terms of the crest value of a standard lightning impulse under standard atmospheric conditions. BIL may be expressed as either statistical or conventional.

3.1.6 basic switching impulse insulation level (BSL): The electrical strength of insulation expressed in terms of the crest value of a standard switching impulse. BSL may be expressed as either statistical or conventional.

3.1.7 coefficient of grounding (COG): The ratio, ELG/ELL (expressed as a percentage), of the highest root-mean-square (rms) line-to-ground power-frequency voltage ELG on a sound phase, at a selected location, during a fault to ground affecting one or more phases to the line-to-line power-frequency voltage ELL that would be obtained at the selected location with the fault removed.

⁵NEMA publications are available from the National Electrical Manufacturers Association, 1300 N. 17th St., Ste. 1847, Rosslyn, VA 22209, USA.

3.1.8 conventional BIL: The crest value of a standard lightning impulse for which the insulation shall not exhibit disruptive discharge when subjected to a specific number of applications of this impulse under specified conditions, applicable specifically to nonself-restoring insulations.

3.1.9 conventional BSL: The crest value of a standard switching impulse for which the insulation does not exhibit disruptive discharge when subjected to a specific number of impulses under specified conditions, applicable to nonself-restoring insulations.

3.1.10 conventional withstand voltage: The voltage that an insulation is capable of withstanding with a 0% probability of failure.

3.1.11 coordination of insulation: The selection of insulation strength consistent with expected overvoltages to obtain an acceptable risk of failure.

3.1.12 crest value: (of an impulse) The maximum value that an impulse attains. *Synonym:* **peak value.**

3.1.13 critical flashover voltage (CFO): The amplitude of voltage of a given waveshape that, under specified conditions, causes flashover through the surrounding medium on 50% of the voltage applications.

3.1.14 deadfront type arrester: An arrester assembled in a shielded housing providing system insulation and conductive ground shield, intended to be installed in an enclosure for the protection of underground and padmounted distribution equipment and circuits.

3.1.15 disruptive discharge: The sudden and large increase in current through an insulating medium due to the complete failure of the medium under electrical stress.

3.1.16 distribution arrester:

(A) **heavy duty class:** An arrester most often used to protect overhead distribution systems exposed to severe lightning currents.

(B) **light duty class:** An arrester generally installed on and used to protect underground distribution systems where the major portion of the lightning stroke current is discharged by an arrester located at the overhead line/cable junction.

(C) **normal duty class:** An arrester generally used to protect overhead distribution systems exposed to normal lightning currents.

3.1.17 ferroresonance: Can also occur between the capacitance to ground of an ungrounded circuit and voltage transformers with primary windings that are grounded. This phenomenon is also possible in gas-insulated systems.

3.1.18 flashover: A disruptive discharge around or over the surface of a solid or liquid insulator.

3.1.19 impulse: A surge of unidirectional polarity.

3.1.20 insulation level: A combination of voltage values (both power frequency and impulse) that characterize the insulation of an equipment with regard to its capability of withstanding dielectric stresses.

3.1.21 lightning overvoltage: The crest voltage appearing across an arrester or insulation caused by a lightning surge.

3.1.22 lightning surge: A transient electric disturbance in an electric circuit caused by lightning.

3.1.23 liquid-immersed type arrester: An arrester designed for use immersed in an insulating liquid.

3.1.39 surge: A transient wave of current, potential, or power in an electric circuit.

3.1.40 surge arrester: A protective device for limiting surge voltages on equipment by discharging or bypassing surge current; it limits the flow of power follow current to ground, and is capable of repeating these functions as specified.

3.1.41 switching overvoltage: Any combination of switching surge(s) and temporary overvoltage(s) associated with a single switching episode.

3.1.42 switching surge: A heavily damped transient electrical disturbance associated with switching. System insulation flashover may precede or follow the switching in some cases but not all.

3.1.43 system voltage: The root-mean-square (rms) phase-to-phase power frequency voltage on a three-phase alternating-current electric system.

3.1.44 temporary overvoltage: An oscillatory overvoltage, associated with switching or faults (for example, load rejection, single-phase faults) and/or nonlinearities (ferroresonance effects, harmonics), of relatively long duration, which is undamped or slightly damped.

3.1.45 traveling wave: The resulting wave when an electrical variation in a circuit such as a transmission line takes the form of translation of energy along a conductor, such energy being always equally divided between current and potential forms.

3.1.46 unit operation: Discharge of a surge through an arrester while the arrester is energized.

3.1.47 valve arrester: An arrester that includes one or more valve elements.

3.1.48 valve element: A resistor that, because of its nonlinear current-voltage characteristic, limits the voltage across the arrester terminals during the flow of discharge current and contributes to the limitation of follow current at normal power-frequency voltage.

3.1.49 virtual duration of wave front: (of an impulse) The virtual value for the duration of the wave front is as follows:

- a) For voltage waves with wave front durations less than 30 μs , either full or chopped on the front, crest, or tail, 1.67 times the time for the voltage to increase from 30% to 90% of its crest value.
- b) For voltage waves with wave front durations of 30 μs or more, the time taken by the voltage to increase from actual zero to maximum crest value.
- c) For current waves, 1.25 times the time for the current to increase from 10% to 90% of crest value.

3.1.50 virtual zero point: (of an impulse) The intersection with the time axis of a straight line drawn through points on the front of the current wave at 10% and 90% crest value or through points on the front of the voltage wave at 30% and 90% crest value.

3.1.51 wave front: (of an impulse) That part of an impulse that occurs prior to the crest value.

3.1.52 wave shape: (of an impulse test wave) The graph of an impulse test wave as a function of time.

3.1.53 wave shape designation: (of an impulse)

- a) The wave shape of an impulse (other than rectangular) of a current or voltage is designated by a combination of two numbers. The first, an index of the wave front, is the virtual duration of the wave front in microseconds. The second, an index of the wave tail, is the time in microseconds from virtual zero to the instant at which one-half of the crest value is reached on the wave tail. Examples are 1.2/50 and 8/20 waves.

- b) The wave shape of a rectangular impulse of current or voltage is designated by two numbers. The first designates the minimum value of current or voltage that is sustained for the time in microseconds designated by the second number. An example is the 75 A \times 2000 μ s wave.

3.1.54 wave tail: (of an impulse) That part between the crest value and the end of the impulse.

3.1.55 withstand voltage: The voltage that an insulation is capable of withstanding with a given probability of failure. In terms of insulation, this is expressed as either conventional withstand voltage or statistical withstand voltage.

4. General considerations

4.1 Overvoltages

Overvoltages in power systems may be generated by external events, such as lightning; by internal events, such as switching and faults; by internal conditions including faults, ferroresonance, load rejection, loss of ground, etc.; or by any combination of the above. The magnitude of these overvoltages can be above maximum permissible levels and therefore need to be reduced and protected against if damage to equipment and possible undesirable system performance are to be avoided.

4.1.1 Lightning currents and overvoltages

Lightning surge voltages that arrive at the line entrance of a station are caused either by:

- a) A lightning flash terminating on the overhead shield wire or structure with a subsequent flashover to the phase conductor (denoted as a backflash); or by
- b) A lightning flash terminating on the phase conductor (denoted as a shielding failure).

The lightning surge voltage magnitudes and wave shapes that enter a station are functions of the magnitude, polarity, and shape of the lightning stroke current, the tower and line surge impedance, the tower footing impedance, and the lightning impulse critical flashover voltage (CFO) of the line insulation.

The crest magnitude of the surge voltage arriving at the station caused by a backflash is generally considered to be 1 to 1.2 times the positive polarity CFO of the line. This represents a reasonable worst-case condition. The steepness of the incoming surge (rate of rise) is dependent on the distance between the station and the backflash location. The steepness decreases approximately as an inverse function of this distance, d , and ranges from about 700/ d kV/ μ s for a single phase conductor to about 1700/ d kV/ μ s for a 3- to 4-conductor bundle where d is in km. Steepnesses in the range of 500 to 2000 kV/ μ s are typically encountered. The tail of the incoming surge described is generally in the range of 10 to 20 μ s.

Lightning surge crest voltages caused by shielding failures generally do not exceed the negative polarity CFO of the line. The wave fronts and tails at the location of the shielding failure are equal to those of the lightning stroke current. Therefore, the steepness of the incoming surge at the station is less than those from a backflash while the tail is longer, an average time to half value of about 92 μ s.

For lines that are effectively shielded, for the same reliability criterion, the surge voltages caused by a backflash are usually more severe. That is, they have greater steepness and greater crest voltage, and therefore are the only ones generally considered for analysis of station protection.

4.1.2 Switching overvoltages

Switching overvoltages occur on all systems (AIEE Committee Report [B1]⁶, IEEE Committee Report [B61], and IEEE Committee Report [B62]) and usually result from a circuit-breaker operation or the occurrence of a fault. These overvoltages are an important consideration in systems above 115 kV and in all systems where the effective surge impedance as seen from the arrester location is low (e.g., cable and capacitor bank circuits).

The switching surge duty on metal-oxide arresters applied on overhead transmission lines increases for increased system voltage and increased length of switched line. Typically, transients occurring from high speed reclosing impose greater duty than energizing.

On extra high-voltage (EHV) systems, it is important that transients on the high-voltage network do not transfer excessive energy to arresters on the low side windings of step-down transformers. This situation arises when a line is switched at one end and the other end of the line is transformer terminated. The per-unit protective levels of the low-side arrester should be higher than the high-voltage winding arresters so they do not respond to high-side surges.

Because of the likelihood of unusually high discharge currents, the application of arresters to shunt capacitor banks or cables may require a special review, such as a detailed analytical system study. Arresters of higher energy capability or parallel arresters may be required (see 5.11).

4.1.3 Temporary overvoltages

Temporary overvoltages consist of lightly damped power frequency voltage oscillation, often with harmonics, usually lasting a period of hundreds of milliseconds or longer. Situations that may give rise to these overvoltages include single line-to-ground faults, ferroresonance, load rejection, loss of ground, long unloaded transmission lines (Ferranti rise), coupled-line resonance, and transformer-line inrush. The system configuration and operating practices should be reviewed to identify the most probable forms of temporary overvoltages that may occur at the arrester location. In addition, proper application of metal-oxide arresters requires that the duration of these overvoltages be known (see 4.2.3).

When detailed system studies or detailed calculations are unavailable, as a minimum the overvoltages due to line-to-ground faults should be addressed. Single line-to-ground faults are the most common type of system disturbance. The magnitudes of these overvoltages are related to system grounding and can be estimated by the “coefficient of grounding” (COG) as outlined in 5.3.2.1. Arresters on a well-grounded system are normally exposed to low-magnitude temporary overvoltages during single line-to-ground faults, whereas they are exposed to higher voltages when the system is either ungrounded or grounded through an impedance. This is also true of arresters installed on the neutral of reactance- or resistance-grounded transformers and for systems using resonant grounding and Peterson coils (Clarke [B25]).

4.2 Metal-oxide arresters

4.2.1 Design

Metal-oxide arresters fall into three broad design categories, namely: gapless arresters, shunt-gapped arresters, and series-gapped arresters. The general principles of these three design types are described in the following subsections.

⁶The numbers in brackets correspond to those of the bibliography in annex D.

4.2.1.1 Gapless arresters

Gapless arresters utilize a single stacked column or two or more parallel columns of metal-oxide valve elements, as schematically shown in Figure 1(a). A typical volt-ampere characteristic for such an arrester is illustrated in Figure 1(b). Above the knee of the volt-ampere curve, the metal-oxide elements exhibit a very nonlinear behavior that may be approximated by the relationship $I = kV^\alpha$. Alpha (α) values will normally vary from 10 to 50, depending on the metal-oxide formulation and current range being studied. Typically, higher current values and wider ranges will yield lower values of α . For example, α may be 50 over a current range of 1–600 A and may average 26 over the wider range of 1–10 000 A. The arrester discharge voltage for a given surge-current magnitude is directly proportional to the height of the valve element stack and is thus more or less proportional to the arrester rated voltage. Additionally, the arrester discharge voltage is a function of the rate of rise of the current surge, with higher voltages occurring for faster rates of rise and vice-versa. Typically, for the same current magnitude, the voltage occurring for a current cresting in 1 μ s is 8–12% higher than that occurring for a standard 8/20 μ s lightning current wave. The voltage occurring for a current cresting in 45–60 μ s is 2–4% lower than that for the 8/20 μ s wave.

The maximum continuous operating voltage (MCOV) of the arrester is typically in the range of 75% to 85% of the duty cycle voltage rating. At MCOV, the arrester current is usually not more than a few milliamperes, typically less than 10 mA. On the arrival of a surge, the increasing surge current is accompanied by a rise in arrester voltage to a maximum level determined by the volt-ampere characteristic. As the surge current decreases, the discharge voltage will decrease back toward the pre-surge level.




Figure 1—Gapless metal-oxide surge arrester

4.2.1.2 Shunt-gapped arresters

For surge currents above a certain magnitude, the discharge voltage of a column or columns of metal-oxide valve elements can be reduced by shunting a portion of the stack. This is the basic principle of a shunt-gapped arrester, schematically shown in Figure 2(a). A typical volt-ampere characteristic of such an arrester is illustrated in Figure 2(b). On arrival of a surge, the arrester voltage initially increases with increasing surge-current magnitude according to the volt-ampere characteristics A-B. When the surge current magnitude reaches 250–500 A (range B to C on volt-ampere characteristic), sparkover of a gap electrically connected in parallel with a few metal-oxide valve elements results in a shunting of the surge current around these valve elements, thereby proportionally lowering the discharge voltage (in the range D to E). For further increases in surge current, the voltage increases according to the characteristic E-F. As the surge current decreases, the arrester voltage decreases accordingly, following the characteristic F-G until the shunt gaps extinguish at a low level of current. Following the extinction of the arrester leakage current, the arrester operating point returns to A.

From an energy standpoint, the energy absorption capability is less after gap sparkover than before.

4.2.1.3 Series-gapped arresters

Another approach to obtain reduced protective levels is to use fewer valve elements in conjunction with series-connected spark gaps, as depicted in Figure 3(a). The series gaps are shunted by a linear component impedance network of such characteristic that the applied voltage is divided between the impedance network and the metal-oxide elements. A typical volt-ampere characteristic is illustrated in Figure 3(b). On the arrival of a surge, the arrester voltage begins to rise (A-B), the total voltage being the vector sum of the voltages across the metal-oxide elements and the series gap impedance network. At a level of current in the vicinity of 1 A (depending on rate of rise in the range B to C), the gaps sparkover and the arrester voltage is reduced to the discharge voltage of the metal-oxide elements only. For further increase in surge current, the voltage increases according to the characteristic D-E-F. As the surge current decreases, the arrester voltage decreases accordingly, following the characteristic F-G until the series gaps extinguish at a low level of current..




Figure 2—Shunt-gapped metal-oxide surge arrester




Figure 3—Series-gapped metal-oxide surge arrester

4.3.3 Front-of-wave protective level (FOW)

FOW protective level for metal-oxide arresters is the higher of

- a) The crest discharge voltage resulting from a current wave through the arrester of lightning impulse classifying current magnitude with a rate-of-rise high enough to produce arrester crest voltage in 0.5 μs ; or
- b) Gap sparkover for specified rates-of-rise of wave shapes in IEEE Std C62.11-1993.

4.3.4 Switching impulse protective level (SPL)

SPL is the higher of either:

- a) The discharge voltage measured with a current wave through the arrester of switching impulse classifying current magnitude and a time to actual current crest of 45–60 μs ; or
- b) Gap sparkover voltage on similar wave shapes.

The switching impulse classifying currents of Table 4 of IEEE Std C62.11-1993 for a two line substation were calculated by dividing the line charge voltage (E), minus the switching surge-protective level of the minimum arrester rating used at that voltage, by one-half of the surge impedance (Z_L) given in Table 5 of IEEE Std C62.11-1993. These currents are considered conservative for most arrester applications, but they may be exceeded in applications involving capacitor banks or cables or in other low-impedance circuits. Manufacturers should be consulted for information on protective levels for currents that exceed the switching impulse classifying current.

4.4 Insulation withstand

Insulation strength is expressed in terms of conventional or statistical BILs and BSLs. The withstand voltages of interest in arrester applications are taken from the list of preferred BIL and BSL values in IEEE Std 1313.1-1993.

The following withstand levels for equipment and bus insulation are of interest in arrester application:

- a) *Chopped Wave Withstand (CWW)*: Tests are made with a 1.2/50 μs impulse chopped by the action of a gap in a minimum time as specified in the appropriate product standard.
- b) *Basic Lightning Impulse Insulation Level (BIL)*: Tests are made with full-wave 1.2/50 μs impulses as specified in the appropriate equipment standard.
- c) *Basic Switching Impulse Insulation Level (BSL)*: The test impulse depends on the type of equipment.

Transmission and distribution line insulation strength is usually statistically described by a critical flashover voltage (CFO) at which the insulation exhibits a 50% probability of flashover and by a standard deviation σ which is approximately 5% of the CFO.

The insulation strength of apparatus within a station is expressed in terms of a BIL, a chopped-wave voltage, and for higher system voltages, a BSL. As noted from the definitions, the BIL and BSL may be either conventional or for statistical BILs and BSLs. The statistical BIL (or BSL) is equal to CFO – 1.28 σ .

4.5 Separation effects

The voltage at the protected insulation will usually be higher than at the arrester terminals due to oscillations on connecting leads (Witzke and Bliss [B133]). This rise in voltage is called a separation effect.

Separation effects increase with the increasing rate of rise of the incoming surge and with increasing distances between the arrester and protected equipment. For evaluation of separation effects due to lightning surges, refer to Annex C. Due to the relatively slow rates of rise of switching surges, separation effects need not be considered in applying the fundamental protective ratio formula to switching surge withstand (BSL).

Other considerations in locating arresters are discussed in 5.5.

4.6 Insulation coordination

Insulation coordination is defined in IEEE Std 1313.1-1996 and in this guide as “the selection of insulation strength consistent with expected overvoltages to obtain an acceptable risk of failure.”

Degree of coordination is measured by the protective ratio (PR). The fundamental definition of PR is

$$PR = \frac{\text{Insulation Withstand Level}}{\text{Voltage at Protected Equipment}}$$

“Voltage at protected equipment” includes separation effect, if significant. If not, it is equal to arrester protective level.

Three protective ratios are in common use, comparing protective levels with corresponding insulation withstands.

$$PR_{L1} = \frac{CWW}{FOW} \quad (\text{Acceptable ratio is 1.15})$$

$$PR_{L2} = \frac{BIL}{LPL} \quad (\text{Acceptable ratio is 1.15})$$

$$PR_S = \frac{BSL}{SPL} \quad (\text{Acceptable ratio is 1.2})$$

The protective margin (PM) in percent is defined as: $PM = (PR - 1)100$. PR and PM applications are covered in Clauses 5 and 6.

A graphical approach to insulation coordination is also discussed in 5.7.

5. Protection of transmission systems

5.1 Introduction

The general procedures given here are applicable where transformers and other equipment and station components have a chopped-wave voltage withstand level at least 1.10 times the BIL. For this withstand level, the procedures for the selection and location of arresters in relation to the insulation system to be protected can generally be reduced to a series of steps. These are summarized in 5.2 and elaborated upon in 5.3 through 5.8.

Arrester applications for transformer or other series windings, unloaded windings, and ungrounded neutrals are discussed in 5.9.

Where a lower chopped-wave insulation level is specified in equipment such as dry-type transformers, the protection procedures are covered in 5.10.

Basic to the application theory presented by this guide are the presumptions that

- a) Surge arrester ground terminals are connected to the grounded parts of the protected equipment.
- b) Both line and ground surge arrester connections are as short as practical.
- c) The station is shielded against direct strokes.

5.2 Step-by-step procedures

A summary of the steps required to select arresters is provided in Figure 4.

1. Select surge arrester
 - 1.1 $MCOV \geq$ Maximum Phase-to-Neutral Voltage (see 5.3.1)
 - 1.2 TOV Capability \geq System TOV (see 5.3.2)
 - 1.3 Switching Impulse Energy Capability \geq that produced by the system (see 5.3.3)
 - 1.4 Arrester Class:

| | |
|--|---------------|
| (1) Available ratings (2) Pressure relief (3) Durability | (see Table 1) |
|--|---------------|

2. Determine protective characteristics (see 5.4.1)
 - 2.1 Lightning Impulse Protective Level, LPL
 - 2.2 Front-of Wave Protection Level, FOW
 - 2.3 Switching Impulse Protective Level, SPL

3. Locate surge arrester (see 5.5)
As close as possible to equipment to be protected

4. Determine voltage at equipment terminals (see 5.5)
Arrester lead length and transformer-to-arrester separation distance effects can be determined per Annex C

5. Select Insulation Strength (see 5.6)
See equipment standards for BILs, BSLs and CWWs

6. Evaluate coordination (see 5.7)
 - 6.1 If effects of separation distance can be disregarded, the protective ratios for lightning, PR_{L1} and PR_{L2} , and switching impulses, PR_S , are:

$$PR_L = CWW/FOW$$

$$PR_{L2} = BIL/LPL$$

$$PR_S = BSL/SPL$$

For acceptable coordination, PR_{L1} and PR_{L2} should be equal to or greater than 1.2, and PR_S should be equal to or greater than 1.15.

- 6.2 If the voltage at the equipment terminals, V_T , is calculated per Annex C, the protective ratios are as follows:

If the time-to-crest of the arrester voltage is equal to or less than 2 μ s:

$$PR_{L1} = CWW/V_T$$

$$PM_{L1} = (PR_{L1} - 1) 100 (\%)$$

If CWW does not exist or the time-to-crest of the arrester voltage is greater than 2 μ s:

$$PR_{L2} = BIL/V_T$$

$$PM_{L2} = (PR_{L2} - 1) 100 (\%)$$

Also

$$PR_S = BSL/SPL$$

$$PM_S = (PR_S - 1) 100 (\%)$$

For acceptable coordination PR_{L1} or PR_{L2} and PR_S have to be equal to or greater than 1.15 (PM_{L1} or PM_{L2} and $PM_S \geq 15$).

7. Evaluate alternates (see 5.8)

If acceptable coordination cannot be achieved, evaluate the following measures:

 - (1) Increase BIL and BSL
 - (2) Decrease arrester separation distance
 - (3) Add additional arresters
 - (4) Use arrester with lower protective characteristics

Figure 4—Summary of procedures for arresters selection and insulation coordination

Table 1—Typical station and intermediate class arrester characteristics

| Station class | | | | | | | | | |
|--|--|------------------------------|---------------------------------|---|--|--|---|-----------------------------------|---|
| Steady state operation: system voltage and arrester ratings | | | | Protective levels: range of industry maxima per unit of MCOV | | | Durability characteristics: IEEE Std C62.11-1993 | | |
| Max system voltage L-L kV-rms ^a | Max system voltage L-G kV-rms ^a | Min MCOV rating kV-rms | Duty cycle ratings kV-rms | 0.5 μ s FOW protective level ^b | 8/20 μ s protective level ^b | Switching surge protective level ^c | High current withstand crest amperes | Trans. line discharge miles | Pressure relief kA rms (symmetrical) ^d |
| 4.37 | 2.52 | 2.55 | 3 | 2.32–2.48 | 2.10–2.20 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 8.73 | 5.04 | 5.1 | 6–9 | 2.33–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 13.1 | 7.56 | 7.65 | 9–12 | 2.33–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 13.9 | 8.00 | 8.4 | 10–15 | 2.33–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 14.5 | 8.37 | 8.4 | 10–15 | 2.33–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 26.2 | 15.1 | 15.3 | 18–27 | 2.33–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 36.2 | 20.9 | 22 | 27–36 | 2.43–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 48.3 | 27.8 | 29 | 36–48 | 2.43–2.48 | 1.97–2.23 | 1.70–1.85 | 65 000 | 150 | 40–80 |
| 72.5 | 41.8 | 42 | 54–72 | 2.19–2.40 | 1.97–2.18 | 1.64–1.84 | 65 000 | 150 | 40–80 |
| 121 | 69.8 | 70 | 90–120 | 2.19–2.40 | 1.97–2.18 | 1.64–1.84 | 65 000 | 150 | 40–80 |
| 145 | 83.7 | 84 | 108–144 | 2.19–2.39 | 1.97–2.17 | 1.64–1.84 | 65 000 | 150 | 40–80 |
| 169 | 97.5 | 98 | 120–172 | 2.19–2.39 | 1.97–2.17 | 1.64–1.84 | 65 000 | 175 | 40–80 |
| 242 | 139 | 140 | 172–240 | 2.19–2.36 | 1.97–2.15 | 1.64–1.84 | 65 000 | 175 | 40–80 |
| 362 | 209 | 209 | 258–312 | 2.19–2.36 | 1.97–2.15 | 1.71–1.85 | 65 000 | 200 | 40–80 |
| 550 | 317 | 318 | 396–564 | 2.01–2.47 | 2.01–2.25 | 1.71–1.85 | 65 000 | 200 | 40–80 |
| 800 | 461 | 462 | 576–612 | 2.01–2.47 | 2.01–2.25 | 1.71–1.85 | 65 000 | 200 | 40–80 |
| Intermediate class | | | | | | | | | |
| 4.37–145 | 2.52–83.72 | 2.8–84 | 3–144 | 2.38–2.85 | 2.28–2.55 | 1.71–1.85 | 65 000 | 100 | 16.1 ^d |

^aVoltage range A, ANSI C84.1-1989

^bEquivalent front-of-wave protective level producing a voltage wave cresting in 0.5 μ s. Protective level is maximum discharge voltage (DV) for 10 kA impulse current wave on arrester duty cycle rating through 312 kV, 15 kA for duty cycle ratings 396–564 kV and 20 kA for duty cycle ratings 576–612 kV, per IEEE Std C62.11-1993.

^cSwitching surge characteristics based on maximum switching surge classifying current (based on an impulse current wave with a time to actual crest of 45 μ s to 60 μ s) of 500 A on arrester duty cycle ratings 3–108 kV, 1000 A on duty cycle ratings 120–240 kV, and 2000 A on duty cycle ratings above 240 kV, per IEEE Std C62.11-1993.

^dTest values for arresters with porcelain tops have not been standardized. Pressure relief classification is in 5 kA steps.

The following sequence is used:

- a) Select an arrester and determine its protective characteristics.
- b) Select (or determine) the insulation withstand.
- c) Evaluate the insulation coordination.

Other sequences may be equally acceptable. The key step is insulation coordination evaluation. Withstand voltages may be selected to match the characteristics of certain arresters, or arresters may be matched to available insulation. Typical characteristics of station class and intermediate class arresters are given in Table 1. Distribution class arresters are sometimes used in stations, and typical characteristics of such arresters may be found in Table 6. Protective levels are given in per-unit values of crest arrester MCOV rating. Per-unit values may be converted to kilovolts and used in preliminary selection of arresters. Values in the numbered columns under "Durability Characteristics" are specified requirements for the range of ratings as prescribed in IEEE Std C62.11-1993.

5.3 Arrester selection

For a given application, the selection of an appropriate arrester (Figure 4, Item 1) involves considerations of maximum continuous operating voltage; protective characteristics (lightning and switching impulse); durability (temporary overvoltage and switching surge); service conditions; and pressure relief requirements. Durability and protective level considerations will primarily determine the class of arrester selected: station, intermediate or, occasionally, distribution.

Station arresters are designed for heavy-duty applications. They have the widest range of ratings (see Table 1), the lowest protective characteristics, and the most durability. Intermediate arresters are designed for moderate duty and for maximum system voltages of 169 kV and below. Distribution arresters (see Tables 5 and 6 of Clause 6) are used to protect lower voltage transformers and lines where the system-imposed duty is minimal and there is a need for an economical design.

5.3.1 Maximum continuous operating voltage (MCOV)

For each arrester location, arrester MCOV must equal or exceed the expected MCOV of the system. Proper application requires that the system configuration (single-phase, delta, or wye) and the arrester connection (phase-to-ground, phase-to-phase, or phase-to-neutral) be evaluated. For example, in EHV systems the arrester is typically connected phase-to-ground, and therefore, is exposed to system phase-to-ground voltages on a steady-state basis. On the other hand, an arrester connected to a tertiary winding with one corner grounded, or to a delta-connected system with a fault on one phase, is exposed to phase-to-phase voltage.

5.3.2 Temporary overvoltage capability (TOV)

In addition to considerations affecting the selection of arrester MCOV, the user must also select the arrester to withstand the temporary overvoltages in the system at the arrester location. The basic requirement is that the power frequency voltage versus time characteristic of the arrester should be higher than the temporary overvoltage (TOV) amplitude versus duration characteristic of the system for all times of concern.

Figure 5 is a typical generic TOV curve for Station and Intermediate Class Arresters. The upper curve shows the time the arrester withstands given overvoltages and subsequently thermally recovers when MCOV is applied. The lower curve is similar to upper, but applies to a condition where the arrester has absorbed prior energy from two transmission line discharges. For Station and Intermediate Class arresters, the test procedure is described in IEEE Std C62.11-1993 and each manufacturer may publish different test results. Figure 5 is shown for illustrative purposes only. For applications, TOV data should be obtained from the manufacturers.




Figure 5—Example of typical arrester TOV data (do not use for application)

The selected arrester must have both MCOV and temporary overvoltage capability appropriate for the operating system. Sometimes the MCOV is decisive and sometimes TOV considerations are decisive.

A change in relay setting, or use of faster breakers may sometimes allow use of arresters based on MCOV when TOV would otherwise have been decisive.

5.3.2.1 Fault conditions

5.3.2.1.1 Overvoltage amplitude considerations

The most common source of TOV is voltage rise on unfaulted phases during a line-to-ground fault. The curves of Annex B may be used to quickly determine temporary overvoltages during fault conditions for applications involving short lines operating at voltages through 242 kV.

The numbers adjacent to each of the curves of Annex B are the coefficients of grounding in percent. From known values of R_0/X_1 and X_0/X_1 , determine the corresponding coefficient of grounding, interpolating between curves as necessary. Multiply the coefficient of grounding by maximum system phase-to-phase operating voltage to determine the temporary overvoltage to ground at the point of fault. Alternatively, the voltage can be calculated from the equations in Figure 6 using equivalent system impedances as seen from the fault location. The effect of shunt reactors, shunt and series capacitors, and distributed line capacitances have to be included in the calculations where significant. This applies particularly to applications involving long lines and EHV lines (AIEE Committee Report [B1]). Where the shunt capacitance of lines is large, there may be significant additional voltage rise due to line-charging currents, harmonics due to transformer saturation, and (less frequently) resonance effects.

NOTE—Annex A of IEEE Std C62.92.1-1987 contains additional information for determining coefficients of grounding, more thoroughly addressing this subject.

| | |
|--|---|
| <p>The following equations can be used to calculate the COG. The equations are applicable for $Z_1 = Z_2$, but do not include fault resistance.</p> <p>Single-line-to-ground (SLG) fault at phase a:</p> $\text{COG (phase b)} = -\frac{1}{2} \left[\frac{\sqrt{3}k}{2+k} + j1 \right]$ $\text{COG (phase c)} = -\frac{1}{2} \left[\frac{\sqrt{3}k}{2+k} + j1 \right]$ <p>Double line-to-ground (DLG) fault on phases b and c:</p> $\text{COG (phase a)} = \frac{\sqrt{3}k}{1+2k}$ <p>where</p> $k = \frac{Z_0}{Z_1} = \frac{R_0 + jX_0}{R_1 + jX_1}$ | <p>In general, fault resistance tends to reduce COG, except in low-resistance (R_f) the definitions of k above would have to be modified as follows:</p> <p>For SLG fault:</p> $k = \frac{R_0 + R_f + jX_0}{R_1 + R_f + jX_0}$ <p>For DLG fault:</p> $k = \frac{R_0 + 2R_f + jX_0}{R_1 + 2R_f + jX_1}$ <p>where</p> $R_f = \text{Fault resistance}$ |
|--|---|

Figure 6—COG calculations

5.3.2.1.2 Overvoltage duration considerations

The duration of overvoltages from line-to-ground faults depends on the adopted short-circuit relaying protection. In the absence of other information the following typical values may be used:

| | |
|--|--------------|
| Grounded neutral systems: | TOV duration |
| Line protection | 0.2 s |
| Back-up protection | 1 s |
| Resonant grounded or isolated neutral systems: | |
| Without ground fault clearing | 3 h |
| With ground fault clearing | 4 s |

5.3.2.2 Load rejection

After disconnection of loads, the voltage rises at the source side of the operating circuit breaker. The amplitude of the overvoltage depends on the disconnected load and on the short circuit power of the feeding substation. The temporary overvoltages can have particularly high amplitudes after full load rejection at generator transformers due to magnetizing and overspeed conditions. The amplitudes of load rejection overvoltages are usually not constant during their durations. Accurate calculations have to consider many parameters.

As a guidance the following typical values of such overvoltages may be used:

- In moderately extended systems, a full load rejection can give rise to phase-to-ground overvoltages with amplitude usually below 1.2 p.u. The overvoltage duration depends on the operation of voltage-control equipment and may be up to several minutes.

- In extended systems, after a full load rejection, the phase-to-ground overvoltages may reach 1.5 p.u. or even more when Ferranti or resonance effects occur. Their durations may be in the order of some seconds.
- Where load is rejected from the load side of a generator step-up transformer, the temporary overvoltages may reach amplitudes up to 1.4 p.u. for turbo generators and up to 1.5 p.u. for hydro generators. The duration is approximately 3 s.
- When the time dependence of the amplitudes is known, a suitable representation of the overvoltage is the maximum amplitude with a duration equal to the time that the amplitudes exceed 90% of this value.

Other causes of temporary overvoltages need consideration. In some cases the following:

- a) Resonance effects, e.g., when charging long unloaded lines or when resonances exist between systems. Temporary overvoltages due to ferroresonance should be considered and are addressed in 6.4.4. Temporary overvoltages due to ferroresonance should not form the basis for the surge arrester selection and should be eliminated.
- b) Voltage rise along long lines (Ferranti effect).
- c) Harmonic overvoltages, e.g., when switching transformers.
- d) Accidental contact with conductors of higher system voltage.
- e) Backfeed through interconnected transformer windings, e.g., dual transformer station with common secondary bus during fault clearing or single-phase switched three-phase transformer with an unbalanced secondary load.
- f) Loss of system grounding.

Sequences of causes of temporary overvoltages, e.g., load rejection caused by a ground fault, need consideration when the overvoltages due to the load rejection are due to the ground fault with comparable severity. In such cases, however, the amount of rejected load dependent on the fault location and the arrester location has to be carefully examined.

Combination of causes such as ground faults caused by load rejection may result in higher temporary overvoltage values than the single events. When such combinations are considered sufficiently probable, the overvoltage factors for each cause have to be multiplied, taking into account the actual system configuration.

5.3.3 Switching surge durability

Surge arresters dissipate switching surges by absorbing thermal energy. The amount of energy is related to the prospective switching surge magnitude, its waveshape, the system impedance, circuit topology, the arrester voltage-current characteristics, and the number of operations (single/multiple events). The selected arrester should have an energy capability greater than the energy associated with the expected switching surges on the system.

The actual amount of energy discharged by a metal-oxide arrester during a switching surge can be determined through detailed system studies performed with a Transient Network Analyzer (TNA) and/or a digital circuit analysis program such as the Electromagnetic Transients Program (EMTP). When such study results are not available, the approximate arrester duty due to energizing and reclosing operations on transmission lines can be estimated from the following equation and curves.

The energy discharged by an arrester, J , in kilojoules, may be conservatively estimated by the equation:

$$J = D_L E_A I_A / v \quad (1)$$

where

- E_A is arrester switching impulse discharge voltage (in kilovolts) for I_A ,
 I_A is switching impulse current (in kiloamperes),
 D_L is line length (in miles or kilometers), and
 v is the speed of light (300 km/ms) or 186 000 mi/s.

The equation assumes that the entire line is charged to a prospective switching surge voltage (which exists at the arrester location) and is discharged through the arrester during twice the travel time of the line. The discharge voltage and current are related by the equation


$$I_A = (E_S - E_A) / Z \quad (2)$$

where

- E_S is prospective switching surge voltage (in kilovolts) and
 Z is single-phase surge impedance of line (in ohms).

To determine the prospective discharge energy, manufacturer data should be consulted to first determine consistent values of E_A and I_A per equations (1) and (2).

The calculated energy can then be plotted in curve form for varying quantities of line length, switching impulse voltage, and surge impedance. A typical curve is shown in Figure 7 for a 209 kV MCOV rated arrester (258 kV duty cycle rating) on a 345 kV, 100 mi transmission line that dissipates approximately 0.33 MJ of energy during a 2.5 p.u. switching surge. Since arresters are constructed with series repeated sections, the energy can be presented in per-unit of MCOV or duty cycle rating. In this case, 0.33 MJ translates to 1.58 kJ/kV of MCOV or 1.28 kJ/kV of duty cycle rating. The energy capability of station class arresters is within the range of 4.0 kJ/kV to 20.0 kJ/kV of MCOV and is a function of the volume, formulation, and processing of the metal-oxide disk. The number of discharges allowed in a short period of time (approximately 1 min or less) is the arrester energy capability divided by the energy per discharge. A curve is also shown for a 276 kV duty cycle rated arrester. Additional information is contained in the application guides of the manufacturer.



NOTE—In Figure 7, V_s is prospective voltage in per unit of peak line-to-ground system voltage.

Figure 7—Typical curve for a prospective switching surge voltage versus arrester discharge energy for a 345 kV line

5.3.4 Tentative selection of arrester voltage rating

The arrester voltage rating should be tentatively selected on the basis of MCOV (5.3.1), TOV (5.3.2), and switching surge durability (5.3.3).

Special conditions that should be considered in choosing the arrester voltage rating are as follows:

- a) *Abnormal system operating voltages.* The selection of arrester voltage ratings based on maximum system voltages assumes that, in service, the maximum system voltage is exceeded only under abnormal operating conditions, and only for durations within the arrester TOV capability. However, if maximum system voltages used in determining temporary overvoltages, as in 5.3.2.1 are likely to be exceeded frequently, increasing the probability of arrester operations during such conditions, it may be necessary to use an arrester with a higher voltage rating. Other causes of TOV as listed in 5.3.2.2 require consideration on an individual basis; no general rules are applicable. If any grounding source could be disconnected by sectionalizing, the effect on the COG and the arrester rating should be checked.
- b) *Abnormal system frequency.* Normal system frequency of less than 48 Hz or more than 62 Hz may require special consideration in the design or application of surge arresters and should be a subject of discussion between the user and the manufacturer.

5.3.5 Selection of arrester class

The arrester class should be selected on the basis of required level of protection (protective levels summarized in Table 1) and the following:

- a) Available voltage ratings
- b) Pressure relief current limits, which should not be exceeded by the system's available short-circuit current and duration at the arrester location
- c) Durability characteristics (see Table 1) that are adequate for systems requirements

The class of arrester selected may be influenced by the importance of the station or equipment to be protected. For example, station-class arresters should be used in large substations. Intermediate-class arresters may be used in smaller substations, and on subtransmission lines and cable terminal poles at 161 kV and below. Distribution-class arresters might be used in small distribution substations to protect distribution voltage buses.

5.4 Protective levels of arrester (Figure 4, Item 2)

5.4.1 Determination of protective levels

Protective levels are determined by either sparkover voltages or discharge voltages of the arrester under consideration, based on the measurement procedure outlined in Subclauses 8.3 and 8.4 of IEEE Std C62.11-1993. The following protective levels should be considered:

- a) *FWO:* The higher value of FWO sparkover or arrester discharge voltage cresting in 0.5 μ s at the classifying current.
- b) *LPL:* The higher value of lightning impulse sparkover for a 1.2/50 lightning impulse or arrester discharge voltage that results from an 8/20 current wave. The appropriate current magnitude is determined by the system voltage per Table 2.
- c) *SPL:* The higher value of switching impulse sparkover or arrester discharge voltage that results from a current wave with a time to actual crest of 45 μ s to 60 μ s. The appropriate current magnitude is based on the system voltage as contained in 5.4.3.

Table 2—Recommended currents for determining discharge voltage in shielded stations with shielded incoming lines

| Maximum system voltage (kV) | Coordinating current (kA) |
|-----------------------------|---------------------------|
| 72.5 | 5 |
| 121 | 10 |
| 145 | 10 |
| 242 | 10 |
| 362 | 10 |
| 550 | 15 |
| 800 | 20 |

5.4.2 Arrester coordinating currents for lightning surges

5.4.2.1 Factors that affect the selection of discharge currents for determining discharge voltage

In order to determine the protective levels of the arrester for lightning surges, proper coordinating currents need to be determined. Factors that affect this selection include the following:

- The importance and degree of protection desired. Basing protective levels on higher current magnitudes and rates-of-rise increases the reliability of protection.
- The line insulation. The potential for higher lightning currents increases with higher line insulations (e.g., fully insulated wood poles), unless the stroke occurs so close to the arrester that the impedance and insulation of the line cannot influence the surge.
- The probability of occurrence of the higher stroke currents. The magnitude of lightning currents vary over a wide range of values (Orville, Henderson, and Pyle [B105]). Lines in areas of high keraunic levels have an increased chance of being struck by lightning with high-current magnitudes (see Annex A).
- Line performance and lightning environment. Coordinating currents and rates-of-rise are functions of the backflash and shielding failure rates of the lines (or flashover rates of unshielded lines) that are within some limiting distance from the station. Higher (lower) failure rates increase (decrease) the coordinating current magnitude and rate-of-rise.

5.4.2.2 Recommended arrester coordinating currents for lightning surges

The appropriate coordinating current for lightning surges depends strongly on the effectiveness of line shielding.

5.4.2.2.1 Recommended currents for shielded stations with completely shielded lines

The lightning performance of shielded lines is based on the shielding failure and back-flashover rates of the lines. If the position of the ground wire(s) relative to the phase conductors is such that the line is considered “effectively shielded” (i.e., protected from direct lightning strokes), then the number of line insulation flashovers due to shielding failures will be negligible, and back-flashovers will be the predominant mechanism of

line insulation flashover. In either event, the magnitude of the arrester discharge current can be estimated from:

$$I = I_c = 3.84(E_{CFO} - E_C)/Z_0 \quad (3)$$

where

- I is arrester discharge current (in kiloamperes),
- I_C is arrester coordinating current (in kiloamperes),
- E_{CFO} is positive CFO of line insulation (in kilovolts),
- E_C is arrester discharge voltage (in kilovolts) for the estimated value of the coordinating current (see Table 2),
- Z_0 is single-phase surge impedance of line (in ohms), and
- 3.84 is the correction factor based on system studies. The increase in current is due to transformer capacitance.

This relationship assumes the line flashover occurs at a considerable distance from the station or that the phase conductor is struck without ensuing flashover. Otherwise, the portion of the total stroke current discharged through the arrester can vary considerably depending upon the parameters involved.

Using typical system parameters and the above equation, Table 2 contains coordinating currents that have been found to be satisfactory in most situations.

5.4.2.2.2 Discharge currents where lines are shielded for a short distance adjacent to the station

Where shielding does not include the entire line, increased arrester discharge currents become more probable. In assessing the probability of an arrester discharge current, it is necessary to consider the following:

- a) The ground flash density
- b) The probability of strokes to the line exceeding a selected value
- c) The percentage of total stroke current that discharges through the arrester

Items (a) and (b) can be evaluated using the methods of Brown and Thunander [B18] or from the ground flash density maps published by EPRI (Orville, Henderson, and Pyle [B105]). Conservative guidelines for (c) are contained in the following table (from Schei and Huse [B117]).

Table 3—Guidelines for total stroke discharge current

| Distance line shielding extends from station | Percentage of stroke current discharged through arrester |
|--|--|
| 1.5 mi (2.4 km) | 25 |
| 1.0 mi (1.6 km) | 35 |
| 0.5 mi (0.8 km) | 50 |

5.4.2.2.3 Discharge currents in stations where lines are not shielded

Completely unshielded lines usually are limited to either

- a) Lower voltage lines, (i.e., 34.5 kV and below); and/or
- b) Lines located in areas of low lightning ground flash density.

The probability may be high that arresters in the lower voltage stations are subjected to large currents and rates-of-rise in areas of high lightning ground flash density. In these cases, the coordinating current should not be less than 20 000 A. In severe thunderstorm areas, higher levels should be considered.

For lines located in areas of low lightning ground flash density, coordinating currents may be similar to those for completely shielded lines in areas of high lightning ground flash density. In this case, no specific guidelines can be given, and special studies are required.

5.4.3 Arrester coordinating currents for switching surges

The current an arrester conducts during a switching surge is a complex function of both the arrester and the details of the system. The effective impedance seen by the arrester during a switching surge can vary from several hundred ohms for an overhead transmission line to tens of ohms for arresters connected near cables and large capacitor banks. In these two cases, the arrester current and the resulting arrester energy vary significantly for a switching surge of a given magnitude and duration.

In the case of arresters connected to overhead transmission lines, the recommended switching surge coordinating currents (per IEEE Std C62.11-1993) are listed in the following table:

Table 4—Recommended switching surge coordinating currents

| Maximum system voltage (kV) | Station class (A crest) | Intermediate class (A crest) |
|-----------------------------|-------------------------|------------------------------|
| 3–150 | 500 | 500 |
| 151–325 | 1000 | — |
| 326–900 | 2000 | — |

5.4.4 Surge transfer through transformers

When a transformer and connected transmission line are switched together, the low side arrester may operate, causing it to discharge the energy transferred through the transformer from the higher-voltage line. There is a possibility of overstressing an arrester on the low side of a transformer due to this surge transfer. Measures must be taken to ensure that the high-side arrester operates to absorb the majority of the surge energy. This can be accomplished by coordinating the switching surge discharge voltages of the high- and low-side arresters.

The probability of failure of the low-side arrester can be reduced by selecting a low-side arrester with a higher relative switching surge protective level (SPL) than the arrester on the high side, taking the transformer turns ratio into consideration. For example:

$$SPL_{LV} > N(SPL_{HV})$$

where

- SPL_{LV} is switching surge protective level of the low-side arrester,
 SPL_{HV} is switching surge protective level of the high-side arrester, and
 N is transformer turns ratio.

5.5 Locating arresters and determining voltage at protected equipment (Figure 4, Item 3)

A major factor in locating arresters within a station is the line and station shielding. It is usually feasible to provide shielding for the substation even if the associated lines are unshielded. Station shielding reduces the probability of high voltages and steep fronts within the station resulting from high-current lightning strokes. However, it should be recognized that the majority of strokes will be to the lines, creating surges that travel along the line and into the station. If the lines are shielded, the surges entering the station are less severe than those from unshielded lines (Bewley [B14]). Consequently, the magnitude of the prospective arrester currents are lower, resulting in lower arrester protective levels.

As a general rule, the voltage at the protected equipment is higher than the arrester discharge voltage (see 4.5 and Annex C). Therefore, it is always good practice to reduce separation between the arrester and major equipment to a minimum. However, it is sometimes possible to protect more than one piece of equipment with a single arrester installation provided that rates-of-rise can be restricted, as in the case where both the station and overhead feeder lines are shielded.

5.5.1 Locating arresters in unshielded installations

Such installations are subjected to the highest lightning currents and voltage rates-of-rise. The minimum possible separation is recommended for installations where complete shielding is not used.

With a single unshielded incoming overhead line, the arrester should be located as near as possible to the terminals of the equipment (usually a transformer) to be protected.

When several unshielded incoming overhead lines meet in the station, the incoming overvoltage waves are reduced by refraction. However, consideration should be given to the case when one or more of the lines are out of service.

When one or more circuit breakers or disconnecting switches are open in such a station, the corresponding line entrances or certain parts of the station may be left without protection from the arresters at the transformers. Lightning flashover of insulation on a de-energized line is unlikely to cause damage, but other insulation in equipment such as circuit breakers, potential transformers, and current transformers connected on the line side might be damaged. If protection is required in such cases, arresters can be installed at the respective line entrances.

5.5.2 Locating arresters in shielded installations

Incoming voltages from shielded lines are lower in amplitude and steepness than voltages from unshielded lines. In many cases, this will permit some separation between the arresters and the insulation to be protected.

With a single shielded incoming overhead line, one set of arresters may be located at a point that provides protection to all equipment but gives preference to the transformer. The method in Annex C can be used to determine the maximum separation distance between the arrester and the transformer.

At stations with multiple shielded incoming overhead lines (associated with large installations with transformers, switchgear, and measuring equipment), arresters are not always placed at the terminals of every transformer. The methods described in 5.7.1 and Annex C can be used to determine maximum separation distances for arresters used to protect more than one transformer. More important installations may justify a detailed transient study. Such studies and interpretation of their results are outside the scope of this guide.

Consideration has to be given in the calculations to the possibility that the station may become sectionalized, or that lines may be disconnected during service. Under all circumstances, the proper protective ratios for both lightning and switching surges should be maintained.

5.5.3 Cable-connected equipment

Cable-connected equipment involves a station, substation, or individual apparatus connected to cable, which in turn is connected to an overhead line. The overhead line may or may not be shielded at the line-cable junction. In the case of unshielded overhead lines, it may be advantageous to mount additional protective devices a few spans before this junction.

5.5.3.1 Arresters at protected cable-connected equipment

If arresters can be installed at the equipment, a procedure analogous to that outlined in 5.5.2 should be followed. However, the methods of 5.7.1 and Annex C are not applicable (Owen [B106], Owen and Clinkenbeard [B107], Witzke and Bliss [B133]).

The grounded end of any arrester installed at the protected equipment should be connected to the equipment ground and the station ground with the shortest possible lead.

5.5.3.2 Arresters at the overhead line-cable junction

It is preferable to install arresters at the overhead line-cable junction for protection of junction equipment. If it is impossible or undesirable to install arresters at the protected equipment terminals, it is then necessary to determine whether adequate protection can be obtained with an arrester at the junction. The following procedure may be used:

- a) Determine the length of the cable connection.
- b) Determine the maximum impulse voltage at the protected equipment, using procedures and recommendations from either Powell [B110] or Witzke and Bliss [B133].

Arresters installed at the line-cable junction should be grounded to the station ground through a low-impedance path, which may be the cable shield, if suitable. If the cable shield is not suitable, or for cables without a metallic shield, the grounded end of the arrester should be connected to the station ground with a conductor in proximity to the cable. Special consideration may be necessary for cables with shields that cannot be grounded at both ends because of shield currents.

5.5.4 Phase-to-phase transformer protection

Arresters are typically installed phase-to-ground and as such may not provide adequate phase-to-phase protection for delta connected transformer windings. Solutions are to increase phase-to-phase insulation strength (BIL) or apply phase-to-phase arresters.

5.5.4.1 Sources of phase-to-phase overvoltages

Phase-to-phase overvoltages exceeding transformer insulation withstand can result from switching surges and lightning surges, explained as follows:

- a) *Switching surges:* High phase-to-phase switching overvoltages may occur due to capacitor bank switching or misoperation of capacitor bank switching devices (Jones and Fortson [B76], Lishchyna and Brierley [B88], and O'Leary and Harner [B103]).
- b) *Lightning surges:* High phase-to-phase lightning overvoltages may result from lightning striking a phase conductor of a transmission line. Lightning initiates current and voltage waves which propagate along the struck phase conductor and also induce voltage on the other phase conductors. At the struck location, the induced voltages have the same polarity as the struck phase voltage. Thus, this phase-to-phase voltage is the difference of the struck and the induced phase voltages. However, due to the propagation phenomenon, it is possible for the voltage wave forms to become of opposite polarity and the maximum phase-to-phase overvoltage could be as high as the sum of the absolute values of the peak (line mode) voltages on the struck and the induced phases. For these cases, the phase-to-phase overvoltage can exceed a delta connected transformer insulation withstand level (Keri, Musa, and Halladay [B77]).
- c) *Surge transfer through transformer windings:* Lightning surges entering a transformer terminal can excite the natural frequencies of delta connected windings resulting in phase-to-phase overvoltages in excess of the transformer insulation withstand (Keri, Musa, and Halladay [B77]).

5.5.4.2 Surge protection

Since surge arresters are typically installed phase-to-ground at each terminal of the delta connected transformer windings, each winding is protected by two arresters connected in series through their ground connection. The protective level of the two series-connected arresters may not provide the minimum recommended protective ratios for the transformer insulation. Delta-connected transformer windings can be protected by directly installing phase-to-phase and phase-to-ground surge arresters. This can be accomplished by either of the arrangements shown in Figure 8 (Keri, Musa, and Halladay [B77]).




Figure 8—Phase-to-phase protection

Figure 8(a) represents a six-surge arrester arrangement, consisting of three phase-to-phase and three phase-to-ground arresters for three-phase bank. Figure 8(b) represents a four-legged surge arrester arrangement, consisting of three surge arresters connected from three phases to common neutral, and one arrester connected from the common neutral-to-ground.

5.5.4.3 Guidelines for phase-to-phase surge arrester protection at delta connected transformers

Application of phase-to-phase surge arresters using either the six-surge arrester or the four-legged surge arrester arrangement should be considered under the following conditions:

- a) Protective level of two arresters connected in series through their ground connection does not provide the minimum recommended protective ratio for the transformer CWW, BIL, and BSL (Figure 4, Item 6); and

- b) The transformer is subjected to phase-to-phase overvoltages due to switching of a remote capacitor bank, without switching surge control means (such as preinsertion inductor, resistor, or controlled closing), or
- c) The number of transmission lines connected to the transformer bus is less than or equal to three transmission lines and the length of each line is equal to or more than 6 mi.

5.5.4.4 Selection of surge arrester ratings

The following describes the process recommended for selecting the surge arrester duty cycle/MCOV ratings and TOV capabilities depending on whether a four or six-arrester arrangement is selected (Keri, Musa, and Halladay [B77]):

- a) Six-surge arrester arrangement:
 - 1) The traditional selection process should be used to select the phase-to-ground surge arresters (Figure 4).
 - 2) The phase-to-phase surge arrester MCOV rating should be equal to or slightly greater than the maximum phase-to-phase system voltage.
- b) Four-legged surge arrester arrangement:
 - 1) Phase-to-neutral arrester MCOV should be equal to or slightly greater than the maximum phase-to-phase system voltage divided by square root of three. The arrester MCOV rating determined is often the same as that used on the solidly grounded transformer. In addition, the phase-to-neutral arresters must be matched to avoid overstressing the neutral-to-ground surge arrester. Proper insulation coordination must be established between the series combination of two phase-to-neutral arresters, and the transformer phase-to-phase insulation.
 - 2) Neutral-to-ground arrester MCOV rating: The design of the neutral-to-ground arrester should be the same as that used for the phase-to-neutral arrester.
 - i) Determine minimum required phase-to-ground MCOV based on the traditional phase-to-ground requirements (Figure 4).
 - ii) Subtract phase-to-neutral arrester MCOV obtained in (b1) from minimum required phase-to-ground MCOV obtained in (b2i). Select a surge arrester MCOV rating equal to or slightly greater than this value.
 - iii) If the phase-to-neutral arrester MCOV rating was increased to utilize ANSI/IEEE Standard MCOV ratings, then the neutral-to-ground arrester MCOV may be reduced, provided the conditions of (b2ii) are met. This iteration will permit the lowest ANSI/IEEE MCOV ratings to be used. Proper insulation coordination should be established between the series combination of the phase-to-neutral and neutral-to-ground arrester, and the transformer phase-to-ground insulation.

5.6 Determining insulation strength (Figure 4, Item 5)

BIL, BSL, and CWW voltages may be obtained from equipment standards. However, BSLs and CWWs do not exist for all equipment voltage ratings. Refer to IEEE Std C57.12.00-1993, IEEE Std C57.13-1993, IEEE Std C57.21-1990, and IEEE Std C37.04-1979.

The BSL for various types of equipment is presented in Table 5. The optional front-of-wave test for some transformers and reactors is also listed but is not used in this guide for purposes of insulation coordination.

The negative polarity lightning impulse CFO voltage of air insulation is approximately 600 kV/m (180 kV/ft) and for positive polarity CFO, the values are 560 kV/m (170 kV/ft). Bus and line support insulators have voltage characteristics that increase substantially at short times to flashover. At 3 μ s the breakdown voltage is approximately 1.3 to 1.4 times the CFO.

Table 5—Factors for estimating the withstand voltages of mineral-oil-immersed equipment

| Type of equipment | Impulse duration | Withstand voltage |
|---|---|---------------------------|
| Transformers and reactors | Front of wave (0.5 μ s) | 1.30 to 1.50 \times BIL |
| Breakers 15.5 kV and above ^a | Chopped wave (2 μ s) ^b | 1.29 \times BIL |
| Transformers and reactors ^a | Chopped wave (3 μ s) ^b | 1.10 to 1.15 \times BIL |
| Breakers 15.5 kV and above | Chopped wave (3 μ s) ^b | 1.15 \times BIL |
| Transformer and reactor windings | Full wave (1.2/50 μ s) | 1.00 \times BIL |
| Transformer and reactor windings | Switching surge—250/2500 μ s wave | 0.83 \times BIL |
| Bushings | Switching surge—250/2500 μ s wave | 0.63 to 0.69 \times BIL |
| Breakers 362–800 kV ^a | Switching surge—250/2500 μ s wave BSL | 0.63 to 0.69 \times BIL |

^a Includes air blast and SF₆ circuit breakers; the BIL given in the table is for the circuit breaker in the closed position. The BIL across the open contacts of the circuit breakers in the opened position is 9–10% greater.

^bTime to chop.

5.7 Evaluating insulation coordination (Figure 4, Item 6)

Insulation coordination is evaluated on the basis of the margin between the insulation strength and the surge voltage at the equipment terminals, which may be estimated by use of Annex C. If separation distances are less than those shown in Table 4, use of Annex C is not necessary.

In general, there are two methods of portraying insulation coordination, as follows:

- a) The tabulation of protective ratios or margins; and
- b) The graphical presentation of coordination.

Regardless of the method, the same minimum protective ratios and margins apply. The graphical presentation is shown in Figure 9. It should be recognized that data from the four (at most) generally available insulation tests can be used to develop an approximate insulation volt-time curve. A curve plotted in accordance with Figure 9 is a graphical interpretation of the test results, which is presented as an aid to insulation coordination. It is not a true volt-time curve for the transformer. Similarly, the arrester curve is simply a representation of the three protective levels. Evaluation of insulation coordination by the curve method is made in accordance with Figure 9.

NOTE—The transformer surge arrester insulation coordination process is currently under revision for large power transformers (123 kV and above). A new characteristic for transformer insulation coordination, which has been tentatively recommended by the IEEE Transformer Committee [B64], will replace the one shown in Figure 9 and will be used to calculate surge arrester protective margins. Surge arresters satisfying these protective margins will be considered acceptable.

Results of the revision will be published in a future supplement.

5.7.1 Alternative method (Figure 4, Item 6.1)

If the sum of the arrester lead length and the transformer-to-arrester separation distance is less than the values presented in Table 6, the voltages at the equipment need not be determined. The assumptions made in developing the values in Table 6 are similar to those used in Annex C.5 using station-class surge arresters. The rate of rise of the incoming surge on the transmission line was assumed to be 11 kV/μs per kilovolt of MCOV rating to a maximum of 2000 kV/μs as specified in IEEE Std C62.11-1993.

For the situation discussed above, the following protective ratios for lightning overvoltages (PR_{L1} and PR_{L2}) and for switching overvoltages (PR_S) apply

$$PR_{L1} = CWW / FOW$$

$$PR_{L2} = BIL / LPL$$

$$PR_S = BSL / SPL$$

$$PM_{L1} = (PR_{L1} - 1)100\%$$

$$PM_{L2} = (PR_{L2} - 1)100\%$$

$$PM_S = (PR_S - 1)100\%$$




Figure 9—Typical volt-time curve for coordination of arrester-protective levels with insulation withstand strength for liquid filled transformers

Table 6— Allowable separation distance in meters for single-line, single-transformer stations^a

| MCOV ratings (kV) ^b | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------------------------------|----------|---------|---------|---------|---------|----|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|
| BIL (in kV) | 42 | 48 | 57 | 70 | 76 | 84 | 98 | 106 | 115 | 131 | 140 | 144 | 152 | 181 | 190 | 209 | 212 | 220 | 230 | 235 | 245 | 318 | 335 | 353 | 372 | 462 | 470 | 485 | | |
| 250 350 450 | 15 55 | 8 32 | 3 17 | 7 20 | 4 14 | 9 | 4 | 2 | | | | | | | | | | | | | | | | | | | | | | |
| 550 650 750 | | | | 44 | 31 | 21 | 12 | 8 | 5 | 6 | 4 | | | | | | | | | | | | | | | | | | | |
| 825 900 1050 | | | | | | | | | | 14 | 12 | | 10 | 4 | 2 | 3 | | | | | | | | | | | | | | |
| 1175 1300 1475 | | | | | | | | | | | | | | | | 14 | 12 | 11 | 9 | 8 | 7 | | | | | | | | | |
| 1550 1675 1800 | | | | | | | | | | | | | | | | | | | | | | 11 | 8 | 6 | 4 | | | | | |
| 1925 2050 | | | | | | | | | | | | | | | | | | | | | | | | | 6 | 5 | 3 | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | 10 | 9 | 4 | | | |

^aThis table is based on the following: a) Use of station-class surge arresters; b) Use of maximum value for the 0.5 μs FOW protective level from Table 1; and c) Use of 7.6 m for the surge arrester lead length.

^bThe MCOV ratings in this table are commonly used. Use Annex C for other ratings.

NOTE—In Table 6 the following items are applicable: 1) Use Annex C for all cases not covered by this table; 2) Conversion factor to feet: meters multiplied by 3.28; and 3) The allowable separation distances in this table were rounded off.

For acceptable coordination, the protective PR_{L1} and PR_{L2} should be equal to or greater than 1.2, which means that the protective margins PM_{L1} and PM_{L2} should be equal to or greater than 20%. Similarly, PR_S should be equal to or greater than 1.15, which means that the protective margin PM_S should be equal to, or greater than 15%.

5.7.2 Voltage at equipment calculated (Figure 4, Item 6.2)

If the alternate method is not applicable and the voltage at the equipment, V_T , is calculated by methods presented in Annex C, the protective ratios and margins are as follows:

If the time-to-crest of the arrester voltage is equal to, or less than 2 μ s

$$PR_{L1} = CWW/V_T$$

$$PM_{L1} = (PR_{L1} - 1)100(\%)$$

If CWW does not exist or the time-to-crest of the arrester voltage is greater than 2 μ s

$$PR_{L2} = BIL/V_T$$

$$PM_{L2} = (PR_{L2} - 1)100(\%)$$

Also

$$PR_S = BSL/SPL$$

$$PM_S = (PR_S - 1)100(\%)$$

For acceptable coordination PR_{L1} or PR_{L2} and PR_S have to be equal to or greater than 1.15 (PM_{L1} or PM_{L2} and $PM_S \geq 15\%$).

5.8 Evaluation of alternatives (Figure 4, Item 7)

If acceptable coordination cannot be achieved, the following measures may be evaluated:

- a) Increase the BIL and BSL
- b) Decrease arrester-transformer separation distance
- c) Add additional arresters
- d) Use arresters with lower protective characteristics

Since the method presented in Annex C is conservative, an additional suggestion is to determine the surge voltage at the equipment more accurately by the use of computers.

5.9 Protection of transformers

5.9.1 Series windings

Sometimes it is desirable to provide surge protection across series windings of equipment. When arresters are connected in parallel with the series winding, it is necessary to insulate both arrester terminals from ground. In such case install the arrester at or close to the terminals of the equipment

5.9.2 Unloaded transformer windings

In some cases, multiwinding transformers have connections brought out to external bushings that do not have lines connected. Arresters should always be connected at or close to the terminals of such bushings.

5.9.3 Transformer ungrounded neutral

This section applies to wye-connected (Y-connected) transformers or transformer banks, with neutrals isolated or grounded through an impedance.

Neutral terminals are subjected to surge voltages as a result of overvoltages at the line terminals propagating through the windings, and thus may require arrester protection. Neutral terminals are also subjected to temporary overvoltages caused by line-to-ground faults. Isolated neutral terminals may experience overvoltages due to the reflection of impulse voltages from the line terminals.

In selecting an arrester voltage rating for protection of a neutral terminal, the general consideration of 5.3.1 is particularly applicable. The equations of Figure 6 cannot be used. The overvoltage at the neutral is equal to system zero-sequence voltage during faults involving ground. Calculations using the method of symmetrical components are straightforward (Clarke [B25]).

If the transformer power source is switched with single-phase devices or protected by fuses, the voltage at the ungrounded neutral may become equal to system phase-to-neutral voltage for an extended period. This condition occurs when one fuse or switch remains closed while the other two remain open. Since the neutral voltage for this condition will generally be higher and of longer duration than the TOV due to ground faults, it should be taken into account when selecting the MCOV rating for the neutral arrester.

Care has to be taken to use the BIL of the neutral (which is not usually as great as the transformer BIL) in determining required arrester protective level. A protective level $PR_{L2} = \text{BIL (neutral)}/\text{LPL}$ of 1.2 is required; where LPL is the discharge voltage (usually at 3 kA for determining this PR) or the gap sparkover voltage.

5.10 Protection of dry-type insulation

The dry-type insulation equipment covered by this subsection includes such apparatus as dry-type transformers, which may have full-wave impulse withstand insulation strengths lower than liquid-immersed equipment of the same voltage rating. Generally, the impulse withstand strengths with waves of short duration are considered to be the same, or nearly the same, as the full-wave impulse withstand strength, as given for dry-type transformers in Tables 3a and 3b of IEEE Std C57.12.01-1989. Check with the manufacturer of the equipment for specific values.

5.10.1 Dry-type transformers

The following procedure is recommended:

- a) Apply the information in 5.3 for selection of the arrester rating and class.
- b) Determine the minimum permissible full-wave impulse insulation strength (BIL) of the transformer by multiplying the FOW protective level of the arresters by 1.2.

5.11 Protection of shunt capacitor banks

Shunt capacitor banks (IEEE Committee Report [B63], NEMA [B101], and CAN3-C155-M84 [B23]) are used on power transmission systems at voltage levels up to 500 kV, with bank sizes ranging from a few MVAR to over 300 MVAR. The banks are usually installed at substations, wye-connected, with or without

grounded neutrals, and connected to the station busbars through circuit breakers (IEEE Working Group Report [B72] and Reid [B113]). The primary technical benefits of shunt capacitors include the following:

- Supply VARs to local loads
- Power factor correction
- Voltage control
- Increase system capacity
- Reduce system losses

Overvoltage protection should be considered wherever shunt capacitor banks are installed, regardless of voltage level, size, connection, or switching arrangement. The possibility of overvoltages due to lightning, switching surges, and temporary overvoltages requires a detailed evaluation to determine the duty on any surge arresters close to the capacitor bank (IEEE Working Group Report [B71] and McGranaghan et al., [B96]).

Shunt capacitor banks in shielded stations are exposed to incoming lightning surges resulting from line shielding failures or back flashovers on any connected transmission lines. The increase in capacitor bank voltage due to an incoming lightning surge does not depend on the rate-of-rise, but on how much charge is absorbed. If the charge results in excessive overvoltages, surge arresters should be installed to discharge energy and limit the overvoltage level. Due to the low surge impedance of shunt capacitor banks, adding additional surge arresters beyond those that already exist at a station may not be necessary. This may apply to some installations where the surge arresters, for the protection of other equipment, are rated for lightning surge discharge duty (Uman [B125]).

Consequently, a detailed study should be carried out to determine if the bank is adequately protected against lightning. Such a study should include many factors, including origin of the incoming surge, magnitude and waveshape, and also the capacitor bank size, configuration, and location.

The switching of any shunt capacitor bank produces transient overvoltages (Greenwood [B44]). Certain switching operations can present some potentially hazardous overvoltage conditions, not only to the capacitor bank, but to other nearby equipment such as circuit breakers and transformers. Switching surges associated with the installation of shunt capacitor banks include the following (Bayless et al., [B12], Boehne and Low [B16], Dunsmore et al., [B33], Erven and Narang [B37], Lishchyna and Brierley [B88], McCauley et al., [B93], McGranaghan et al., [B96], Mikhail and McGranaghan [B99], Schultz, Johnson, and Schultz [B118], and van der Sluis and Janssen [B128]):

- Bank energization
- Bank de-energization with restrike
- Energization or de-energization combined with a single line-ground fault
- Voltage magnification

Transient overvoltages will always occur on “switching in” a capacitor bank, but will only occur on “switching out” if restrikes occur in the switching device. Arresters installed in a substation to protect transformers and other equipment from overvoltages can be subjected to severe energy absorption duty during capacitor switching because of the large energy ($1/2 CV^2$) stored in the capacitor bank. The capability of all nearby surge arresters to withstand the energies dissipated during capacitor switching is, therefore, an important consideration. In particular, if some existing surge arresters are gapped silicon-carbide units, these units may have to be replaced for one of the following reasons: 1) the higher duty imposed by the addition of the shunt capacitor bank; and 2) the sparkover level will cause them to operate on capacitor switching (Janssen and van der Sluis [B75]).

Due to the frequent switching of shunt capacitor banks, there will be a significant increase in the number and magnitude of transient overvoltages on the power system. Shunt capacitor banks are normally switched in during peak loading conditions and switched out during light loading conditions or high voltage.

Overvoltage protection should be considered at the following locations (Alexander [B2], Brunke and Schockelt [B19], IEEE Std 575-1988 [B58], Jones and Fortson [B76], Lishchyna and Brierley [B88], O'Leary and Harner [B103], Pflanz and Lester [B109], Sabot et al., [B116], and Stenstrom [B121]):

- a) On the capacitor primary and backup switchgear to limit transient recovery voltages (TRV) when shunt capacitors are being switched out.
- b) At the end of transformer terminated lines to limit phase-to-phase overvoltages resulting from capacitor switching or line switching in the presence of shunt capacitor banks.
- c) On transformers when energized in the presence of shunt capacitor banks.
- d) On shunt capacitor banks in series or parallel with transformers.
- e) On lower voltage systems that are inductively coupled through transformers to higher voltage systems with shunt capacitor banks.
- f) On the neutrals of ungrounded shunt capacitor banks.

5.12 Protection of underground cables (Witzke and Bliss [B134])

Many of the concerns identified in 5.11 should be considered also for high-voltage cable installations (ANSI/IEEE Std 422-1986 [B6] and IEEE Std 525-1992 [B56]). In addition, overvoltage protection of the junction between overhead lines and cables, as discussed in 5.5.3, should be evaluated. Lightning may also be an important consideration at cable terminals. Cables may require further consideration because of traveling wave phenomena and the effects of distributed and smaller capacitance values.

5.12.1 Cable insulation

Any equipment that is connected to overhead transmission lines needs consideration for overvoltage protection. Any dielectric failure in an underground power cable will undoubtedly involve non self-restoring insulation. This implies that any breakdown of cable insulation would require extensive outage time for repairs at a high cost. The conventional method for protecting cable circuits within overhead line sections from high transient overvoltages has been to apply rod gaps or surge arresters at both terminals. Cable circuits connected between substations and overhead lines should also be protected from overvoltages.

Cable circuits, due to their relatively high capacitance, have low surge impedance. A typical value is about 50 ohms, which means that surges incoming from overhead lines will be reduced significantly at the line-cable junction. On the other hand, surges originating at a substation will enter a cable only to undergo an increase in voltage at the cable-line connection due to the much higher surge impedance of the line. Since there is little attenuation of surges in cables and the ratio of surge impedances is so large it is common for the reflected wave plus the oncoming wave to cause a voltage doubling at the cable-line connection. This effect should be considered when evaluating the margin of protection.

Metal-oxide surge arresters can provide excellent cable protection, but the arrester should be capable of absorbing the high energy that can be stored in a cable when subjected to an overvoltage that causes the arrester to discharge.

For multiple cable and overhead line connections, optimum protection against overvoltages can best be achieved by carrying out a comprehensive transients study of the interconnected system (Greenfield [B43], Greenwood [B44], Marti [B92], and van der Merwe and van der Merwe [B127],). The selection of arrester placement, voltage rating, and energy absorption capability can be based on model studies.

5.12.2 Sheath and joint insulation

High voltage power cables are provided with metallic sheaths to give a uniform field distribution to the solid dielectric, to protect it from external damage and to provide a return path for fault current.

To ensure safety and to avoid the losses associated with circulating currents requires special bonding and grounding of the metallic sheath circuits. The special sheath bonding systems in common use in North America are single point bonding and cross-bonding. The length of the cable sheath circuit involved in each case is usually determined by the allowable 60 Hz voltage under steady state and fault conditions. A disadvantage of both methods, however, is that a change in surge impedance occurs at the ungrounded terminals of the cable sheath and at the sheath sectionalizing insulators. As a result, all traveling wave surges entering the cable system due to lightning, switching operations, or faults will be subjected to partial reflection and refraction at these locations. As a consequence, hazardous transient overvoltages can be developed across the sheath joint insulators and sheath jacket insulation (Ball, Occhini, and Luoni [B9], Halperin, Clem, and Miller [B49], Kuwahara and Doench [B84], and Watson and Erven [B132]).

Metal-oxide surge arresters can offer excellent protection for cable sheath and joint bonding providing the following conditions are met (Reid et al., [B114]):

- a) Should be suitable for continuous operation under operating voltages during normal and emergency loads on the cable circuit.
- b) Should withstand 60 Hz overvoltages resulting from faults in or external to the cable circuit.
- c) Should limit surge voltages below the surge withstand strength of the jacket and sheath joint insulators.
- d) Should absorb, without damage, impulse currents and energy during discharge conditions associated with switching, fault initiation, and lightning.

5.13 Protection of gas-insulated substations (GIS)

SF₆-gas-insulated substations (GIS) at voltages up to 500 kV have been installed in increasing numbers over the past 25 years (*Proceedings* [B111]). From the design standpoint, a GIS is more sensitive to overvoltages than an air-insulated station (AIS). This is a result of the high electrical stress placed on relatively small geometries. With GIS the dielectric performance is independent of the atmospheric conditions, therefore the insulation coordination is based solely on the rated insulation level of the GIS and the margin considered to satisfy the risk of flashover. In this case, the risk should be kept very low since any flashover involves non-self-restoring insulation. Any flashover in a GIS involves an outage to inspect the damage, coupled with a long restoration time.

Another important feature about GIS is that the volt-time characteristics of pressurized SF₆ are much flatter than for atmospheric pressure air or for solid dielectrics, especially for fast fronts. This means that any incoming surge having a sufficiently high peak value and rate-of-rise is likely to cause breakdown in the GIS before flashing over any coordinating air gaps. Insulation co-ordination can be achieved with a device that has volt/time characteristics similar to those of the SF₆ system. In practice, this can be obtained through the use of metal-oxide surge arresters. Their highly nonlinear characteristics and construction make them ideally suited for this duty. Due to the differences mentioned above, some consideration should be given to increasing the protective margin for fast front surges as compared to AIS.

In general, GIS with connections to overhead lines will need arresters on each line entrance. One of the most common questions is related to the location and type of the surge arrester within the GIS system. Currently there are two types of metal-oxide arrester structure available; an insulated housing type and a metal tank type. If the arrester is air insulated and located as close as feasible to the GIS, the arrester rating should be selected based on the insulation level chosen for the GIS and the margin required (Alvinsson et al., [B3], Boeck et al., [B15], and Hileman and Weck [B52]). The MCOV and TOV requirements for the surge arrester should be satisfied and a minimum 20% protective margin is recommended. Such coordination based on the insulation level chosen for the GIS and the catalogue data (V-I characteristic for the surge arrester) is needed with the GIS systems. Difficulty arises when the same protective margin is required with respect to fast front surges (1–3 μs fronts) such as lightning striking overhead lines or towers close to the GIS. In addition to surge arresters, capacitance such as capacitor voltage transformers (CVTs) may be used at the overhead

junction to slow the fast fronts of the incoming surges and to extend the protective zone of the arrester at that location. If the arrester is a tank type, its rating can also be selected on the same basis. However, if it is connected as part of the GIS system, which is often desirable to save space, then the arrester will have to be disconnected from the rest of the GIS when high potential tests are being conducted. This occurs during commissioning and following repairs to adjacent parts of the system.

Although there has been much discussion about the use of metal-oxide surge arresters within a GIS, there does not appear to be a strong body of evidence to indicate the need for surge arresters within a well designed GIS, and particularly for GIS rated 230 kV and below. On the other hand, GIS switchgear, notably disconnect switches, have been known to generate very fast transients. Although metal-oxide surge arresters have demonstrated capabilities to respond to fast front surges, it appears doubtful that the dimensions involved will allow for control of the extremely fast fronts (nanoseconds) that are associated with GIS switching. The effect of fast transients on the equipment, such as transformers connected to the high voltage side, however should be taken into account.

5.14 Protection of rotating machines

At present a guide for the protection of rotating machines is in preparation.⁷ In the interim refer to NEMA and IEC Standards in the Reference Section, and refer to the Annex D (Dick et al., [B29], Dick et al., [B30], Gupta et al., [B47], Gupta et al., [B48], IEEE Working Group Report [B72], Jackson [B74], and McLaren and Abdel-Rahman [B97]).

5.15 Protection of power line insulation

Transmission and distribution line insulators may be protected from lightning flashover by overhead shield wires. However, the effectiveness of the shield wire depends on many factors. Prime among these are shield angle and structure ground footing resistance.

Strokes to the shield wire will cause surge voltages to be induced in the phase conductors. The magnitude of the induced voltage is a function of the current magnitude, resistance, and geometry (Anderson [B4]). Stroke currents exceeding a critical current value will develop sufficient voltage between the structure and the phase conductor to cause an insulator flashover. The phase with the poorest coupling to the shield wire will be the most highly stressed and therefore most likely to flash over.

The possibility of a flashover of the line insulation and subsequent service interruption may be significantly reduced through the application of line arresters (Brewer [B17]). Line arresters may also be applied on one circuit of a double circuit line in order to reduce double circuit interruptions due to lightning. Line arresters may be installed phase-to-ground, either in parallel with the line insulators (Koch et al., [B83]), or built into the insulators (Yamada et al., [B135]). While the failure rate of these arresters is low, the user should consider the failure mode of the arrester. After failure, the arresters should be disconnected from the line to allow for successful line reclosing.

The protective level of the line arresters should be greater than the protective levels of the adjacent substation arresters. This will reduce the energy absorbed by the line arresters due to switching surges and therefore reduce the possibility of a line arrester failure (Anderson [B4]).

The appropriate location of the surge arresters depends on many factors including lightning ground stroke density, exposure, span length, conductor geometry, footing resistance, insulation level, and desired line performance goals. In general, the more frequently arresters are installed, the better the performance. There are

⁷IEEE PC62.21

several computer models available to assist in selecting the location of surge arresters, or the arrester manufacturer may be contacted for a recommendation.

In some cases, arresters are being used successfully in place of a shield wire(s). The user should consider energy, mechanical strength, and weight requirements in developing the system design. The arrester manufacturer should be contacted for recommendations.

5.16 Protection of series capacitor banks

The development of metal-oxide materials has now matured to a point where the material is commonly used to protect the capacitor units within a series capacitor bank. When used in this form it is commonly called a varistor. A varistor protects the capacitor units by controlling the voltage across the capacitor units to the design protective level, by commutating a portion of the capacitor current. When the capacitor voltage falls significantly below the varistor protective level, the capacitors are automatically electrically reinserted. Depending on the series capacitor location and available fault current, the varistor may be protected by a bypass device such as a breaker, gap, or a thyristor. Field experience indicates that capacitor life will be extended by eliminating or minimizing bypass operations. This should be considered when varistor energy handling capability makes it economically feasible.

The following performance characteristics should be considered for properly applying a varistor:

- a) Protective level—This is the maximum voltage appearing across the capacitor at the specified current (usually worst case fault). This level is generally determined by performing system studies. The protective level is usually set above steady state and dynamic overcurrents such as the 30-minute overload rating of the bank and system swings.
- b) Energy handling capability—This is the thermal withstand capability of the varistor. The manufacturer's design is based on the identified duty cycle, and the dissipated energy for the various system events associated with the duty cycle. The dissipated energies (varistor duty) are determined by system study simulations and based on the time until the bypass device operates, or when circuit breakers clear a fault condition, and the number of circuit breaker line reclosures to which the series capacitor bank is exposed. The above capabilities are described below:
 - 1) Thermal capability—The maximum temperature at which the varistors can continue to be operated without the need for bypassing to allow the varistor to cool. This is typically determined by the bank's duty cycle consisting of a combination of internal and external faults, system swings and/or operation at the bank's 30-minute rating, and the number of circuit breaker line reclosures to which the series capacitor bank is exposed.
 - 2) Withstand capability—The maximum short time energy that may be withstood, above which disks are exposed to a statistical probability of failure due to an unequal current distribution or excessive temperature rise.
- c) Current sharing—The manufacturer should balance the varistor disk columns to avoid exposing individual columns to a disproportionately large current. To accomplish this, the discharge voltage of the disk columns should be matched and tested to show that each column, including spare units (which should be energized), are exposed to approximately the same current, and, hence energy.
- d) Pressure relief—Since the varistor is paralleled with the capacitor bank and only a small amount of inductance is present in the loop during a varistor failure, extremely large currents at high frequency will be present. This current will produce a large over-pressure within the porcelain or enclosure. To avoid catastrophic failure, and the associated safety hazard, a pressure relief system may be provided to safely vent this over-pressure.

Under fault conditions, the varistor should be capable of withstanding the currents and energies present until the fault is removed or a bypass takes place. To control varistor duty, a protection system is usually provided

that typically monitors varistor and, in some cases, capacitor currents. The following protective functions for the varistor are usually provided:

- a) Fast bypass—Monitor the varistor current and calculated energy to detect internal faults that can be bypassed as soon as detected. To speed detection, capacitor current can also be monitored.
- b) Thermal bypass—Takes place when varistor temperature exceeds a preset level. This would normally indicate that either normal operation or operation at some specified additional duty (e.g. external fault and 30-minute rating) could produce a thermal bypass. A bypass can also take place following a significant energy injection to allow equalization of disk temperature.
- c) Imbalance—Detects a current difference between groups of parallel varistor units and bypasses and locks the bank out if the imbalance exceeds preset limits. Such an imbalance is normally due to the failure of either a partial or complete varistor unit. For every reclosure of the line with the series capacitor bank, the bank protection is exposed to additional energy with the possibility of a sustained fault, and the actions of the above functions should be repeated.

5.17 Protection of circuit breakers—TRV control

Metal-oxide surge arresters can be used to limit the magnitude of TRV across circuit breakers to acceptable values. This may provide a more economical solution than increasing the number of interrupting chambers to withstand the higher TRV.

Surge arresters electrically connected across the circuit breakers are the most direct means of controlling TRV, as the amplitude of the TRV can not exceed the protective level of the surge arresters. If the surge arresters are mounted across the interrupters of multi-chambered circuit breakers, caution should be exercised when interrupting fault currents. A reignition of a single series chamber can result in fault currents flowing through the surge arrester across the non-reignited chamber. Surge arresters across the open circuit breakers during reclosing should be able to withstand the difference of the power frequency out-of-phase overvoltages on each side of the open circuit breakers for the time required for the reclosing.

Surge arresters can be used across an interrupter to limit reactor switching TRV (IEEE Std C37.015-1993). Surge arresters can be used instead of opening resistors on circuit breakers to reduce trapped charge on shunt capacitors or transmission lines. Surge arresters have been considered to limit the TRV across circuit breakers used to switch series-compensated lines. The voltage appearing on the series capacitor during a fault augments the higher-frequency fault component of the TRV. The location of the series capacitor bank (i.e., on the load side of the circuit breaker or on the source side) can have a significant effect on the magnitude of the TRV. Series capacitor banks protected against overvoltage with metal-oxide varistors as opposed to spark-gap protection deserve special consideration. Following clearing of the fault, a dc voltage equal to the protective level of the varistor can remain on the bank throughout the duration of the TRV.

Surge arresters can also be installed phase-to-ground at either or both sides of the circuit breakers. However, depending on the required rating and protective levels of the surge arresters for TRV control, this usually requires appropriate studies with proper simulation of the surge arresters. Studies should include coordination with any other surge arresters installed in the substation or on shunt reactors.

6. Protection of distribution systems

6.1 Introduction

This section covers the application of metal-oxide surge arresters to safeguard electrical distribution equipment and lines against the hazards of abnormally high voltage surges, particularly those caused by lightning.

Although the basic principles of arrester selection and application as outlined in Clause 5 also apply to distribution arresters, there are specific differences that require special consideration.

Distribution lines are generally not shielded and therefore are particularly susceptible to direct lightning strokes (Brown and Thunander [B18], Eriksson, Stringfellow, and Meal [B36], Goldenhuys, Stringfellow, and Meal [B42], Linck [B87], MacCarthy et al., [B90], and McEachron and McMorris [B94]). The transient overvoltages developed by lightning are of greater concern than those caused by switching. Insulation coordination based on lightning surge voltages is thus the major consideration for distribution systems.

The level and frequency of occurrence of discharge currents varies widely and depends to a great extent on the exposure of the distribution system and the ground flash density. Detailed reviews of material relating to this subject are available in references (Barker et al., [B11], Berger, Anderson, and Kroninger [[B13], Darveniza and Uman [B28], Gaibrois [B38], Grumm [B45], MacCarthy et al., [B90], and McEachron and McMorris [B94]). Arresters applied on exposed systems (few trees and buildings) of a rural nature (less frequent equipment and grounds) located in areas of high ground flash density (GFD) will see large magnitude currents more often than arresters in shielded locations. The peak magnitudes and frequencies of discharge for exposed arrester applications are shown by the exposed line curves of Figure 10. Arresters applied on systems which are moderately to well shielded (many trees or surrounding buildings) and are of a suburban or urban nature with closer equipment spacing will see fewer large magnitude discharges (see environmentally shielded line curves in Figure 10).

The arrester discharge current incidence curves of Figure 10 are intended to provide the lightning protection engineer with an estimate for the magnitudes and rates of occurrence of discharges at typical distribution arrester locations under various conditions. For specific arrester applications, Figure 10 and Figure 11 can be used to assist in determining an adequate lightning-coordination-current for protective margin calculations. For example, the lightning-coordination-current for protection calculations is 10 kA in normal situations. However, for a highly exposed location with a GFD of 10 flashes/km²/year, Figure 10 indicates that an arrester discharge current of 30 kA or greater would occur about once every 10 years. If the expected life of the protected equipment is 30 years, then this suggests that coordination should be made with a current level higher than 10 kA (perhaps as high as 40 kA). In other situations where GFD is very low and there is significant environmental shielding (limited exposure), coordination current may be reduced to values less than 10 kA. The decision to utilize a coordination current different than the standard 10 kA level may impact the type of arrester selected and the arrangement of arresters utilized.

In cases where only thunderstorm days or thunderstorm hours are known, GFD can be estimated as follows:

Converting thunderstorm days to GFD

$$N_g = 0.04T_D^{1.25}$$

where

T_D is Keraunic level in thunderstorm days

N_g is Ground Flash Density (flashes/km²/year)


Converting thunderstorm-hours to GFD

$$N_g = 0.054T_H^{1.1}$$

where

T_H is thunderstorm-hours


N_g is Ground Flash Density (flashes/km²/year)



NOTE—Environmentally shielded areas are equal to situations with average to high levels of environmental shielding (nearby trees and buildings)—suburban lines usually fit this definition. Exposed lines are equal to exposed situations (few nearby trees and buildings or located along elevated ridges, etc.)—rural lines often fit this definition. (These curves are intended for arresters on lines without overhead ground wires, static wires, or shield wires.)

Figure 10—Distribution arrester discharge currents

Lightning data provided by the U. S. National Lightning Detection Network™
(Measured Lightning Flash Density Corrected for NLDN Detection Efficiency)



Graphic reproduced with permission from Global Atmospheric, Inc., Tucson, Ariz. Lightning data provided by the U.S. National Lightning Detection Network.

**Figure 11 — 1989 to 1994 average U.S. lightning flash density; ground flashes/km²/year
(Byerley et al., [B22] and Cummins et al., [B27])**

Other potential causes of severe arrester duty occur when arresters are used to protect switched capacitor banks (see 6.8.1) or when arresters are subjected to ferroresonant overvoltages (see 6.4.4) or backfeed overvoltage (see 6.4.5).

Distribution equipment, including arresters, is low in unit cost compared to station equipment, but is used in large quantities. It is usually not economically feasible to make independent studies for each specific arrester application. Consequently, distribution arresters are usually selected so that they can be used for similar application anywhere on a system rather than for a particular location.

6.2 General procedure

The general procedure for selecting a distribution arrester is to determine the proper arrester MCOV that can be used at all similar locations on the distribution system to be protected. Also, the TOV capability of the arrester should not be exceeded by the magnitude and duration (total accumulated cycles) of any TOV of the system at the arrester location. For arrester application on distribution systems, the TOV is usually based on the maximum phase-to-ground voltage that can occur on unfaulted phases during single line-to-ground faults. Surge arrester selection is discussed in 6.3.

Insulation coordination is discussed in 6.5. For system voltages up to 15 kV, insulation coordination for overhead connected equipment has not been rigorously studied because the protective margin (PM) between standard equipment BIL and the protective characteristics of modern distribution arresters is substantially in excess of 20% in usual applications. Insulation coordination becomes a primary consideration for higher dis-

tribution voltage systems because PM is reduced (particularly when reduced BIL values are used). Insulation coordination may also be important for line protection (see 6.6) and for protection of underground distribution systems (see 6.8.4).

6.2.1 Installation practices that jeopardize insulation coordination

Installation practices that jeopardize insulation coordination include the following:

- a) Long leads between line and arrester line terminal and between arrester ground terminal and tap to the equipment case (see 6.7.1)
- b) Large separation distances between the arrester and the protected equipment (see 6.7.2)
- c) Failure to interconnect the arrester and equipment ground terminals (see 6.7.4)

6.2.2 Applications requiring special considerations

Applications that require special considerations, either with regard to duty requirements imposed on the arrester or with regard to protection requirements, include the following:

- a) Ungrounded systems (see 6.4.5)
- b) Shunt capacitor banks (see 6.8.1)
- c) Switches, reclosers, etc. (see 6.8.2)
- d) Voltage regulators (see 6.8.3)
- e) Underground circuits (see 6.8.4)
- f) Contaminated atmospheres (see 6.8.5)

6.3 Selection of arrester ratings

Power systems to be protected by distribution arresters are either:

- a) Three-wire wye or delta, high or low impedance grounded at the source; or
- b) Four-wire multigrounded wye.

Construction includes open wire, spacer cable, and underground cable systems.

Proper application of metal-oxide surge arresters on distribution systems requires knowledge of

- The maximum normal operating voltage of the power system; and
- The magnitude and duration of TOVs during abnormal operating conditions.

This information is compared to the arrester MCOV rating (see 6.3.1) and to the arrester TOV capability (see 6.3.2). The user should be careful not to replace silicon-carbide arresters with metal-oxide arresters that have the same duty cycle voltage rating without first analyzing the expected magnitude and duration of TOVs (Gaibrois, Mashikian, and Johnson [B40]).

Commonly applied voltage ratings of metal-oxide arresters on distribution systems are shown in Table 7. Protective characteristics of metal-oxide distribution arresters are given in Table 8.

6.3.1 MCOV rating

Valve elements in a gapless and shunt gapped metal-oxide surge arrester are continuously exposed to line-to-ground power-frequency voltage. The MCOV rating of a metal-oxide arrester is the maximum designated rms value of power-frequency voltage (at maximum temperature levels as indicated in IEEE Std C62.11-1993) that may be applied continuously between the terminals of the arrester. Consequently, the MCOV rat-

Table 7—Commonly applied voltage ratings of metal-oxide arresters on distribution systems

| System Voltage (V rms) | | Commonly applied arrester duty-cycle (MCOV) voltage rating (kV rms) on distribution systems | | |
|---------------------------|----------------------------|--|---|---|
| Nominal voltage | Maximum voltage range B | Four-wire multigrounded neutral wye | Three-wire low impedance grounded | Three-wire high impedance grounded |
| 2400 | 2540 | | | 3 (2.55) |
| 4160Y/2400 | 4400Y/2540 | 3 (2.55) | 6 (5.1) | 6 (5.1) |
| 4260 | 4400 | | | 6 (5.1) |
| 4800 | 5080 | | | 6 (5.1) |
| 6900 | 7260 | | | 9 (7.65) |
| 8320Y/4800 | 8800Y/5080 | 6 (5.1) | 9 (7.65) | |
| 12 000Y/6930 | 12 700Y/7330 | 9 (7.65) | 12 (10.2) | |
| 12 470Y/7200 | 13 200Y/7620 | 9 (7.65) or 10 (8.4) | 15 (12.7) | |
| 13200Y/7620 | 13 970Y/8070 | 10 (8.4) | 15 (12.7) | |
| 13 800Y/7970 | 14 520Y/8388 | 10 (8.4) and 12 (10.2) | 15 (12.7) | |
| 13 800 | 14 520 | | | 18 (15.3) |
| 20 780Y/12 000 | 22 000Y/12 700 | 15 (12.7) | 21 (17.0) | |
| 22 860Y/12 000 | 22 000Y/12 700 | 15 (12.7) | 21 (17.0) | |
| 23 000 | 24 340 | | | 30 (24.4) |
| 24 940Y/14 400 | 26 400Y/15 240 | 18 (15.3) | 27 (22.0) | |
| 27 600Y/15 935 | 29 255Y/16 890 | 21 (17.0) | 30 (24.4) | |
| 34 500Y/19 920 | 36 510Y/21 080 | 27 (22.0) | 36 (29.0) | |

ing should be at least equal to the expected maximum continuous operating voltage at the location where the arrester is to be applied.

6.3.2 Temporary overvoltage (TOV)

Metal-oxide surge arresters are capable of operating for limited periods of time at power-frequency voltages above their MCOV rating. The amount of overvoltage that a metal-oxide arrester can successfully tolerate depends on the length of time that the overvoltage exists. Manufacturers can describe the arrester overvoltage capability in the form of a curve that shows temporary power-frequency overvoltage versus allowable time. A typical curve is shown in Figure 12. (These curves are sensitive to ambient temperature and prior energy input.)

To ensure that the arrester TOV capability is not exceeded, the maximum TOV of the power system has to be determined along with the maximum time that the system is operated in the abnormal voltage state. This abnormal voltage state can result from several factors, some of which are: overvoltage on an unfaulted phase during a phase-to-ground fault, switching transients, and ferroresonance. In the case of the overvoltage due to a phase-to-ground fault, this voltage can be calculated using the equations shown in the annex of IEEE

Table 8—Distribution arrester protective characteristics

| Voltage ratings | | Protective level—range of industry maxima (kV) | | | | | |
|---------------------|---------------|--|------------------|------------------|----------------------------------|------------------|------------------|
| Duty cycle (kV-rms) | MCOV (kV-rms) | Front-of-wave protective level | | | Discharge voltage with 8/20 wave | | |
| | | 5 kA normal duty | 10 kA heavy duty | 10 kA riser pole | 5 kA normal duty | 10 kA heavy duty | 10 kA riser pole |
| 3 | 2.55 | 11.2–17 | 13.5–17 | 10.4 | 10.2–16 | 9.1–16 | 8.2 |
| 6 | 5.1 | 22.3–25.5 | 26.5–35.3 | 17.4–18 | 20.3–24 | 18.2–25 | 16.2 |
| 9 | 7.65 | 33.5–36 | 26.5–35.3 | 22.5–36 | 30.0–33.5 | 21.7–31.5 | 20.0–24.9 |
| 10 | 8.4 | 36.0–37.2 | 29.4–39.2 | 26.0–36 | 31.5–33.8 | 24.5–35 | 22.5–26.6 |
| 12 | 10.2 | 44.7–50 | 35.3–50 | 34.8–37.5 | 40.6–44 | 32.1–44 | 30.0–32.4 |
| 15 | 12.7 | 54.0–58.5 | 42.0–59 | 39.0–54 | 50.7–52 | 35.9–52 | 33.0–40.2 |
| 18 | 15.3 | 63.0–67 | 51.0–68 | 47.0–63 | 58.0–60.9 | 43.3–61 | 40.0–48 |
| 21 | 17.0 | 73.0–80 | 57.0–81 | 52.0–63.1 | 64.0–75 | 47.8–75 | 44.0–56.1 |
| 24 | 19.5 | 89.0–92 | 68.0–93 | 63.0–72.5 | 81.1–83 | 57.6–83 | 53.0–64.7 |
| 27 | 22.0 | 94.0–100.5 | 77.0–102 | 71.0–81.9 | 87.0–91.1 | 65.1–91 | 60.0–72.1 |
| 30 | 24.4 | 107.0–180 | 85.0–109.5 | 78.0–85.1 | 94.5–99 | 71.8–99 | 66.0–79.5 |
| 36 | 29.0 | 125.0 | 99.0–136 | 91.0–102.8 | 116.0 | 83.7–125 | 77.0–96 |

Working Group Report [B72], the methods described in Lat [B86], or a computer program capable of modeling the distribution system. A conservative approach is to multiply the maximum phase-to-phase operating voltage by the coefficient of grounding (see Figure 6 and Annex B). During this type of fault, the surge arrester is subjected to a TOV whose duration is a function of the operating times of protective relays and fault interrupting devices. The MCOV of the arrester selected should be high enough so neither the magnitude nor duration of the TOV exceeds the capability of the arrester.

6.3.2.1 Application of arresters on distribution systems

See section 5.3.2 for use of TOV curve. For distribution systems, the usual problem is not lack of data but a large number of locations, overvoltages, and durations. These differences have to be considered to determine the single arrester rating to be used on the entire feeder.

TOV should be a consideration for non-effectively grounded systems.

Ferroresonance is a particular concern on distribution systems. Applications prone to ferroresonance may require attention to arrester rating and capabilities (see section 6.4.4).

When accurate data is available on feeder overvoltages and durations, this data can be compared to the single standard curve to select the appropriate arrester rating.




Figure 12—Minimum expected TOV capability of gapless distribution class MOSAs, no prior duty-arrester preheated to 60 °C (North American Manufacturers, May 1995)

If the user has distribution arrester failures attributed to TOV, selection of the next higher voltage rating may resolve the problem, or in extreme cases, a system study may be warranted to determine TOV amplitudes and durations at problem locations.

6.3.2.2 Application of arrester for distribution system generators

Overvoltages may occur when generation units are present on distribution systems. Overvoltages can be caused when a generator and part of the distribution network are separated from the utility. This is called “islanding” and could be caused by ungrounded transformer connections, self-excitation, or ferroresonance. Generator overvoltages have not been a major problem in the past. One reason is that a small number of generation units were in operation and most of these were quite small. Another reason is that gapped arresters, used almost exclusively until about the early 1980s, may not have sparked over from the overvoltages and therefore would not be harmed. Since some metal-oxide arresters do not have gaps, they may not be able to survive the sustained overvoltages caused by the presence of a generator. As a generator’s use and size increases and surge arresters are used more at the distribution level, generation overvoltages could become a problem.

The results of studies suggest that surge arresters should survive most overvoltage situations if the protection scheme can relay the generator off the utility system in a few seconds. Fault protection schemes used at the generation site would be expected to sense the “islanding” condition and disconnect from the system in a matter of a few seconds. On systems with large generation relative to the possible load, utilities may consider using higher rated surge arresters.

6.3.3 Normal-duty versus heavy-duty surge arresters

The application of normal- or heavy-duty surge arresters is not well defined and is more a choice of the user than a decision based on actual firm requirements or performance data.

Table 9 compares design requirements for tests on normal and heavy-duty arresters (IEEE Std C62.11-1993).

The heavy-duty arrester is therefore capable of discharging a higher energy than a normal-duty arrester and should be used when greater than normal withstand capability is desired or required. High energies due to

Table 9—Design requirements for tests on normal- and heavy-duty arresters

| Test performed | Normal duty | Heavy duty |
|------------------------------|----------------------------|-----------------------------|
| High-current short duration | 65 kA (4/10 μ s) | 100 kA (4/10 μ s) |
| Low-current long duration | 75 A \times 2000 μ s | 250 A \times 2000 μ s |
| Duty cycle impulse current | 5 kA (8/20 μ s) | 10 kA (8/20 μ s) |
| Surges after duty cycle test | — | 40 kA (4/10 μ s) |

lightning are more likely to occur in areas with a high yearly number of thunderstorm days where lightning flashes are more frequent and there can be a higher number of lightning surges above 65 kA.

The total lightning current is unlikely to be discharged by a single arrester and the amount of current discharged by an arrester depends on the distance between the strike and the arrester, the presence of other arresters, and the level of line insulation (Brown and Thunander [B18]).

Heavy-duty arresters could also be chosen to discharge higher energy surges, such as those generated while switching large capacitive loads. For these cases, other arrester classes may be considered.

Finally, heavy-duty arresters generally have a lower discharge voltage characteristic than normal duty arresters, but prior to selecting any arrester, all characteristics, as well as the economics of one arrester classification versus the other, should be closely scrutinized.

6.4 Distribution system overvoltages

6.4.1 Four-wire multigrounded-wye systems (including spacer-cable circuits)

The arrester MCOV should be equal to, or greater than, the maximum continuous operating voltage applied to the arrester.

Most distribution systems in use in North America are of the four-wire multigrounded type. In lieu of calculations to determine phase-to-ground voltage during ground faults it can be assumed that the TOV on unfaulted phases exceeds the nominal line-to-ground voltage by a factor of 1.25. The 1.25 factor applies when line-to-ground resistance is low (i.e., less than 25 Ω) and neutral conductor size is at least 50% of the phase conductor (McMillen, Schoendube, and Kaufmann [B98]). The factor can exceed 1.25 when small size neutral conductors are used (Kershaw Jr., Gaibrois, and Stump [B81]).

Because the metal-oxide arrester may be more sensitive to overvoltages caused by poor grounding and poor regulation, many utilities use a factor of 1.35.

6.4.2 Three-wire, low-impedance, grounded systems (grounded at source only)

As mentioned in 6.4.1, the arrester MCOV rating has to be greater than the MCOV applied to the arrester.

In lieu of calculations to determine phase-to-ground voltages during ground faults, the general practice has been to assume the TOV on the unfaulted phases rises to 1.4 p.u. (Report [B7]). The maximum duration of this TOV has to be determined and the arrester overvoltage-versus-time curve examined to be sure the arrester can withstand the TOV for the duration of the fault.

If the system is grounded through an impedance, the voltage rise on the unfaulted phases could easily be greater than 1.4 p.u. and therefore should be calculated. When a fault occurs at the arrester installation, the voltage on unfaulted phases can rise on the order of 80% (Report [B7]) due to the ground resistance at the point of fault. Values for both unfaulted phases should be calculated since grounding through a resistance can result in unequal voltages (IEEE Tutorial [B65]).

Where it is possible to backfeed a portion of the circuit which has been disconnected from the source through devices such as transformers or capacitors that are connected to that part of the circuit, the TOV should be assumed to be equal to the maximum phase-to-phase voltage. In this case, it should be assumed that the duration of this situation is within the capability of the arrester. If duration cannot be determined, the arrester should be selected so that its MCOV rating equals or exceeds the maximum system phase-to-phase voltage.

6.4.3 Three-wire, high-impedance ground, or delta-connected systems

The arrester MCOV rating should equal, or exceed, the MCOV applied to the arrester.

During a single line-to-ground fault, the line-to-ground voltage on the other two unfaulted phases will rise to line-to-line values. Because fault current values are extremely low, relaying schemes could allow this type of fault to exist for considerable time. Consequently, the general practice is to choose an arrester with an MCOV rating greater than the maximum system phase-to-phase voltage.

A lower MCOV rating may be used if fault detection relaying limits the duration, but the arrester should have the capability to withstand line-to-line voltage for the maximum time required to clear the fault. This could result in a duty cycle rating lower than that recommended for a silicon-carbide arrester (but caution is advised in making this choice).

6.4.4 Overvoltages caused by ferroresonance effects

Ferroresonant overvoltages result when a saturable inductance is placed in series with a capacitance in a lightly damped circuit. The series L-C circuit topology usually results when a three-phase transformer, or bank of transformers, is left with one or two phases disconnected from the source. The capacitance is typically provided by overhead lines, underground cables, the internal capacitance of the transformer windings, or by shunt capacitor banks. One of the following combinations of transformer and capacitance connections should be present to create the ferroresonant circuit:

- a) An ungrounded transformer primary connection (delta, open delta, ungrounded-wye, three-phase transformer or bank, or a phase-phase connected single-phase) and phase-ground capacitance(s) connected to the transformer phase(s) disconnected from the source.
- b) A grounded wye-wye three-phase transformer or transformer bank with one or two phases disconnected from the source and an ungrounded capacitance connected between the opened transformer phases on either the primary or the secondary terminals of the bank. The ungrounded capacitance is typically in the form of a delta or ungrounded-wye capacitor bank, or a length of overhead three-phase primary line.
- c) A grounded wye-wye three-phase transformer, constructed with a five-leg or four-leg core, having one or two phases disconnected from the source and also having phase-ground capacitance(s) connected to these same phases on the primary or secondary transformer terminals.

Ferroresonant overvoltage magnitudes are dependent on the transformer primary winding connection and the amount of capacitance present compared to the transformer characteristics. They tend to be more severe for higher system voltage classes, smaller transformer kVA ratings, and higher efficiency (lower core loss) transformers. References predating the 1980s, characterizing ferroresonant overvoltage magnitudes or the conditions necessary to have ferroresonance (Auer and Schultz [B8]; Crann and Flickinger [B26]; Hopkinson [B53], [B54], and [B55]; and Smith, Swanson, and Borst [B120]), were based on transformers with core

losses considerably greater than are now typically installed. More recent research (Walling et al., [B131]) suggests ferroresonance occurs more easily and overvoltage magnitudes are more severe for contemporary transformer designs. A conservative approach is to consider ferroresonance possible for any open-phase conditions with the transformer and capacitance configurations listed above.

For transformers with ungrounded primary connections, ferroresonant overvoltages can easily exceed 3–4 p.u. (Hopkinson [B53], Young, Schmid, and Fergestad [B136]). Internal transformer capacitance can often be sufficient to support severe ferroresonance in ungrounded-primary transformers and banks, without any connected line, cable, or capacitor banks. This “self-ferroresonance” phenomenon previously existed only with small banks at 24.9Y/14.4 kV and 34.5Y/19.9 kV (Hopkinson [B53]), but has now been observed with more efficient 15 kV-class banks.

Overvoltage magnitudes from ferroresonance involving grounded-wye padmount transformers on five leg cores can exceed 2.5 p.u. Underground cable lengths on the order of a few hundred feet are sufficient to create crest voltages of this severity. Self-ferroresonance previously was thought to not occur with these transformers, but more recent testing has shown moderate overvoltages in 24.9Y/14.4 kV and 34.5Y/19.9 kV units for switching at the transformer terminals (Walling et al., [B130]).

Provided sufficient capacitance, compared to the transformer characteristics, is present and the transformer is virtually unloaded (load less than a few percent), the ferroresonant overvoltage can persist for as long as the open-phase condition continues. In practice, the open-phase condition is usually the result of intentional switching by the utility, or is due to the operation of a protective device such as a fuse. In the case of intentional phase-by-phase switching of cutouts or load-break elbows, the overvoltages are present until the switching of the last phase is completed. Single-phase protective device (e.g., fuse) operations can result in the open-phase condition being present for an extended period of time. For ferroresonance to be present, however, there should not be a permanent fault on the opened phase and the transformer should be virtually unloaded on the associated phase(s).

Ferroresonant overvoltages can result in arrester failure. The ferroresonant circuit, however, is a high-impedance source and gapless metal-oxide arresters limit the voltage while discharging relatively small currents (Walling et al., [B131]). Consequently, accumulation of energy is usually relatively slow and an arrester can often withstand exposure to ferroresonant overvoltages for a period of minutes or longer (Short, Burke, and Mancao [B119], and Walling et al., [B131]). Arrester TOV curves are based on application of a strong power-frequency voltage source and do not accurately reflect the ability of metal-oxide surge arresters to withstand ferroresonant overvoltage duty. If the valve elements of an arrester are raised to an excessive temperature by ferroresonant overvoltage exposure, arrester failure is not apparent until the open phase, to which the arrester is connected, is reclosed into the low-impedance system source.

In many cases, the arrester is not overheated by ferroresonance during the brief time required to complete a switching operation. Also, where an arrester has the ability to dissipate the heat to the ambient without an excessive metal-oxide temperature rise, the arrester may survive indefinite exposure to the ferroresonance. With due consideration of the ferroresonant circuit and arrester thermal characteristics, metal-oxide arresters can provide a means for short-term or extended duration limitation of ferroresonant overvoltages in situations where the ferroresonance cannot be easily avoided (Walling et al., [B131]).

6.4.5 Overvoltages caused by backfeed

6.4.5.1 Ungrounded wye-delta banks

Ungrounded wye-delta banks are particularly susceptible to ferroresonant overvoltages. On the other hand, ungrounded wye-delta banks have the advantage that, when both single- and three-phase loads need to be serviced, different impedance transformers can be used in the three-phase bank. Zero-sequence currents are eliminated in the primary, particularly during fault conditions.

Ungrounded wye-delta banks present an unusual condition for metal-oxide surge arresters installed on the open phase of the wye with an unbalanced load on the delta secondary. As shown in Annex E, voltages of 2.7 p.u., high enough to force the normally applied arrester into thermal runaway, can exist on the open primary by feedback from the secondary. This condition can occur if a three-phase secondary load is removed during work on the system, leaving a single-phase load connected for lighting, refrigeration, etc. Rather than installing higher rated metal-oxide arresters on these wye-delta banks and thereby jeopardizing equipment protection, the following practices are recommended:

- a) Balance the load so that the load on each phase of the delta is no more than four times that on each of the other two phases. If nearly balanced three-phase loads are served from a transformer, it is not subject to this overvoltage.
- b) Ground the wye. This would eliminate the problem, but may raise concerns for serving unbalanced three-phase loads and single-phase loads. It also provides a path for zero-sequence currents that may be a problem.
- c) Close the disconnect last on the phase that has the largest single-phase load.
- d) Apply a grounding resistor or reactor in the neutral of the ungrounded-wye windings.
- e) Close a neutral grounding switch during the energization of the phases and open it after all three phases have been closed. The neutral switch has to be able to clear the unbalanced load current that may be flowing.
- f) Place arresters on the source side, instead of the load side, of circuit interrupters to prevent arrester damage due to the backfeed overvoltage. This connection, however, does not provide protection of the bank from ferroresonant overvoltage (refers to 6.4.4) or the backfeed overvoltage described here. This connection may also reduce the lightning overvoltage protection due to longer lead lengths (refer to 6.7.1).

6.4.5.2 Dual-transformer station

Annex F shows a situation that can lead to overvoltage on surge arresters in dual-transformer substations. Although a single line-to-ground fault on the primary of one transformer is isolated from the HV supply system, the faulted circuit is still energized back through the transformer from the distribution system by the normally closed bus breaker. Surge arresters on the unfaulted phases at the fault location, therefore, see an overvoltage of 1.73 p.u. because the neutral voltage on the faulted primary is shifted until this breaker is opened.

6.4.6 Distribution system neutral conductors and grounding effect on overvoltage magnitude

A study on the effect of neutral wire size on distribution system overvoltages, annex A of Kershaw Jr., Gaibrois, and Stump [B81], shows that values as high as 1.68 p.u. can occur on unfaulted phases if the neutral conductor is inadequately grounded throughout the system and the wire size is too small. Although this would be unusual, it can occur when converting an older ungrounded system and emphasizes the importance of good grounding practices during construction and maintenance.

When ground resistivity or system conversion results in a system that is not effectively grounded, special attention has to be given to the TOV capability of the metal-oxide surge arrester. A higher duty cycle and MCOV rating may be required. It may be better to rebuild part of the system to bring it up to state-of-the-art technology. If the arrester duty cycle and MCOV rating are increased, the insulation coordination of the system has to be rechecked to assure that the required protective margins are still met.

6.4.7 Regulated voltage

Special attention has to be given to the actual voltage on distribution systems. Standards on voltage levels apply only at the metering point of the customer. Out on the distribution circuit, much larger voltage varia-

tions are permitted as long as the voltage at the metering point of the customer is within the standard. A study (Burke, Douglass, and Lawrence [B20]) on a random sample of system voltages found some voltages 17% above nominal. Most voltage studies, until recently, did not take into consideration the mutual coupling effect between phases as a result of different load currents in the phases. Some three-phase switched capacitor banks sense only single-phase voltage. This can result in capacitor compensation being added to other phases at a time when they are not in need of voltage correction. Arrester MCOV and actual maximum phase-to-ground voltage have to be taken into account when selecting metal-oxide surge arresters for a specific application.

When regulators are used to control system voltage, special care is required to make sure the MCOV rating of metal-oxide surge arresters is not exceeded. For example, stable voltage swings may result when three single-phase voltage regulators are installed at an unstable system neutral point. When three single-phase regulators are connected wye, the controls measure line-to-neutral voltage so that, if the neutral is permitted to float, there is no stable reference point from which to excite the regulator controls. Each regulator control will measure this shift and try to correct it. The operation of regulators under these conditions will be erratic.

6.4.8 Non-effectively grounded systems

A system is considered to be non-effectively grounded when the coefficient of grounding exceeds 80%. This value can be exceeded when the system X_0/X_1 ratio is negative or is positive and ≥ 3 or, the system R_0/X_1 ratio is positive and ≥ 1 . Since the temporary overvoltage magnitude for a non-effectively grounded system exceeds that of an effectively grounded system during ground faults, it is common to use a higher voltage rated arrester for the non-effectively grounded system.

While effectively grounded systems can typically use an arrester with an MCOV rating of about 80% of the system phase-phase voltage, non-effectively grounded systems often require an arrester whose MCOV rating is about 100% of the system phase-phase voltage where ground faults are removed within a few seconds. Such systems might include three- or four-wire systems with the neutral grounded either directly or through a low inductance or resistance. Users should review their system grounding conditions to determine the actual system coefficient of grounding and maximum fault clearing time and compare this against the TOV capability of the intended arrester. There may also be seasonal effects. Systems which may be effectively grounded when there is a high soil water content may change to a non-effectively grounded condition as the water content is reduced. Worst case temporary overvoltage conditions and maximum fault clearing times should be reviewed to determine the appropriate arrester MCOV (see Figure 12). Ungrounded delta systems and systems with high-resistance grounding and neutral grounding are typically not effectively grounded. If ground faults are not cleared rapidly, such systems may require arresters with a duty-cycle rating of about 125% of the system phase-phase voltage to withstand the relatively high overvoltage resulting from neutral shift. High impedance arcing faults which occur on an ungrounded system can result in excessively high overvoltages, greater than phase-phase voltage, and may result in arrester failure.

6.5 Insulation coordination

Distribution system insulation coordination is normally based on the following protective margins:

$$PM_{L1} = [CWW / (FOW + Ldi / dt) - 1] 100\%$$

$$PM_{L1} = [(BIL / LPL) - 1] 100(\%)$$

where

| | |
|-----------|---|
| PM_{L1} | is FOW Protective Margin (in percent) |
| PM_{L2} | is Full Wave Protective Margin (in percent) |
| CWW | is Chopped Wave Withstand of protected equipment (in kilovolts) |
| FOW | is Front-of-Wave protective level of arrester (in kilovolts) |
| BIL | is Basic Impulse Insulation Level of protected equipment (in kilovolts) |
| LPL | is Lightning Protective Level (in kilovolts) |
| Ldi/dt | is connecting lead wire voltage drop (in kilovolts)—see 6.7.1 |

For oil-filled, air, and solid (inorganic) insulation, CWW can be assumed to be $1.15 \times BIL$; for dry-type (organic) insulation, the CWW is assumed to be the same as the BIL.

The general rule is that PM_{L1} and PM_{L2} both have to be at least 20%. However, experience with surge protection of distribution systems (15 kV and less) has been gained with protective margins well above 20%, usually exceeding 50%. Separation effects (SE) are minimized by connecting distribution arresters directly across overhead equipment insulation.

The discharge voltage of an arrester is greater for the less frequent high-current lightning surges, and increases with higher rates of rise of the lightning current (Sabot et al., [B116]). It is the usual practice to select a reference value of discharge current that will be exceeded infrequently. The discharge voltage at this reference level is used to calculate PM_{L2} . Obviously, the selection of a higher reference level will result in a smaller PM_{L2} for a given BIL.

There is no universally accepted surge-current level on which to base insulation coordination. Currents in the 10 to 20 kA range are often used, 10 kA for low flash density areas, 20 kA (or more) for high flash density areas. The range of arrester discharge voltage values at 10 kA (8/20 wave) is shown in columns 7 and 8 of Table 6. Reference currents above 20 kA can be considered. This will account for lightning currents with faster rates of rise than the standard test waves used to make discharge voltage measurements (Auer and Schultz [B8]) or where severe lightning is common. (Arrester discharge voltage values can be obtained from the manufacturer for currents greater than 20 kA). Strict application of the 20% margin rule will then favor the use of arresters with low discharge voltages. PM_{L2} includes an allowance for the voltage developed across arrester connecting lead wires (see 6.7.1). The arrester discharge voltage characteristic to be used for insulation coordination purposes is the total of the arrester discharge voltage plus the connecting lead wire voltage. Maintaining lead wire lengths to be as short as possible is particularly important when protecting underground systems (see 6.8.4).

6.6 Protection of distribution lines

Distribution arresters are frequently used, instead of overhead shield wires, to protect the distribution lines from flashover resulting from lightning strikes.

The protection of overhead distribution circuits has been studied, and reports (Task Force Report [B122]; Task Force Report [B123]) have been made regarding the degree of protection afforded by gapped silicon-

carbide surge arresters. These reports indicate the number of line flashovers to be expected as a function of arrester spacing along the line, line design, and keraunic level. Similar studies have not yet been made based on the operational characteristics of metal-oxide arresters, but the application of metal-oxide surge arresters should result in an equal or possibly lower, number of outages per circuit mile than that expected using silicon-carbide arresters (Owen [B106]). Arrester ratings employed for circuit protection are the same as those used for equipment protection at the given line voltage level.

6.7 Arrester connections

6.7.1 Effect of connecting lead wires

The discharge of lightning currents through the inductance of connecting lead wires produces a voltage that adds to the arrester discharge voltage. Lead length includes the ground lead length as well as the primary lead. The total length of these leads is measured from the point at which the arrester line connection is made to the point where interconnection is made between the arrester ground lead and the protected equipment ground lead, excluding the arrester length.

The inductance per unit length of the lead is a complex function of the lead geometry. The effect of lead conductor diameter is relatively minor. Tests indicate that an inductance of $0.4 \mu\text{H}/\text{ft}$ ($1.3 \mu\text{H}/\text{m}$) is representative of typical applications. The inductance per length of conductor for a coiled lead will be much greater than this value. For this reason, arrester leads should not be coiled.

Recorded lightning data indicates that the mean rate of current rise is $24.3 \text{ kA}/\mu\text{s}$ for first strokes and $39.9 \text{ kA}/\mu\text{s}$ for subsequent strokes in a lightning flash (AIEE Committee Report [B1]). The current discharged by a surge arrester may be the entire stroke current if it terminates on the line very close to the arrester location, or it may be a portion of the total stroke current. A lightning stroke terminating more than one span away from any arrester location is likely to result in line flashover. Flashover does not eliminate significant conduction in nearby arresters. This is because a portion of the stroke current will be carried away from the struck location on both the phase and neutral conductors of a multigrounded distribution line. A significant portion of the stroke current can pass through arresters located within several spans of the line flashover.

The typical current rate-of-rise for distribution insulation coordination is one-half of the mean subsequent lightning stroke current rate-of-rise, or $20 \text{ kA}/\mu\text{s}$. The product of the current rate-of-rise times the total lead inductance is the lead voltage. The lead voltage adds to the arrester discharge voltage only during the rise of the discharge current. The time duration that the protected device is exposed to the sum of the lead voltage and arrester discharge voltage is the rise-time of the current. In strokes where the rate-of-rise is high, the front time will be a maximum of $1\text{--}2 \mu\text{s}$. Therefore, it is appropriate to coordinate the sum of the lead voltage and arrester discharge voltage with the chopped-wave withstand of the protected device. The discharge voltage, without lead length effects, should also be coordinated with the full-wave withstand of the protected device.

Lead length effects can have a substantial role in distribution insulation coordination. This is illustrated in the following example of a typical 10 kV duty cycle voltage rated arrester with a 1.83 m (6 ft) total lead length protecting a 95 kV BIL transformer:

Assumed arrester characteristics:

- 37 kV lightning protective level ($8 \times 20 \mu\text{s}$, 10 kA)
- 41 kV front of wave protective level

Insulation withstand:

- 95 kV full wave withstand
- 110 kV chopped wave withstand

The calculated protective margins are:

$$PM_{L1} = \left[\left(\frac{CWW}{FOW + 20 \left(\frac{1.3 \mu H}{m} \right) m} \right) - 1 \right] 100$$

$$PM_{L1} = \left[\left(\frac{110}{41 + 20 \left(\frac{1.3 \mu H}{m} \right) 1.83} \right) - 1 \right] 100 = 24\%$$

$$PM_{L2} = \left(\left[\frac{BIL}{LPL} \right] - 1 \right) 100$$

$$PM_{L2} = \left(\left[\frac{95}{37} \right] - 1 \right) 100 = 156\%$$

6.7.2 Effect of separation distance

Distribution arresters are often used to protect a single piece of equipment and therefore should be connected as close as possible to that equipment. This reduces separation effects (see 4.5 and Annex C). Arresters used to protect equipment should not be installed at locations a pole-span away from the equipment to be protected. This is particularly important where only one arrester is used to protect equipment (a transformer) that is connected to a line that runs in two directions from the tap point. In effect, surges approaching from the unprotected side can exceed the protective level of the arrester, diminishing the effectiveness of the arrester, and equipment failure may result. Surges approaching from the arrester side are limited by arrester action, but the separation effect can be very high.

6.7.3 Location of arresters with respect to equipment fuses

Locating an arrester on the source side of a fused cutout often results in very long arrester lead lengths. As presented in 6.7.1, excess lead length can severely impair equipment protection, particularly at the higher distribution voltage classes. Location of the fuse ahead of the arrester, however, requires that the fuse carries arrester discharge current. Nuisance fuse blowing or fuse damage can result. Experience has shown that nuisance fuse blowing is generally limited to fuse links smaller than 15T or 20K.

Some utilities coordinate fuses for transformer overload protection, others consider only coordination with upstream protection. Fuses selected to provide overload protection are often small and are vulnerable to nuisance fuse blowing. Alternatives that allow both overload protection of small transformers and avoid excess arrester lead lengths are

- Dual-element fuses, which have both low-current sensitivity for overload protection and immunity from lightning discharge currents, applied in cutouts ahead of tank-mounted or internal arresters.
- Internal fuses located between the transformer winding and a tank-mounted or internal arrester.

Three-phase transformer banks with ungrounded primary connections are subject to overvoltages generated within the bank when one or two phases are disconnected from the source. These overvoltages can be the result of ferroresonance involving the internal capacitance of the transformers (refer to 6.4.4), or in the case of ungrounded wye-delta banks only, the overvoltage can be the result of feedback from the secondary (refer to 6.4.5.1). Location of the arrester on the source side of the fuse can leave the bank unprotected from these

overvoltages if the bank is open-phased by fuse operation or cutout operation. Transformer insulation failure has been observed due to ferroresonant overvoltages. Location on the transformer side of the circuit interrupter provides transformer protection, but there is a risk of arrester failure. This risk is primarily limited to ungrounded wye-delta banks with unbalanced secondary loads.

6.7.4 Interconnection of grounds

See Figures 13 and 14.




Figure 13—Arrester protection with solid interconnection




Figure 14—Arrester protection with interconnection through gaps

6.7.4.1 Primary and secondary ground

It is recommended that primary and secondary grounds of the distribution transformer be interconnected with the arrester ground terminal.

6.7.4.2 Tanks, hardware, and support structures

Where possible and where local regulations permit, ground connections should be made to the tanks of transformers, reclosers, capacitor support frames, and all hardware associated with the protected equipment (Figure 13).

6.7.4.3 Protective gaps

Where regulations do not allow grounding of equipment support structures, protective gaps should be connected between the arrester ground terminal and the structure. Transformer mounted arresters are grounded to the transformer tank, and the tank can be isolated from ground by inserting the protective gap between the transformer tank and ground (Figure 14).

6.7.4.4 Clearances of arresters to energized conductors and equipment and to grounds

For proper insulation coordination, distribution arresters should be installed to maintain, as a minimum, the clearances listed in Table 10. Regulations or other considerations may dictate larger clearances in exposed locations. The listed clearances are suitable for arresters in metal enclosures.

Table 10—Recommended minimum clearances

| Arrester duty cycle voltage rating (kV rms) | Surge arrester housing BIL (kV crest) ^a | Recommended minimum clearances [in. (mm)] ^b | |
|---|--|--|----------------|
| | | To grounds | Between phases |
| 3 | 45 | 1-3/4 (45) | 2 (51) |
| 6 | 60 | 2-3/4 (70) | 3-1/4 (83) |
| 9 | 75 | 4 (102) | 4-3/4 (121) |
| 10 | 75 | 4 (102) | 4-3/4 (121) |
| 12 | 85 | 4-3/4 (121) | 5-1/2 (140) |
| 15 | 95 | 5-1/2 (140) | 6-1/2 (165) |
| 18 | 125 | 8 (203) | 9 (229) |
| 21 | 125 | 8 (203) | 9 (229) |
| 24 | 150 | 9-1/2 (241) | 11 (279) |
| 27 | 150 | 9-1/2 (241) | 11 (279) |
| 30 | 150 | 9-1/2 (241) | 11 (279) |

^aClearances measured from metal parts of arrester line terminal and dictated by minimum flashover to maintain BIL in accordance with IEEE Std C62.11-1993, and to allow for the bias effect of 60 Hz voltage between adjacent phases. Air insulation between arrester wall(s) or between arresters is assumed. Minimum clearances required between bottom stud on arrester and enclosure floor need be only that required to install ground connection and to provide sufficient space for free operation of the arrester disconnecter, if used.

^b1.2/50 full-wave BIL per Table 2 in IEEE Std C62.11-1993.

6.8 Special applications

6.8.1 Protection of capacitor banks

Pole-mounted shunt capacitor banks may be protected by line-to-ground connection of arresters mounted on the same pole as the bank. Connections should be as outlined in 6.7 (refer also to 5.11). The ratings of arresters used are usually the same as used elsewhere on the system.

Capacitor banks connected grounded-wye can be charged to high voltages by lightning currents. When protected by metal-oxide surge arresters, these capacitor banks can only be charged to the protective level of the arrester. The stroke current will then be shared by the arrester and bank for the duration of the stroke current. At the completion of the stroke current, the arrester will cease to conduct, leaving some charge on the capacitors. As a result, energy dissipated by the arrester may be less than it would have been for a silicon-carbide arrester.

Arrester operation on ungrounded banks is usually caused by a high transient voltage transmitted from the line to the bank, developing between neutral and ground, such that relatively little of the transient energy is added to the stored energy in the capacitors. Therefore, no special high-energy capability is required for arresters protecting ungrounded capacitor banks against lightning surges.

If a capacitor bank is switched, arresters having high energy absorption capability may be required regardless of the circuit configuration. Surge arresters applied to switched capacitor banks can be exposed to high-energy surges if restriking of the switching device occurs when the bank is being de-energized. In the case of an ungrounded capacitor bank, a two-phase restrike can cause excessive current to flow in both arresters associated with the restriking phases. Arresters on either side of the switching device can experience high-energy switching transients. The arrester manufacturer should be consulted for aid in selecting arresters suitable for this duty.

6.8.2 Protection of switches, reclosers, sectionalizers, etc.

Switches operated in the open position should be protected by arresters at both sides of the switch. The special case of switches in an underground system is covered in 6.8.4.

Reclosers are best protected by installing arresters on both the source and load side. However, some reclosers are designed with a built-in bypass protector across the series coils. A fair degree of protection may therefore be obtained, assuming normal operation of the reclosers in the closed position, by applying one arrester from line to ground on the source side. However, it should be recognized that there is some risk of lightning damage when the recloser is open for any reason.

The arresters usually have the same rating as those used in other parts of the system. Connections should follow the recommendations outlined in 6.7.

6.8.3 Protection of regulators and series apparatus

6.8.3.1 Line voltage regulators

Voltage regulators connected to exposed circuits should be protected on both line and load sides with the same arresters used on other distribution apparatus. For the most effective protection, the arrester should be mounted on the tank with the arrester ground connected to the tank. The series winding is usually protected with an arrester selected by the regulator manufacturer and connected between the source and load bushings, or on winding terminals inside the tank.

6.8.3.2 Bus voltage regulators

Bus voltage regulators at substations are often protected by station- or intermediate-class arresters on the substation bus or on the substation transformer low-voltage bushings, and by distribution arresters adjacent to the substation on the outgoing feeders. The series winding is protected by arresters selected by the manufacturer of the regulator. The series winding arrester can get inordinate operating duty because a disproportionate share of the incoming current is discharged by the station arrester as a result of its low discharge voltage characteristic. In order to prevent premature failure of the series winding, it is recommended that at least intermediate arresters with lower discharge voltage characteristics be substituted for the distribution arresters on the outgoing line terminals.

6.8.3.3 Series current-limiting reactors

Unless coil protection is built into a current-limiting reactor by the manufacturer, an arrester connected from terminal to terminal can be installed to prevent overvoltages due to incoming surges. In addition, an arrester connected between line and ground should be installed on the source side of the reactor. In all cases, the reactor manufacturer should be consulted.

6.8.3.4 Autotransformers

The remarks on series windings of regulators are generally applicable to autotransformers where the voltage across the series winding is small compared to the common winding ($< 25\%$). For other applications, arresters at the high-voltage and low-voltage terminals with the arrester interconnection to the transformer tank will be adequate.

6.8.4 Protection of equipment on underground systems (including cables)

Underground sections of the distribution system usually take the form of relatively short cable runs to transformers or that of long loops that are open at the center. For longer cable lengths, equipment such as transformers or switchgear is installed along the entire cable length. In either case, the system can basically be described as a length of cable terminated by an open point.

Surge voltages enter the underground system from the overhead feeder at the riser pole. The magnitude of surge voltage entering the cable is limited by the arrester on the riser pole. However, surge voltage in excess of the protective level of the riser pole arresters can occur on the cable and at equipment locations remote from the riser pole because of amplification by reflection from the open point (Owen [B106]).

Most of the problems associated with protection of underground systems result from the practical difficulties involved in locating arresters as close as desired to terminating points or points where substantial changes in surge impedance occur in the underground system. Sometimes, consideration has to be given to the installation of arresters on underground transformers to provide adequate protective margins (Miller and Westrom [B100], Owen [B106], and Owen and Clinkenbeard [B107]). Recent developments in elbow and liquid-immersed arresters make individual equipment protection practical. When it is possible to install arresters at equipment locations, application procedures are similar to those used for protection of overhead equipment. When it is not possible to install arresters at individual equipment locations in the underground system, protection is usually provided by arresters located at the junction of the overhead line conductors and the underground system cables.

For system voltages of 15 kV and below, and where the arrester leads between the overhead line and the cable sheath are short [< 5 ft (1.6 m)], the use of a distribution arrester at the riser pole generally will provide an adequate margin of protection for cable-connected equipment. For 25 kV system voltages, an arrester with lower discharge voltage than a distribution arrester may have to be used. Other possibilities are discussed in (IEEE Working Group Report [B72], and Kershaw Jr. [B78], and Kershaw Jr. [B79]). For 28 kV

and 34.5 kV systems, arresters at the riser pole only will not provide adequate protection, and the use of one or more arresters installed on the cable circuit is necessary.

When arrester protection is provided at the riser pole only, the voltage held at the riser pole by a gapless metal-oxide surge arrester is the sum of the arrester discharge voltage and the inductive voltage drop in the arrester connecting leads (Kershaw Jr. and Clinkenbeard [B80]) (see 6.7.1). This voltage propagates into the cable circuit and can approach double its value on the cable and at connected transformers because of the reflections at points such as open switches and terminating transformers. The following rules (Owen [B106]) are directed toward determining the voltages at terminations to permit the calculation of protective margins:

- a) Assume no attenuation. This assumption becomes conservative for cable lengths greater than 3000 ft (900 m) (Valentine, Dillard, and Clayton [B126]).
- b) Assume the incident voltages will double at open points and terminating transformers.
- c) Assume that a significant number of lightning surges will have faster rise times than the 8 ms used for published discharge voltage characteristics. Discharge voltages can be significantly higher under these conditions.
- d) Use a 10 kA crest surge when considering protection schemes for a shielded system and a 20 kA crest surge for an unshielded system.
- e) Calculate inductive voltage drop in an arrester connecting lead from:

$$\text{Total voltage} = \text{lead length (ft or m)} \times \text{lead inductance (L)} \times \text{rate of rise factor (di/dt)}$$

where

L is 0.4 $\mu\text{H}/\text{ft}$ or 1.3 $\mu\text{H}/\text{m}$, and the rate of rise factor (di/dt) is calculated by dividing the crest current by the time to crest (i.e., di/dt for a 10 kA impulse cresting in 8 μs is 1.25; di/dt for a 10 kA impulse cresting in 1 μs is 10).

The inductive voltage will vary as a function of current magnitude and current impulse rate of rise. At 10 kA with a risetime of 8 μs , the inductive voltage is about .5 kv/ft (1.625 kV/m). Also, at 10 kA, the inductive voltage can be as high as 4 kv/ft (13 kV/m) when the risetime is 1 μs . A 20 kA surge will double the above voltages. Leads should be kept as short as possible. Even with the best arrester at the riser pole, the system will not be protected if the leads are long.

For gapless arresters, compare the doubled sum of the FOW protective level and the connecting lead voltage with CWW (assumed to be 1.15 BIL) for liquid-filled transformers and with BIL for dry-type transformers and cables.

For gapped arresters, compare the greater of:

Doubled FOW protective level (if determined by sparkover); or
Doubled sum of FOW protective level (if determined by discharge voltage) and connecting lead voltage with CWW for liquid-filled transformers and with BIL for dry-type transformers and cables.

For both gapless and gapped arresters, compare the doubled sum of the discharge voltage, at the assumed discharge current, and the connecting lead voltage with transformer and cable BIL. Then, using a recommended protective margin of 20%

Oil insulation: $\text{CWW} \geq 1.2 \times 2 \times \text{FOW}$
Dry insulation: $\text{BIL} \geq 1.2 \times 2 \times \text{FOW}$
Both insulations: $\text{BIL} \geq 1.2 \times 2 \times \text{LPL}$

- f) Example: A 10 kV riser pole type arrester is chosen to protect a 15 kV class underground distribution system. The BIL of the system is equal to 95 kV. Assume that the arrester has 1.52 m of lead and that the current surge through the arrester at the riser pole is 10 kA with a 1 μs rise time

$$\text{Maximum surge voltage} = 2 (\text{FOW} + 1.52 \text{ m (L di/dt)})$$

Using a common value for the FOW protective level, this becomes

$$\text{Maximum surge voltage} = 2 (29 \text{ kV} + 1.52 \text{ m} (13 \text{ kV/m})) = 98 \text{ kV}$$

This shows that even on a 15 kV system, the insulation may not be adequately protected with an arrester at the riser pole only.

Another protection method is to use an arrester at the riser pole and a second arrester at the remote end of the cable, which is a reflection point for the traveling wave. The voltage at the reflection point will be limited to the discharge voltage of the remote arrester at a current of less than one-fourth of the current through the riser pole arrester (unless the cable is very short) (Miller and Westrom [B100], Owen and Clinkenbeard [B107]). Because the remote arrester appears as an open circuit until it becomes conductive, it permits the reflection of a portion of the incoming wavefront, which is then superimposed on the approaching surge voltage wave. Therefore, the voltage at intermediate points in the cable circuit will usually be higher than at either end. The maximum voltage at intermediate points will be the protective level of the riser pole arrester (discharge voltage plus lead voltage drop), plus some fraction of the discharge voltage of the reflection point arrester. A conservative number to use for coordination is the discharge voltage of the riser pole arrester plus one half of the 1.5 kA discharge voltage of the reflection point arrester. (The 1.5 kA value is obtainable from the published literature of the manufacturer and, because of the nonlinear characteristics of metal-oxide valve elements, will yield a value very close to one-fourth of any assumed current through the riser pole arrester.) A computer simulation of this effect can be found in Burke, Smith, and Sakshaug [B21].

The effectiveness of the previous method can be substantially improved by installing a single arrester at an equipment location about 300 ft (100 m) or more upstream from the open-point termination. This midcircuit arrester will suppress the reflected surge as it is being superimposed on the incoming surge voltage wave. A significant distance is necessary for recombination of surge voltages with longer rise times (Lat [B85]). The protective level between the riser pole and the midcircuit arrester will be the greater of the protective level of the riser pole arrester or the discharge voltage of the reflection-point arrester. The protective level in the cable between the reflection-point arrester and the midcircuit arrester is as in the previous example. Equipment connected between the reflection-point arrester and the midcircuit arrester may need individual arrester protection.

The most effective protection method is to install arresters at the riser pole, open point, and at each underground equipment location. The voltage on each piece of equipment will be held to the low-current discharge voltage of its arrester, and only the section of cable between the open point and the first upstream arrester will see a higher surge voltage.

The surge energy, or duty, discharged by an arrester installed on an underground system is controlled by the exposure of the arrester at the riser pole and is usually a small fraction of the energy discharged by the riser pole arrester. For arresters with identical discharge voltage characteristics, the arrester in the cable system will discharge only about 20% of the total surge current (Owen and Clinkenbeard [B107]). The use of arresters at the riser pole with lower discharge voltage, riser pole type, or intermediate class will further reduce the magnitude of surge current discharged by the underground arresters by themselves discharging a larger portion of the surge current.

When control of transients to lower values is desired to prolong cable life, arresters with lower discharge voltage characteristics, or possibly elbow or liquid-immersed arresters, can be used. Although not yet proven effective, such applications have been made when “treeing” has been suspected of decreasing cable life.

Arresters installed directly on underground equipment may be either elbow arresters (for dead front equipment) or base- or bracket-mounted arresters (if equipment has mounting provisions). Also, liquid-immersed arresters are available mounted inside the transformers.

6.8.5 Contaminated atmospheres

Surveys (IEEE Working Group Report [B70]) have shown that failures of gapped silicon-carbide arresters due to operation in contaminated atmospheres are quite rare. Because metal-oxide distribution arresters are usually constructed without internal gaps, internally induced failures of these arresters due to external contamination should not be a factor. However, external failure (flashover) of the arrester housing may occur from the combined effect of accumulation of contaminants on the arrester and conditions of wet snow, frost, light rain, or fog.

The usual solution is periodic cleaning of the housing. In a few cases, application of nonconducting, non-tracking, water-repellent greases to the insulating surfaces has been used. Overinsulating the arrester housings has also been used effectively to reduce the effects of external contamination.

6.8.6 Low side (secondary) surges

Surges impressed on the secondary terminals of transformers can result in failure of the primary or secondary winding insulation.

Relatively small surge currents into the center tap of 120/240 V secondary windings can induce high primary winding layer-to-layer voltages. This secondary surge phenomenon is a major cause of distribution transformer failures (IEEE Transformer Committee Task Force Report [B64]). Interlaced transformer windings are believed to be less susceptible to this failure mode. Adequate secondary-side surge protection applied on non-interlaced transformers is believed to provide the same level of protection. There has been much industry debate regarding the impact of secondary surges on interlaced and non-interlaced distribution transformer designs. The phenomena are discussed in detail in Dugan and Smith [B32] and IEEE Transformer Committee Task Force Report [B64].

Lightning strikes to either the primary or the secondary system can produce secondary surges. Strikes to the primary system elevate the transformer secondary neutral potential above the neutral potential at the customer service, forcing surge current into the transformer. The configuration of the secondary system will affect the magnitude and characteristics of surges impressed on the transformer secondary. The relative impedances of customer service ground and transformer ground have a substantial effect on secondary surge current magnitudes. Open wire service drops allow greater secondary surge currents to flow compared to a triplex service drop, due to decreased mutual coupling between the conductors.

Secondary surges can also occur as a result of direct strokes to the secondary service conductors or the connected load. Field coupling and ground potential rise will also induce secondary surges if lightning strikes nearby objects such as trees and structures. Surges impressed on the primary winding of the transformer also are reflected to the secondary by inductive and capacitive coupling, although this is not usually of concern to the integrity of the transformer secondary winding insulator (Barker et al., [B11], Dugan and Smith [B32], and IEEE Transformer Committee Task Force Report [B64]).

6.8.7 Protection of transformers from low side surges

Secondary winding protection can be achieved through the use of metal-oxide arresters or spark gaps located at the secondary terminals of the transformer (connected between each leg and neutral). The BIL of distribution secondary windings is 30 kV according to IEEE Std C57.12.00-1993, so it is relatively easy to coordinate the insulation withstand with the surge arrester protective level. Transformers on underground distribution system are just as vulnerable to secondary surges as overhead transformers and are also candidates for secondary arrester protection.

Several references (Dugan, Kershaw, and Smith [B31], Dugan and Smith [B32], and IEEE Transformer Committee Task Force Report [B64]) recommend using either spark gaps or metal-oxide secondary arresters with a protective level of 4 to 6 kV for the transformer secondary in cases where the transformer may be

exposed to a high level of surge activity (see Figure 15). There is considerable controversy on the need for secondary arresters. Some industry experts feel that transformers with interlaced secondary windings do not need secondary arresters to maintain reasonable service reliability (McMillen, Schoendube, and Kaufmann [B98]). Since the transformer is located in an exposed environment relative to typical indoor or customer load applications, a surge protective device which is suitable for indoor or customer service applications may (and will likely) not have sufficient energy handling capability for an outdoor distribution transformer application. Only suitable secondary devices which meet the requirements per IEEE Std C62.11-1993 should be utilized at the transformer. The surge arrester utilized at the transformer should have an MCOV and TOV capability that exceeds the maximum sustained and/or temporary secondary voltages which can be expected at the transformer.




Figure 15—Typical transformer secondary surge protection

Where possible, the transformer secondary neutral terminal should be bonded to the primary neutral which also should be bonded to the tank. This is very important because severe voltage potentials can develop between the secondary and primary windings during lightning surges which can cause transformer failure even though all windings have arresters connected across the terminals.

Studies suggest that the use of secondary arresters at the distribution transformer, while quite effective in protecting the transformer, may actually increase the surge voltage that reaches the customer service connection (Dugan and Smith [B32] and IEEE Transformer Committee Task Force Report [B64]). As a result of this phenomena, some utilities install secondary protection at both the distribution transformer and the customer service entrance. Note that a secondary arrester at the customer service would generally have a much lower protective level than that which is recommended for the transformer since customer appliances can be damaged at surge voltages much less than 4 kV.

6.9 Isolation

6.9.1 Disconnectors and external gaps

Distribution arresters are sometimes furnished with external gaps that are placed between the line lead and the arrester terminal. Other arresters may be provided with disconnectors, which are usually mounted on the ground terminal of the arrester and connected between the ground terminal and the ground lead. The purpose of both devices is to isolate a failed arrester from the distribution system. In each case, a system fuse, recloser, or circuit breaker may operate to clear the fault if the arrester fails.

In the case of an arrester equipped with an external isolating gap, a failed, but intact, arrester remains connected to the system and continues to provide some measure of protection for the transformer on subsequent lightning surges. However, detection of a failed arrester from ground level may be difficult, but close inspection will usually reveal a burn mark or bubble of metal on the arcing horn from the passage of an abnormally high power-frequency current.

In the case of an arrester equipped with a disconnector, operation of the disconnector physically separates the arrester ground connection from the failed arrester and thus gives a visual indication of failure. Surge protection for the transformer is no longer provided. Care has to be taken to provide enough clearance to ensure that the separated ground lead is not thrown into an energized conductor. The ground lead should be flexible enough to allow the disconnector to separate from the arrester.

6.9.2 Current-limiting fuses

Current-limiting fuses are used to protect and isolate faulted distribution equipment as well as some single- and three-phase laterals. The principal advantage of these fuses is their ability to limit the let-through fault current (fault energy).

Since some current-limiting fuses can generate high arc voltage with peak magnitudes exceeding system voltage, care has to be exercised to ensure proper coordination between the fuse and the source side arrester. Although experience with these applications for metal-oxide arresters is limited, distribution arrester damage as a result of current-limiting fuse operation has not been an application problem. In the event that arrester damage does occur, an arrester with a higher MCOV rating than would normally be applied could be required, i.e., conduction would start at higher arc voltages, reducing the number of arrester operations and, therefore, reducing the duty on the arrester. Should conduction occur, the energy (joules/kilovolts of rating) dissipated by the arrester would be reduced.

Additional information on the effects of current-limiting fuses can be found in (IEEE Switchgear Committee and Surge Protective Devices Committee Working Group [B63], Kershaw Jr., Huber, and Hassler [B82], and Olive Jr. and Westrom [B104]).

Annex A

(informative)

Lightning flashes, lightning stroke currents, traveling waves, and station shielding

A.1 Lightning flashes and strokes

A lightning flash is composed of one or more lightning strokes, each flash having three strokes on the average. In general, the first stroke has a higher current but the rate of rise is less steep than subsequent strokes. To determine the incoming surge voltage to a station for analyzing protection of station equipment, usually only the surge voltages caused by the first stroke are considered. However, to determine the energy discharged by an arrester, subsequent strokes should also be considered.

As shown in Anderson and Eriksson [B5] and Berger, Anderson, and Kroninger [B13], the lightning stroke parameters for negative downward strokes are considered to be approximated by Log-Normal distribution, whose probability density function is

$$f(x) = \frac{1}{xB\sqrt{2\pi}} e^{-\frac{1}{2} \left[\frac{\ln \frac{x}{M}}{B} \right]^2} \quad (\text{A.1})$$

where

- $f(x)$ is probability density function;
- M is median value of distribution ;
- B is logarithmic standard deviation; and
- P is the correlation coefficient.

The measurements of Berger, Anderson, and Kroninger [B13] show the following values of M and B for first and subsequent strokes:

Table A.1 – First stroke statistics

| Parameter | M | B | P |
|---------------------------------|------|------|------|
| Crest current (kA) | 31.1 | 0.48 | 0.38 |
| Maximum steepness (kA/ μ s) | 24.4 | 0.60 | 0.38 |
| Front (μ s) | 1.28 | 0.61 | — |
| Tail (μ s) | 77.5 | 0.58 | — |

Table A.2—Subsequent stroke statistics

| Parameter | <i>M</i> | <i>B</i> | <i>P</i> |
|---------------------------|----------|----------|----------|
| Crest current (kA) | 12.3 | 0.53 | 0.56 |
| Maximum steepness (kA/μs) | 39.9 | 0.85 | 0.56 |
| Front (μs) | 0.31 | 0.71 | — |
| Tail (μs) | 30.2 | 0.93 | — |

As noted, the steepness and crest current are correlated; the correlation coefficient is denoted by *P*. The front is derived on a statistical basis from the other two quantities and the correlation coefficient.

The first-stroke crest current data in the above table obtained by Berger was combined with other data. The resultant distribution is piecewise Log-Normal whose parameters are

| Range | <i>M</i> | <i>B</i> |
|-----------------|----------|----------|
| 20 kA and below | 61 | 1.33 |
| 20 kA and above | 33.3 | 0.605 |

The distribution may also be approximated (Anderson [B4]) by the equation

$$P(I_S) = \frac{100}{1 + \left[\frac{I_S}{31}\right]^{2.6}} \quad (\text{A.2})$$

where

P(I_S) is probability of peak current that is equal to or exceeds *I_S* (in percent)
I_S is peak first-stroke current (in kiloamperes)

The lightning severity within a specific area is generally specified by the ground flash density, *N_g*, in flashes per kilometer squared. However, at present within the United States, data on the average *N_g* are not generally available, and the lightning severity has to be based on the annual keraunic level or the number of thunderstorm days per year, *T_d*. In the United States, these levels vary from five or less on the West Coast to greater than 100 in Florida, with an average between 35 and 40 (IEEE Working Group Report [B66]). The value of *N_g* may be approximated from *T_d* by the equation

$$N_g = 0.04T_d^{1.25} \quad (\text{A.3})$$

where both *N_g* and *T_d* are average yearly values (Eriksson and Meal [B35]). The coefficients of variation of both *N_g* and *T_d* are large, about 60% for low values of *T_d* and about 30% for high values of *T_d* (Dunsmore et al., [B33]). (An exponent of 1.35 for this equation appears in IEEE Working Group Report [B66]). The 1.25 exponent has since been accepted and approved by the developers of IEEE Working Group Report [B69].

A.2 Arrester currents due to lightning strokes

As a general rule, arrester currents due to lightning strokes are less than the current in the stroke itself. In the case of direct strokes to lines, traveling waves are set up in opposite directions from the point of contact. Flashover of line insulation provides a parallel path to ground through which a portion of the stroke is diverted from the arrester. In the case of strokes to more than one conductor or flashovers between conductors, two or more surge arresters may operate and share the current. Only in the case of a direct stroke very near to the terminal of the arrester, with no flashover occurring before arrester operation, is the arrester called upon to discharge most of the lightning stroke current. The probability of such an occurrence can be significantly reduced by the use of shielding. Evaluation of arrester currents is discussed in 5.4.2.

A.3 Line shielding

Overhead lines may be protected against direct lightning strokes to the conductors by the use of shield (overhead ground) wires, which are positioned to intercept lightning strokes and to direct the stroke current to ground via metallic tower or pole structures. Where wood pole structures are used, low-impedance conductors are used to connect the shield wires to ground.

Almost all direct strokes to line conductors are eliminated by the use of shield wires. When such a direct stroke (shielding failure) does occur, line flashover is almost certain. When a lightning stroke terminates on a shield wire, the stroke current is diverted to ground through the structure-connecting conductors. The impedance of the current path together with ground resistance results in a voltage at the top of the line structure, a portion of which is coupled to the phase conductor. The difference between the phase conductor potential and structure top potential is impressed directly across line insulation and may result in flashover. This type of flashover is called a backflash. The incidence of backflashes is controlled by selection of a proper insulation level; by keeping the structure ground resistance at an acceptably low value; and by providing adequate clearance from conductor to structure ground, conductor to shield wire, and conductor to conductor.

A.4 Station shielding

Procedures analogous to those used for shielding lines may also be used for shielding stations. Shielding methods include overhead ground wires, metallic masts without ground wires, and lightning rods supported from the station structure. These methods may be used in many combinations. Refer to IEEE Std 998-1996.

A.5 Uses of shielding in station protection applications

The purpose of shielding in station applications is to reduce the risk of insulation failure to an acceptable level. In certain applications, this may be achieved by shielding the station alone. In other cases, it may be necessary to shield all incoming lines to the station. As pointed out in A.6, shielding of the lines for a relatively short distance from the station may be all that is required for station protection.

With well-designed shielding, insulation, and grounding systems, the probability of direct strokes to phase conductors is reduced to a low level and the voltages across insulation in the event of strokes to the shielding system are reduced below flashover levels. As a result, arrester discharge currents are reduced, thereby permitting the arrester to provide better protection to equipment insulation (see 5.4.2).

A.6 Traveling waves

Lightning strokes to lines, as well as switching operations, set up traveling waves that move along the line (Bewley [B14]). Crest voltage can double when the wave arrives at the terminals of an open line switch or circuit breaker. A reflected voltage approaching double the incident wave occurs at line-terminating transformers.

As a wave initiated by lightning moves along a line, the crest is reduced and time to crest is increased (Wagner, Gross, and Lloyd [B129]). Effective shielding of a line for as little as one-half mile (800 m) from the station can reduce a high percentage of incoming surges to a tolerable level (Bewley [B14]).

Annex B

(informative)

COG for various conditions




Figure B.1—Coefficients of grounding for $R_1/X_1=0$




Figure B.2—Coefficients of grounding for $R_1/X_1=0.2$




Figure B.3—Coefficients of grounding for $R_1/X_1=0.5$




Figure B.4—Coefficients of grounding for $R_1/X_1=1$




Figure B.5—Coefficients of grounding for $R_1/X_1=2$

NOTE—Parameter values given against Figures B.1 through B.5 indicate limiting values of COG (see 3.13) within the area circumscribed by the curve. Definitions of grounding class or means are indicated in each area. All impedance values have to be on the same kilovoltampere base or in ohms on the same voltage base.

- R_0 is zero-sequence resistance
- R_1 is positive-sequence resistance
- R_2 is negative-sequence resistance
- X_0 is zero-sequence inductive reactance
- X_1 is positive-sequence inductive reactance
- X_2 is negative-sequence inductive reactance
- Z_1 is equal to Z_2

All these quantities are components of the system impedance as seen from the point of fault. See 5.3.2.1.

The effect of fault resistance was taken into account. The resistance that gives the maximum voltage to ground was the value used.

The COG for other values of $Z_1 = Z_2$, can be calculated using the equations in Figure 6. The curves of the figures in Annex B are from IEEE Std C62.92.1-1987. For assumptions in producing these curves, see IEEE Std C62.92.1-1987.

Annex C

(informative)

Calculations of surge arrester separation distances

C.1 Purpose

The purpose of this annex is to provide a relatively simple method for calculating maximum allowable separation distances between surge arresters and equipment to be protected.

C.2 Introduction

The most effective location for any surge arrester is at the terminals of the equipment to be protected. For a variety of reasons, surge arresters sometimes have to be located some distance away from the equipment, or sometimes one set of surge arresters may be used to protect more than one piece of equipment.

Locating a surge arrester remote from the equipment to be protected reduces the protective margin. Depending on a number of factors, the transient voltage at the equipment can easily be more than twice the surge arrester protective level. An analysis has to be made to determine how far a surge arrester can be located away from the equipment and still provide adequate protection.

C.3 Study method

This annex provides a simplified procedure for calculating acceptable separation distances for simple substation configurations. The procedure is illustrated in this annex using two examples as follow:

- a) A substation consisting of a single overhead line terminated with a single transformer
- b) A multiline two-transformer substation

A reduction process is used in the second example to derive a single-line single-transformer substation that can be analyzed as shown in the first example.

The procedure uses the curve shown in Figure C.8, which was generated from studies using the Electromagnetic Transients Program (EMTP). Equation (C.1) represents the curve plotted in Figure C.8 and may be used instead. All the computer studies were made on single-line single-transformer substations with system voltages ranging from 69 kV to 765 kV.

The curve on Figure C.8 is an average curve using the results from EMTP studies as indicated above. The curve includes the effect of the power frequency voltage and is valid for separation distances not exceeding 300 ft (91 m). Transformer surge capacitance values of 1000 pF to 5000 pF do not materially affect the separation effects.

Special studies are required for complex substations using analytical tools such as the EMTP. It is not the intent of this annex to provide guidance in selecting cases for study or in interpreting the results obtained when using the EMTP or other analytical tools.

C.4 Definitions of symbols

The symbols used to calculate surge arrester separation distances are defined in Figure C.1 and as follows:




Figure C.1 – Definition of symbols

- BIL* is Basic Lightning Impulse Insulation Level of the transformer (in kilovolts)
- C* is surge propagation rate in overhead conductors (in feet per microsecond or meters per microsecond)
- CWW* is Chopped Wave Withstand of transformers (in kilovolts) ($1.10 \times BIL$) (IEEE Std C57.12.00-1993; Anderson [B4]; Table 5)
- d'* is conductor length between junction *J* and surge arrester terminal (in feet or meters)
- d''* is conductor length between surge arrester and ground (in feet or meters)
- d* is total surge arrester lead, $d' + d''$ (in feet or meters)
- D* is maximum allowable separation distance between junction *J* and transformer terminal (in feet or meters)
- di/dt* is rate of rise of surge current = $2(S)/Z$ (in kiloamperes per microsecond)
- J* is common point among transformer lead, surge arrester lead, and surged line
- L* is inductance of surge arrester lead *d* (in microhenries) (Assume $0.4 \mu\text{H}/\text{ft}$ or $1.3 \mu\text{H}/\text{m}$)
- N* is number of transmission lines, including the surged line
- S'* is rate of rise of incoming surge on the transmission line ($\text{kV}/\mu\text{s}$) (Use $11 \text{ kV}/\mu\text{s}$ per kV MCOV rating to a maximum of $2000 \text{ kV}/\mu\text{s}$ —IEEE Std C62.11-1993)
- S* is rate of rise of incoming surge at junction *J* (in kilovolts per microsecond)
- V_a* is surge arrester FOW protective level at $0.5 \mu\text{s}$ (in kilovolts) (See Table 1)
- V_{sa}* is voltage across the surge arrester, from junction *J* to ground (in kilovolts)
- V_T* is maximum voltage stress allowable at the transformer (in kilovolts):
V_T is $CWW/1.15$ if time to crest voltage is less than $2 \mu\text{s}$
V_T is $BIL/1.15$ if time to crest voltage is more than $2 \mu\text{s}$
 This assumes a 15% protective margin (See Figure 4)
- Z* is surge impedance of transmission line (in ohms) (Refer to Table 5 in IEEE Std C62.11-1993)

C.5 Single-line single-transformer substation, example 1

Refer to Figure C.1. Parameters in this example for a 115 kV system are as follows:

- BIL* is 350 kV
- C* is $984 \text{ ft}/\mu\text{s}$ ($300 \text{ m}/\mu\text{s}$)
- d* is $d' + d'' = 25 \text{ ft}$ (7.6 m)
- S'* is $11 \times \text{MCOV rating} = 11 \times 70 = 770 \text{ kV}/\mu\text{s}$

| | |
|-------|--|
| S | is S' in this example |
| V_a | is 226 kV for MCOV = 70 kV Time to crest voltage: $(226/770) < 2 \mu\text{s}$ Use $V_T = CWW/1.15$ |
| Z | is 450 Ω |

Calculate the following:

| | |
|--------------|---|
| CWW | is $1.1 \times BIL = 1.1 \times 350 = 385 \text{ kV}$ |
| di/dt | is $2 S/Z = 2(770)/450 = 3.42 \text{ kA}/\mu\text{s}$ |
| L | is $(d' + d'') \times 0.4 \mu\text{H}/\text{ft} = 25 \times 0.4 = 10 \mu\text{H}$ $(d' + d'') \times 1.3 \mu\text{H}/\text{m} = 7.6 \times 1.3 = 10 \mu\text{H}$ |
| V_{sa} | is $V_a + L(di/dt) = 226 + 10(3.42) = 260 \text{ kV}$ |
| V_T | is $CWW/1.15 = 385/1.15 = 335 \text{ kV}$ |
| V_T/V_{sa} | is $335/260 = 1.29$ |

The abscissa value corresponding to $V_T/V_{sa} = 1.29$ on the curve of Figure C.8 is $D(S)/(C \times V_{sa}) = 0.068$.

$$\begin{aligned} \text{Solving for: } D & \text{ is } 0.068(C \times V_{sa}) / (S) \\ & \text{is } 0.068(984 \times 260)/770 = 23 \text{ ft (7 m)} \end{aligned}$$

This is the maximum allowable distance between the surge arrester and the transformer.

C.5.1 Calculated allowable separation distances

Allowable separation distances have been calculated using the above procedure for system voltages from 69 kV through 765 kV based on the following:

- Typical values of BILs
- Station class surge arresters
- Minimum MCOV ratings
- Maximum value for the 0.5 μs FOW protective level from Table 1

The allowable separation distances are given in Table 4.

C.6 Multiline two-transformer substation

Figure C.2 shows a substation with three transmission lines, two transformers, and one set of surge arresters. Allowable surge arrester separation distances should be calculated for each transformer, assuming the incoming surge on each of the three lines, to determine the surge-protection adequacy of both transformers with one set of surge arresters.

To use the method of this annex, the multiline two-transformer substation of Figure C.2 has to be reduced to a single-line single-transformer substation similar to that of Figure C.1. The following procedure shows the reduction method. The procedure should be repeated for each transformer, while assuming the incoming

surge to travel on each line separately. Line-out conditions may also be investigated to identify the most severe case.




Figure C.2—An example of multiline two-transformer substation

C.6.1 Step-by-step procedure for reduction process

Step 1: Remove the transformer not being considered and identify the transmission line with the incoming surge.

Step 2: Identify parameters.

- a) Identify junction J, which is the common point among the transformer lead, surge arrester lead, and the surged line.
- b) Identify the separation distance D as the connection between junction J and the transformer terminal that would include the bus-bar length, if applicable.
- c) Identify the surge arrester lead d' as the connection between junction J and the surge arrester that would include the bus-bar length, if applicable.

Step 3: Remove all lines connected to d' (connection between junction J and surge arrester).

Step 4: The rate of voltage rise at junction J is $S = (S') \times 3(N + 2)$, where N equals the total number of lines (including the surged line) remaining after Step 3.

The multiline two-transformer substation has been reduced, and the maximum allowable separation distance, D, can be calculated using the procedure used in Section C.5.

C.6.2 Multiline two-transformer substation—example 2

Refer to Figures C.2 and C.3. Parameters used in this example for a 138 kV system follow:

- BIL is 450 kV;
- C is 984 ft/ μ s (300 m/ μ s);
- d' is 40 ft (12 m);
- d'' is 10 ft (3 m);
- S' is $11 \times \text{MCOV rating} = 11 \times 84 = 924 \text{ kV}/\mu\text{s}$;
- V_a is 273 kV for MCOV = 84 kV; and
Time to crest voltage: $(273/924) < 2 \mu\text{s}$
Use $V_T = CWW/1.15$
- Z is 450 Ω .

C.6.2.1 Reduction of Figure C.2—incoming surge on line A

Step 1: Remove transformer not being considered, T2 in this case, and assume the incoming surge is on Line A. See Figure C.3.

Step 2: Identify parameters.

- Identify junction J , where the dashed lines meet in Figure C.3;
- Identify the separation distance D ; and
- Identify the surge arrester lead d' ; $d' = 40$ ft (12 m) in this example (See Figure C.2), and $d = d' + d'' = 40 + 10 = 50$ ft (12 + 3 = 15 m).

Step 3: Remove all lines connected to d' ; Line C in this case

Step 4: Calculate the voltage rate of rise at junction J .

$$S(S_1) \times 3/(N + 2); N = 2 \text{ (see Figure C.4)}$$

$$= (924) \times 3/(2 + 2) = 693 \text{ kv}/\mu\text{s} \text{ (see Figure C.4)}$$




Figure C.3—Example 2—multiline two-transformer substation with an incoming surge on line A—transformer T2 not being considered is removed

The reduced single-line single-transformer substation to be analyzed is shown in Figure C.5. Calculate the following:

$$CWW = 1.1 \times BIL = 1.1 \times 450 = 495 \text{ kV}$$

$$di/dt = 2(S)/Z = 2(693)/450 = 3.08 \text{ kA}/\mu\text{s}$$

$$L = (d' + d'') 0.4 \mu\text{H}/\text{ft} = (50)0.4 = 20 \mu\text{H}$$

$$(d' + d'') 1.3 \mu\text{H}/\text{m} = (15)1.3 = 20 \mu\text{H}$$

$$V_{sa} = V_a + L(di/dt) = 273 + 20(3.08) = 335 \text{ kV}$$

$$V_T = CWW/1.15 = 495/1.15 = 430 \text{ kV}$$

$$V_T/V_{sa} = 430/335 = 1.28$$




Figure C.4—Example 2—multiline two-transformer substation with an incoming surge on line A—simplified to a single-line single-transformer substation

The abscissa value corresponding to $V_T/V_{sa} = 1.28$ on the curve of Figure C.8 is $D(S)/(C \times V_{sa}) = 0.066$.

$$\begin{aligned} \text{Solving for } D &= 0.066 (C \times V_{sa}) / (S) \\ &= 0.066 (984 \times 335) / (693) = 31 \text{ ft (9.4 m)} \end{aligned}$$

This is the maximum allowable distance between the surge arrester and the T1 transformer if Line A is the surged line.

Repeat the procedure with the incoming surge on each of the other lines. C.6.2.2 shows the incoming surge on Line C.

C.6.2.2 Reduction of Figure C.2—incoming surge on line C




Figure C.5—Example 2—multiline two-transformer substation with an incoming surge on line C—transformer T2 not being considered is removed

Step 1: Remove transformer not being considered, T2 in this case, and assume the incoming surge is on Line C. See Figure C.6.

Step 2: Identify parameters.

- Identify junction J, where the dashed lines meet in Figure C.6;
- Identify the separation distance D; and
- Identify the surge arrester lead d' ; $d' = 20$ ft (6m) in this example (see Figure C.2), and $d = d' + d'' = 20 + 10 = 30$ ft (6 + 3 = 9 m).

Step 3: Remove all lines connected to d' ; none in this case.

Step 4: Calculate the voltage rate of rise at junction J.

$$S = (S') \times 3/(N + 2); N = 3 \text{ (see Figure C.6)}$$

$$= (924) \times 3/(3+2)$$

$$= 554 \text{ kV}/\mu\text{s}$$




Figure C.6—Example 2—multiline two-transformer substation with an incoming surge on line C—reduced to a single-line single-transformer case

The reduced single-line single-transformer substation to be analyzed is shown in Figure C.7.




Figure C.7—Example 2—multiline two-transformer substation with an incoming surge on line C—reduced to a single-line single-transformer case

Calculate the following:

$$CWW = 1.1 \times BIL = 1.1 \times 450 = 495 \text{ kV}$$

$$di/dt = 2(S)/Z = 2(554)/450 = 2.46 \text{ kA}/\mu\text{s}$$

$$L = (d' + d'') 0.4 \mu\text{H}/\text{ft} = (30)0.4 = 12 \mu\text{H}$$

$$(d' + d'') 1.3 \mu\text{H}/\text{m} = (9)1.3 = 12 \mu\text{H}$$

$$V_{sa} = V_a + L(di/dt) = 273 + 12(2.46) = 302 \text{ kV}$$

$$V_T = CWW/1.15 = 495/1.15 = 430 \text{ kV}$$

$$V_T/V_{sa} = 430/302 = 1.42$$

The abscissa value corresponding to $V_T/V_{sa} = 1.42$ on the curve of Figure C.8 is $D(S)/(C \times V_{sa}) = 0.108$.

$$\text{Solve for: } D = 0.108(984 \times 302)/(554) = 58 \text{ ft (17.7 m)}$$

An incoming surge on Line A is more critical than one on Line C ($D = 31$ ft versus 58 ft or 9.4 m versus 17.7 m).

Repeat the procedure with the incoming surge on Line B, and determine the maximum allowable separation distance D for transformer T1.

A similar procedure should be followed to determine the maximum allowable separation distance D for transformer T2.

C.7 Equation representation for Figure C.8

The following equation may be used to calculate the maximum allowable separation distance (D). The equation closely approximates the curve in Figure C.8.

$$D \leq \left[\frac{0.385(CV_{sa})}{S} \right] \times \left[\frac{0.957BIL - V_{sa}}{2.92V_{sa} - 0.957BIL} \right] \quad (\text{C.1})$$

Summary of maximum voltage at transformer (VT) expressed as ratio to maximum voltage at surge arrester (VSA) at junction *J*.




Figure C.8—Curve for graphical determination of acceptable separation distance of surge arrester from a transformer

Annex D

(informative)

Bibliography

[B1] AIEE Committee Report, “Switching surges-I—Phase-to-ground voltages,” *AIEE Transactions—Part III Power Apparatus and Systems*, vol. 80, pp. 240–261, June 1961.

[B2] Alexander, R. W., “Synchronous closing control for shunt capacitor banks,” *IEEE Transactions on Power Apparatus and Systems*, vol. 104, no. 9, pp. 2619–2626, Sept. 1985.

[B3] Alvinsson et al., “A systematic approach to lightning insulation co-ordination for GIS with ZnO arresters,” *CIGRE Paper 33-04*, Paris, France, 1984.

[B4] Anderson, J. G., *Transmission Line Reference Book—345 kV and Above*, 2nd Ed., Palo Alto, Calif.: Electric Power Research Institute, chapter 12, 1982.

[B5] Anderson, R. B., and Eriksson, A. J., “Lightning parameters for engineering application,” *Electra*, no. 69, pp. 5–102, Mar. 1980.

[B6] ANSI/IEEE Std 422-1986, *IEEE Guide for the Design and Installation of Cable Systems in Power Generating Stations*.

[B7] “Application guide for surge arresters on distribution systems,” *Report for the Canadian Electrical Association*, Contract No. 077-D-184A, prepared by Ontario Hydro: Toronto, Ontario, Canada, Sept. 1987.

[B8] Auer, G. G., and Schultz, A. J., “An analysis of 14.4/24.9-kV grounded-wye distribution system over-voltages,” *AIEE Transactions*, vol. PAS-73, pp. 1027–1032, Aug. 1954.

[B9] Ball, E. H., Occhini, E., and Luoni, G., “Sheath overvoltages in high voltage cables resulting from special sheath-bonding connections,” *IEEE Transactions on Power Apparatus and Systems*, vol. PAS-84, pp. 974–988, Oct. 1965.

[B10] Barker, P. P., et al., “Characteristics of lightning surges measured at metal oxide distribution arresters,” *IEEE Transactions on Power Delivery*, vol. 8, no. 1, pp. 301–310, Jan. 1993.

[B11] Barker, P. P., et al., “Induced voltage measurements on an experimental distribution line during nearby rocket triggered lightning flashes,” *IEEE Transactions on Power Delivery*, vol. 11, no. 2, pp. 980–995, Apr. 1996.

[B12] Bayless, R. S., et al., “Capacitor switching and transformer transients,” *IEEE Transactions on Power Delivery*, vol. PWRD-3, no. 1, pp.349–357, Jan. 1988.

[B13] Berger, K., Anderson, R. B., and Kroninger, H., “Parameters of lightning flashes,” *Electra*, no. 41, pp. 23–37, July 1975.

[B14] Bewley, L. V., *Traveling Waves On Transmission Systems*, New York: Dover Publications Inc., 1963.

[B15] Boeck, W., et al., “Insulation co-ordination for SF₆ insulated substations,” *CIGRE Paper 33-09*, Paris, France, 1984.

- [B16] Boehne, E. W., and Low, S. S., "Shunt capacitor energization with vacuum interrupters—A possible source of overvoltage," *IEEE Transactions on Power Apparatus and Systems*, vol. 88, no. 9, pp. 1424–1443, Sept. 1969.
- [B17] Brewer, H. S., "Reduction of lightning caused interruptions on electric power systems," *First International Conference on Power Quality, Societe des Electriciens et des Electroniciens*, Oct. 15–18, 1991.
- [B18] Brown, G. W., and Thunander, S., "Frequency of distribution arrester discharge currents due to direct strokes," *IEEE Transactions on Power Apparatus and Systems*, vol. 7-95, pp. 1571–1578, Sept./Oct. 1976.
- [B19] Brunke, J. H., and Schockelt, G. G., "Synchronous energization of shunt capacitors at 230 kV," *IEEE Transactions on Power Apparatus and Systems*, vol. 97, no. 4, p.1009, July/Aug. 1978.
- [B20] Burke, J. J., Douglass, D. A., and Lawrence, D. J., "Distribution fault current analysis," *EPRI EL-3085*, Project 1209-1, Final Report.
- [B21] Burke, J. J., Smith, S. L., and Sakshaug, E. C., "The application of gapless arresters on underground distribution systems," *IEEE Transactions on Power Apparatus and Systems*, vol. 100, no. 3, pp. 1234–1243, Mar. 1981.
- [B22] Byerley, L. G. III, et al., "The measurement and use of lightning ground flash density," Global Atmospherics, Inc., Tucson, Ariz.
- [B23] CAN3-C155-M84, "Shunt capacitors for AC power systems," (a National Standard of Canada).
- [B24] *CEA 072T223*, "Development of improved sheath cross-bonding joint protectors for self-contained underground cables," Prepared by Ontario Hydro for Canadian Electrical Association, Principal investigators: Erven, C. C., and Ringler, K. G., Dec. 1986.
- [B25] Clarke, E., *Circuit Analysis of A-C Power Systems, Volume 1: Symmetrical and Related Components*, New York: John Wiley and Sons, 1943.
- [B26] Crann, L. B., and Flickinger, R. B., "Overvoltages of 14.4/24.9-kV rural distribution systems," *AIEE Transactions*, vol. 73, pp. 1208–1212, Oct. 1954.
- [B27] Cummins, K. L., et al., "NLDN'95: A combined TOA/MDF technology upgrade of the U.S. national lightning detection network," Global Atmospherics, Inc., Tucson, Ariz.
- [B28] Darveniza, M., and Uman, M. A., "Research into lightning protection of distribution systems II—results from Florida field work 1978 and 1979," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, no. 4, pp. 673–682, Apr. 1984.
- [B29] Dick, E. P., et al., "Practical calculation of switching surges at motor terminals," *IEEE Transactions on Energy Conversion*, vol. 3, no. 4, pp. 864–872, Dec. 1988.
- [B30] Dick, E. P., et al., "Practical design of generator surge protection," *IEEE Transactions on Power Delivery*, vol. 6, no. 2, pp. 736–743, Apr. 1991.
- [B31] Dugan, R. C., Kershaw, S. S., and Smith, S. D., "Protecting distribution transformers from low-side current surges," *IEEE Transactions on Power Delivery*, vol. 5, no. 4, pp. 1892–1901, Oct. 1990.
- [B32] Dugan, R. C., and Smith, S. D., "Low-voltage-side current-surge phenomena in single-phase distribution transformer systems," *IEEE Transactions on Power Delivery*, vol. 3, no. 2, pp. 637–647, Apr. 1988.

- [B33] Dunsmore, D. M., et al., "Magnification of transient voltages in multi-voltage-level, shunt-capacitor-compensated circuits," *IEEE Transactions on Power Delivery*, vol. 7, no. 2, pp. 664–673, Apr. 1992.
- [B34] Durbak, D. W., "Zinc-oxide arrester model for fast front surges," *EMTP Newsletter*, vol. 5, no. 1, Jan. 1985.
- [B35] Eriksson, A. J., and Meal, D. V., "The incidence of direct lightning strikes to structures and overhead lines," *IEEE Conference on Lightning and Power Systems*, London, England, June 1984.
- [B36] Eriksson, A. J., Stringfellow, M. F., and Meal, D. V., "Lightning-induced overvoltages on overhead distribution lines," *IEEE Transactions on Power Apparatus and Systems*, vol. 101, pp. 960–968, Apr. 1982.
- [B37] Erven, C. C., and Narang, A., "Switching of large ungrounded shunt capacitor banks on the Ontario hydro system," *CEA 1985 Transactions of Engineering and Operations*, vol. 24, part 1, paper no. 85-A-65, 1985.
- [B38] Gaibrois, G. L., "Lightning current magnitude through distribution arresters," *IEEE Transactions on Power Apparatus and Systems*, vol. 100, no. 3, pp. 964–970, Mar. 1981.
- [B39] Gaibrois, G. L., Huber, W. J., and Stoelting, H. O., "Blowing of distribution transformer fuses by lightning," *IEEE Transactions on Power Apparatus and Systems*, vol. 92, no. 6, p. 1808, Nov./Dec. 1973.
- [B40] Gaibrois, G. L., Mashikian, M. S., and Johnson, K., "Study of lightning current magnitude through distribution arresters," *EPRI EL-1140*, project 1141, final report.
- [B41] Gilliam, J. D., "Field evaluation of MOV arresters on a 35 kV distribution system," *EEI Transmission and Distribution Committee, Distribution Equipment Task Force*, Long Beach, Calif., pp. 139–148, Jan. 15–17, 1986.
- [B42] Goldenhuys, H. R., Stringfellow, M. F., and Meal, D. V., "Measured lightning discharge duty of distribution surge arresters," *IEE Conference on Lightning and Power Systems*, London, England, June 1984.
- [B43] Greenfield, E. W., "Transient behavior of short and long cables," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, no. 11, pp. 3193–3203, Nov. 1984.
- [B44] Greenwood, A., *Electrical Transients in Power Systems*, New York: Wiley Interscience, 1971.
- [B45] Grumm, R. L., "Lightning transient recorder development—Final report," United States Department of Energy and Jet Propulsion Laboratory, June 1981.
- [B46] "Guide to the protection of specially bonded cable systems against sheath overvoltages," *CIGRE WG 07 of Study Committee 21*.
- [B47] Gupta, B. K., et al., "Turn insulation capability of large AC motors, part 2—Impulse strength," *IEEE Transactions on Energy Conversion*, vol. 2, no. 4, pp. 666–673, Dec. 1987.
- [B48] Gupta, B. K., et al., "Turn insulation capability of large AC motors, part 3—Insulation coordination," *IEEE Transactions on Energy Conversion*, vol. 2, no. 4, pp. 674–679, Dec. 1987.
- [B49] Halperin, H., Clem, J. E., and Miller, K. W., "Transient voltages on bonded cable sheaths," *AIEE Transactions*, vol. 54, pp. 73–82, 1935.
- [B50] Hassler, S., et al., "Accessories for specially bonded extruded dielectric transmission cable systems," *EPRI EL-7259*, Project 7893-1, Final Report.

- [B51] Hileman, A. R., "Weather and its effect on air insulation specifications," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, pp. 3104–3116, Oct. 1984.
- [B52] Hileman, A.R., and Weck, K.H., "Practical methods for GIS insulation co-ordination" *CIGRE 33.83 (SC) 05.2 IWD Colloquium*, Edinburgh, Scotland, 1983.
- [B53] Hopkinson, R. H., "Ferroresonance during single-phase switching of 3-phase distribution transformer banks," *IEEE Transactions on Power Apparatus and Systems*, vol. 84, pp. 289–293, Apr. 1965.
- [B54] Hopkinson, R. H., "Ferroresonant overvoltage control based on TNA tests on three-phase delta-wye transformer banks," *IEEE Transactions on Power Apparatus and Systems*, vol. 86, no. 10, pp. 1258–1265, Oct. 1967.
- [B55] Hopkinson, R. H., "Ferroresonant overvoltage control based on TNA tests on three-phase wye-delta transformer banks," *IEEE Transactions on Power Apparatus and Systems*, vol. 87, no. 2, pp. 352–361, Feb. 1968.
- [B56] IEEE Std 525-1992, *IEEE Guide for the Design and Installation of Cable Systems in Substations*.
- [B57] IEEE Std 532-1982, *IEEE Guide for Selecting and Testing Jackets for Underground Cable*.
- [B58] IEEE Std 575-1988, *IEEE Guide for the Application of Sheath Bonding Methods for Single Conductor Cables and the Calculation of Induced Voltages and Currents in Cable Sheaths*.
- [B59] IEEE Std C62.2-1987, *IEEE Standard for the Application of Gapped-Silicon-Carbide Surge Arresters for AC Systems*.
- [B60] IEEE Committee Report, "Surge protection of cable-connected distribution equipment on underground systems," *IEEE Transactions on Power Apparatus and Systems*, vol. 89, pp. 263–267, Feb. 1970.
- [B61] IEEE Committee Report, "Switching surges, II—Selection of typical waves for insulation coordination," *IEEE Transactions on Power Apparatus and Systems*, vol. 85, no. 10, pp. 1091–1097, Oct. 1966.
- [B62] IEEE Committee Report, "Switching surges, III—Field and analyzer results for transmission lines. Past, present and future trends," *IEEE Transactions on Power Apparatus and Systems*, vol. 89, pp.173–189, Feb. 1970.
- [B63] IEEE Switchgear Committee and Surge Protective Devices Committee Working Group, "Coordination of lightning arresters and current-limiting fuses," *IEEE Transactions on Power Apparatus and Systems*, vol. 91, no. 3, pp. 1075–1078, May/June 1972.
- [B64] IEEE Transformer Committee Task Force Report, "Secondary (low side) surges in distribution transformers," *IEEE Transactions on Power Delivery*, vol. 7, no. 2, pp. 746–756, Apr. 1992.
- [B65] IEEE Tutorial Course—Surge Protection in Power Systems, *79EHOI44-6-PWR*, chapter 2, 1978.
- [B66] IEEE Working Group Report, "A simplified method for estimating lightning performance of transmission lines," *IEEE Transactions on Power Apparatus and Systems*, vol. 104, no. 4, pp. 919–932, Apr. 1985.
- [B67] IEEE Working Group Report, "Impact of shunt capacitor banks on substation surge environment and surge arrester applications," *IEEE Transactions on Power Delivery*, vol. 11, no. 4, pp. 1798–1809, Oct. 1996.

- [B68] IEEE Working Group Report, "Impulse voltage strength of A.C. rotating machines," *IEEE Transactions on Power Apparatus and Systems*, vol. 100, no. 8, pp. 4041–4053, Aug. 1981.
- [B69] IEEE Working Group Report, "Modeling of metal-oxide surge arresters," *IEEE Transactions on Power Delivery*, vol. 7, no. 1, pp. 302–309, Jan. 1992.
- [B70] IEEE Working Group Report, "Service experience with lightning arresters under contaminated conditions," *IEEE Transactions on Power Apparatus and Systems*, vol. 90, no. 1, pp. 369–383, Jan./Feb. 1971.
- [B71] IEEE Working Group Report, "Surge protection of cable-connected equipment on higher voltage distribution systems," *IEEE Transactions on Power Apparatus and Systems*, vol. 100, no. 1, pp. 154–157, Jan. 1981.
- [B72] IEEE Working Group Report, "Surge protection of high voltage shunt capacitor banks on AC power systems survey results and application considerations," *IEEE Transactions on Power Delivery*, vol. PWRD-11, no. 4, pp. 1798–1809, Oct. 1996.
- [B73] IEEE Working Group Report, "Voltage rating investigation for application of lightning arresters on distribution systems," *IEEE Transactions on Power Apparatus and Systems*, vol. 91, no. 3, pp. 1067–1074, May/June 1972.
- [B74] Jackson, D. W., "Analysis of surge capacitor lead connections for the protection of motors," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, no. 9, pp. 2605–2611, Sept. 1984.
- [B75] Janssen, A. L. J., and van der Sluis, L., "Controlling the transient currents and overvoltages after the interruption of a fault near shunt capacitor banks," *CIGRE Paper 13-13*, Paris, 1988
- [B76] Jones, R. A., and Fortson Jr., H. S., "Consideration of Phase-to-Phase Surges in Application of Capacitor Banks," *IEEE Transactions on Power Delivery*, vol. 1, no. 3, pp. 240–244, July 1986.
- [B77] Keri, A. J. F., Musa, Y. I., and Halladay, J. A., "Insulation coordination for delta connected transformers," *IEEE Transactions on Power Delivery*, vol. 9, no. 2, pp. 772–780, Apr. 1994.
- [B78] Kershaw Jr., S. S., "Application of arresters for underground systems protection," *Pacific Coast Electrical Association, Engineering and Operating Conference*, Los Angeles, Calif., Mar. 22–23, 1973.
- [B79] Kershaw Jr., S. S., "Surge protection for high voltage underground distribution circuits," *IEEE Conference on Underground Distribution*, pp. 379–384, 1971.
- [B80] Kershaw Jr., S. S., and Clinkenbeard, C. R., "Discharge voltage of arrester connecting lead wires," *IEEE Transactions on Power Apparatus and Systems*, vol. 93, no. 1, pp. 226–232, Jan./Feb. 1974.
- [B81] Kershaw Jr., S. S., Gaibrois, G. L., and Stump, K. B., "Applying metal-oxide surge arresters on distribution systems," *IEEE Transactions on Power Delivery*, vol. 4, pp. 301–307, Jan. 1989.
- [B82] Kershaw Jr., S. S., Huber, W. J., and Hassler, S. P., "Effect of current-limiting fuse operation on arrester performance," *IEEE Underground T & D Conference*, Atlantic City, N.J., 1976.
- [B83] Koch, R. E., et al., "Design of zinc-oxide transmission line arresters for application on 138 kV towers," *IEEE Transaction on Power Apparatus and Systems*, vol. 104, no. 10, pp. 2675–2680, Oct. 1985.
- [B84] Kuwahara, K., and Doench, C., "Evaluation of power frequency sheath currents and voltages in single conductor cables for various sheath bonding methods," *IEEE Transactions on Power Apparatus and Systems*, special supplement, vol. 82, pp. 206–235, 1963.

[B85] Lat, M. V., "A simplified method for surge protection of underground distribution systems with metal oxide arresters," *IEEE Transactions on Power Delivery*, vol. 2, no. 4, pp. 1110–1116, Oct. 1987.

[B86] Lat, M. V., "Determining temporary overvoltage levels for application of metal oxide surge arresters on multigrounded distribution systems," *IEEE Transactions on Power Delivery*, vol. 5, no. 2, pp. 936–946, Apr. 1990.

[B87] Linck, H., "Surge arrester discharges on 27 kV Essex area feeder," *Ontario Hydro Research Division Report*, May 1977.

[B88] Lishchyna, L., and Brierley, R. H., "Capacitor switching surges and possible effects on transformer insulation," *CEA 1983 Transaction of Engineering and Operations*, vol. 25, paper no. P86-SP-148, 1983.

[B89] Lishchyna, L., and Brierley, R. H., "Phase to phase switching surges due to capacitor energization," *CEA 1986 Transaction of Engineering and Operations*, vol. 25, paper no. P86-SP-148.

[B90] MacCarthy, D. D., et al., "Lightning investigation on a rural distribution system," *AIEE Transactions*, vol. 68, pp. 428–438, 1949.

[B91] MacGorman, D. R., Maier, M. W., and Rust, W. D., "Lightning strike density for the contiguous United States from thunderstorm duration records," National Severe Storms Laboratory, Norman, Okla.

[B92] Marti, L., "Simulation of transients in underground cables with frequency-dependent modal transformation matrices," *IEEE Transactions on Power Delivery*, vol. 3, no. 3, pp. 1099–1110, July 1988.

[B93] McCauley, T. M., et al., "The impact of shunt capacitor installations on power circuit breaker application," *IEEE Transactions on Power Apparatus and Systems*, vol. 99, no. 6, pp. 2210–2222, Nov./Dec. 1980.

[B94] McEachron, K. B., and McMorris, W. A., "Discharge currents in distribution arresters-II," *AIEE Transactions*, vol. 57, pp. 307–314, June 1938.

[B95] McGranaghan, M. F., et al., "Impact of utility switched capacitors on customer systems—Magnification at low voltage capacitors," *IEEE Transactions on Power Delivery*, vol. 7, no. 2, pp. 862–868, Apr. 1992.

[B96] McGranaghan, M. F., et al., "Overvoltage protection of shunt-capacitor banks using MOV arresters," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, no. 8, pp. 2326–2336, Aug. 1984.

[B97] McLaren, P. G., and Abdel-Rahman, M. H., "Steep fronted surges applied to large A. C. motors—Effect of surge capacitor value and lead length," *IEEE Transactions on Power Delivery*, vol. 3, no. 3, pp. 990–997, July 1988.

[B98] McMillen, C. J., Schoendube, C. W., and Kaufmann, G. H., "Surge characteristics and protection of distribution transformer," *EL-3385*, project 1532-1, final report.

[B99] Mikhail, S. S., and McGranaghan, M. F., "Evaluation of switching concerns associated with 345 kV shunt capacitor applications," *IEEE Transactions on Power Delivery*, vol. 1, no. 2, pp. 221–230, Apr. 1986.

[B100] Miller, D. D., and Westrom, A. C., "Traveling wave tests yield new protection alternatives for underground distribution," *EET&D Committee*, Tulsa, Okla., Oct. 7–8, 1976.

[B101] NEMA *Standard CP-1-1988*, "Shunt capacitors."

[B102] *NOVA Lightning! #2213*, WGBH/BOSTON Science Unit, WGBH Educational Foundation, video.

- [B103] O'Leary, R. P., and Harner, R. H., "Evaluation of methods for controlling the overvoltages produced by the energization of a shunt capacitor bank," *CIGRE 1988 Session Paper No. 13-05*.
- [B104] Olive Jr., W. W., and Westrom, A. C., "Current limiting fuses with tapered wire elements provide peak arc voltage control," *IEEE Underground T&D Conference*, Dallas, Tex., 1974.
- [B105] Orville, R. E., Henderson, R. W., and Pyle, R., "Lightning flash characteristics," *B.EPRI EL-4729*, project 2431-1, interim report.
- [B106] Owen, R. E., "Surge behavior of UD cable systems," *EPRI EL-720*, project 795-1, final report.
- [B107] Owen, R. E., and Clinkenbeard, C. R., "Surge protection of UD cable systems—Part 1: cable attenuation and protective constraints," *IEEE Transactions on Power Apparatus and Systems*, vol. 97, no. 4, pp. 1319–1327, July/Aug. 1978.
- [B108] Parmigiani, B., et al., "Zinc oxide sheath voltage limiter for HV and EHV power cable: Field experience and laboratory tests," *IEEE Transactions on Power Delivery*, vol. 1, pp. 164–170, Jan. 1986.
- [B109] Pflanz, H. M., and Lester, G. N., "Control of overvoltages on energizing capacitor banks," *IEEE Transactions on Power Apparatus and Systems*, vol. 92, no. 3, pp. 907–915, May/June 1973.
- [B110] Powell, R. W., "Lightning protection of underground residential distribution circuits," *IEEE Transactions on Power Apparatus and Systems*, vol. 86, no. 9, pp. 1052–1056, Sept. 1967.
- [B111] *Proceedings of the International Symposium on Gas Insulated Substations: Technology and Practice, Toronto, 1985*, Edited by S.A. Boggs, F.Y. Chu, N. Fujimote, Ontario Hydro Research, Toronto, Canada, New York: Pergamon Press, 1986.
- [B112] "Recommendations for tests on anti-corrosion coverings of self-contained pressure cables and accessories and equipment for specially bonded circuits," *Electra*, no. 75, pp. 41–61, Mar. 1981.
- [B113] Reid, W. C., "Capacitor application considerations—Utility/user interface," *T&D Conference*, New Orleans, La., Apr. 1976.
- [B114] Reid, W. E., et al., "MOV arrester protection of shield interrupts on 138 kV extruded dielectric cables," *IEEE Transactions on Power Apparatus and Systems*, vol. 103, pp. 3334–3341, Nov. 1984.
- [B115] Ringler, K. G., et al., "The energy absorption capability and time-to-failure of varistors used in station-class metal-oxide surge arresters," *IEEE Transactions on Power Delivery*, vol. 12, no. 1, pp. 203–212, Jan. 1997.
- [B116] Sabot, A., et al., "A unique multipurpose damping circuit for shunt capacitor bank switching," *IEEE Transactions on Power Delivery*, vol. 8, no. 3, pp. 1173–1183, July 1993.
- [B117] Schei, A., and Huse, J., "Currents through surge arresters due to lightning with main reference to distribution systems," *Electra*, vol. 58, pp. 41–78, May 1978.
- [B118] Schultz, A. J., Johnson, I. B., and Schultz, N. R., "Magnification of switching surges," *AIEE Transactions on Power Apparatus and Systems*, vol. 77, pp. 1418–1426, Feb. 1959.
- [B119] Short, T. A., Burke, J. J., and Mancao, R. T., "Application of MOVs in the distribution environment," *IEEE Transactions on Power Delivery*, vol. 9, no. 1, pp. 293–305, Jan. 1994.

- [B120] Smith, D. R., Swanson, S. R., and Borst, J. D., "Overvoltages with remotely-switched cable-fed grounded wye-wye transformers," *IEEE Transactions on Power Apparatus and Systems*, vol. 94, no. 5, pp. 1843–1853, Sept./Oct. 1975.
- [B121] Stenstrom, L., "Application guidelines for shunt capacitor overvoltage control," *CIGRE SC33-93 W.G.(11)4IWD*.
- [B122] Task Force Report, "Investigation and evaluation of lightning protective methods for distribution circuits, part I: Model study and analysis," *IEEE Transactions on Power Apparatus and Systems*, vol. 88, pp. 1232–1238, Aug. 1969.
- [B123] Task Force Report, "Investigation and evaluation of lightning protective methods for distribution circuits, part II: Application and evaluation," *IEEE Transactions on Power Apparatus and Systems*, vol. 88, pp. 1239–1247, Aug. 1969.
- [B124] "The design of specially bonded cable circuits," *Electra*, no.47, pp. 61–86, July 1976.
- [B125] Uman, M. A., *The Lightning Discharge*, Orlando: Academic Press, 1987.
- [B126] Valentine, W. W., Dillard, J. K., and Clayton, J. M., "Surge Attenuation in Power Cables," *AIEE Transactions*, vol. 74, pp. 1115–1122, Dec. 1955.
- [B127] van der Merwe, H., and van der Merwe, F. S., "Some features of traveling waves on cables," *IEEE Transactions on Power Delivery*, vol. 8, no. 3, pp.789–797, July 1993.
- [B128] van der Sluis, L., and Janssen, A. L. J., "Clearing faults near shunt capacitor banks," *IEEE Transactions on Power Delivery*, vol. 5, no. 3, pp. 1346–1354, July 1990.
- [B129] Wagner, C. F., Gross, I. W., and Lloyd, B. L., "High-voltage impulse tests on transmission lines," *AIEE Transactions on Power Apparatus and Systems*, vol. 73, pp. 196–210, Apr. 1954.
- [B130] Walling, R. A., et al., "Ferroresonant overvoltages in grounded wye-wye padmount transformers with low-loss silicon-steel cores," *IEEE Transactions on Power Delivery*, vol. 8, no. 3, pp. 1647–1660, July 1993.
- [B131] Walling, R. A., et al., "Performance of metal-oxide arresters exposed to ferroresonance in padmount transformers," *IEEE Transactions on Power Delivery*, vol. 9, no. 2, pp. 788–795, Apr. 1994.
- [B132] Watson, W., and Erven, C. C., "Surge potentials on underground cable sheath and joint insulation," *IEEE Transactions on Power Apparatus and Systems*, vol. 66, pp. 239–249, June 1963.
- [B133] Witzke, R. L., and Bliss, T. J., "Coordination of lightning arrester location with transformer insulation level," *AIEE Transactions on Power Apparatus and Systems*, vol. 69, pp. 964–975, 1950.
- [B134] Witzke, R. L., and Bliss, T. J., "Surge protection of cable-connected equipment," *AIEE Transactions on Power Apparatus and Systems*, vol. 69, pp. 527–542, 1950.
- [B135] Yamada, T., et al., "Development of suspension-type arresters for transmission lines," *IEEE Transactions on Power Delivery*, vol. 8, no. 3, pp. 1052–1060, July 1993.
- [B136] Young, F. S., Schmid, R. L., and Fergestad, P. I., "A laboratory investigation of ferroresonance in cable-connected transformers," *IEEE Transactions on Power Apparatus and Systems*, vol. PAS-87, no. 5, pp. 1240–1249, May 1968.

Annex E

(informative)

Distribution system overvoltage line diagrams





Figure E.1—Shorted secondary



$$\begin{aligned}
 V_{ARR} &= V_{AN} - V_A \\
 &= 7.2 \angle 60 - \frac{12.47}{2} \angle 90 \\
 &= 7.2 (0.5 + j0.866) - 6.235 (0 + j1) \\
 &= 3.6 + j6.235 - j6.235 \\
 &= 3.6 \angle 0
 \end{aligned}$$

OR

$$\begin{aligned}
 V_{ARR} &= V_{CN} + V_C \\
 &= 7.2 \angle -60 + \frac{12.47}{2} \angle 90 \\
 &= 7.2 (0.5 - j0.866) + 6.235 (0 + j1) \\
 &= 3.6 - j6.235 + j6.235 \\
 &= 3.6 \angle 0
 \end{aligned}$$

- NOTES: (1) USE 1:1 RATIO FOR CALCULATIONS.
 (2) UNBALANCED LOAD ACROSS "B" ONLY WOULD NOT ALTER THE ABOVE RESULTS.
 (3) SEE 4.4.5.1.




Figure E.2—Open primary

Annex F

(informative)

Dual transformer station




Figure F.1—Dual transformer station

Annex G

(informative)

Modeling of gapless metal-oxide surge arresters

G.1 Introduction

Data on the characteristics of surge arresters has been gathered to form a basis for modeling of surge arresters. The data indicates that metal-oxide arresters have dynamic (or frequency-dependent) characteristics that are significant for lightning and other fast wavefront surges. The significant dynamic characteristics are that the voltage across a metal-oxide arrester increases as the time to crest of the arrester current decreases and that the arrester voltage reaches a peak before the arrester current reaches its peak. This would not be the case if the metal-oxide valve element performed strictly as a non-linear resistance. Dynamic effects are significant considerations for surge arrester location and insulation coordination studies.

G.2 Recommended model for temporary overvoltage and switching surge studies

One objective of a transient study is to evaluate the performance of metal-oxide arresters during temporary and switching surge overvoltages on the system. These overvoltages have a slow wavefront and therefore do not exhibit the dynamic effects mentioned previously. A metal-oxide arrester model suitable for these studies would be a simple, non-linear V-I characteristic. The V-I characteristic should be chosen to be consistent with the range of currents expected in the simulation. Also, consideration should be given to manufacturing tolerances when choosing the appropriate V-I characteristic. For example, if a simulation is being made to determine the maximum voltage to which equipment will be subjected, the characteristic which gives the maximum voltage for a given current should be used. If the simulation is being made to determine the energy which the arrester should dissipate, then the characteristic which gives the minimum voltage for a given current should be used.

G.3 Recommended model for lightning studies

The time to crest for surges found in lightning studies can range from 0.5 μs to several μs . These are fast wavefront surges for which a metal-oxide arrester exhibits the dynamic effects mentioned previously. A model which will represent these effects over this range of times to crest is shown in Figure G.1. In this model the non-linear resistance designated A0 and A1. (See Table G.1— taken from Durbak [34]). The two sections are separated by an R-L filter. For slow-front surges, this R-L filter has very little impedance, and the two non-linear sections of the model are essentially in parallel. For fast-front surges, the impedance of the R-L filter becomes more significant. This results in more current in the non-linear section designated A0 than in the section designated A1. Since characteristic A0 has a higher voltage for a given current than A1, the result is that the arrester model generates a higher voltage. Since metal-oxide arresters have a higher discharge voltage for fast-front surges, the model matches the overall behavior of a metal-oxide arrester.




Figure G.1 – Frequency-dependent model

The following formulas are suggested for choosing the parameters of the model based on an estimated height of an arrester and the number of parallel columns of metal-oxide disks (Durbak [B34]). The inductance $L1$ and the resistance $R1$ of the model comprise the filter between the two nonlinear resistances. The formulas for these two parameters are:

$$\begin{aligned} L1 & \text{ is } 15 \text{ d/n microhenries} \\ R1 & \text{ is } 65 \text{ d/n ohms} \end{aligned}$$

where

$$\begin{aligned} d & \text{ is estimated height of the arrester in meters (use overall dimensions from catalog data)} \\ n & \text{ is number of parallel columns of metal-oxide disks in the arrester.} \end{aligned}$$

The inductance $L0$ in the model represents the inductance associated with magnetic fields in the immediate vicinity of the arrester. The resistor $R0$ is used to stabilize the numerical integration when the model is implemented on a digital computer program. The capacitance C represents the terminal-to-terminal capacitance of the arrester.

$$\begin{aligned} L0 & \text{ is } 0.2 \text{ d/n microhenries} \\ R0 & \text{ is } 100 \text{ d/n } \Omega \\ C & \text{ is } 100 \text{ n/d pF} \end{aligned}$$

The non-linear V-I characteristics $A0$ and $A1$ can be estimated from the voltage-current points given in Table G.1.

Efforts to match model results to laboratory test data have indicated that these formulas do not always give the best parameters for the frequency-dependent model. However, they do provide a good starting point for picking the parameters. Parameter $L1$ has the most impact while the other parameters have little impact. The following procedure is recommended for choosing the parameters of the frequency-dependent model [B72].

- a) Use the previously given formulas to derive initial values for $L0$, $R0$, $L1$, $R1$, C and the non-linear characteristics $A0$ and $A1$.
- b) Adjust the per unit value on the curves for characteristics $A0$ and $A1$ to get a good match for the published discharge voltages associated with switching surge discharge currents (time to crest of approximately 45 ms).
- c) Adjust the value of $L1$ to get a good match of published arrester discharge voltages for 8/20 μ s discharge currents.

Table G.1 — Frequency-dependent model

| kA | V-I characteristics of AØ | V-I characteristics of A1 |
|------|---------------------------|---------------------------|
| | V(p.u.) ^a | V (p.u.) ^a |
| 0.01 | 1.40 | — |
| 0.1 | 1.54 | 1.23 |
| 1 | 1.68 | 1.36 |
| 2 | 1.74 | 1.43 |
| 4 | 1.80 | 1.48 |
| 6 | 1.82 | 1.50 |
| 8 | 1.87 | 1.53 |
| 10 | 1.90 | 1.55 |
| 12 | 1.93 | 1.56 |
| 14 | 1.97 | 1.58 |
| 16 | 2.00 | 1.59 |
| 18 | 2.05 | 1.60 |
| 20 | 2.10 | 1.61 |

^a pu is based on a model element that had a 1.6 kV IR at 10 kA. (See Durbak [B34] for greater detail).

The models recommended here apply to single arresters containing one or more columns of metal-oxide disks. If multiple arresters are used in parallel, the models used must reflect the fact that the nonlinear characteristics are not identical.